

**Models:**

- |            |            |
|------------|------------|
| CD4236MR   | CD4842MR   |
| CD4236MLR  | CD4842MLR  |
| CD4236MIR  | CD4842MIR  |
| CD4236MILR | CD4842MILR |

**Direct Vent Gas Appliance**

**GAS-FIRED**



**CAUTION**



**DO NOT DISCARD THIS MANUAL**

- Important operating and maintenance instructions included.
- Read, understand and follow these instructions for safe installation and operation.
- Leave this manual with party responsible for use and operation.

**⚠ WARNING**



**If the information in these instructions is not followed exactly, a fire may result causing property damage, personal injury, or death.**

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **What to do if you smell gas:**
  - Do not try to light any appliance.
  - Do not touch any electrical switch. Do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

This appliance may be installed as an OEM installation in manufactured home (USA only) or mobile home and must be installed in accordance with the manufacturer's instructions and the manufactured home construction and safety standard, **Title 24 CFR, Part 3280** or **Standard for Installation in Mobile Homes, CAN/CSA Z240MH**.

*This appliance is only for use with the type(s) of gas indicated on the rating plate.*

**⚠ WARNING**



**HOT SURFACES!**

Glass and other surfaces are hot during operation and cool down.

**Hot glass will cause burns.**

- Do not touch glass until it is cooled
  - NEVER allow children to touch glass
  - Keep children away
  - CAREFULLY SUPERVISE children in same room as appliance.
  - Alert children and adults to hazards of high temperatures.
- High temperatures may ignite clothing or other flammable materials.**
- Keep clothing, furniture, draperies and other combustibles away.

***This appliance has been supplied with an integral barrier to prevent direct contact with the fixed glass panel. Do NOT operate the appliance with the barrier removed.***

Contact your dealer or Hearth & Home Technologies if the barrier is not present or help is needed to properly install one.

In the Commonwealth of Massachusetts installation must be performed by a licensed plumber or gas fitter;

See Table of Contents for location of additional Commonwealth of Massachusetts requirements.



Installation and service of this appliance should be performed by qualified personnel. Hearth & Home Technologies suggests NFI certified or factory-trained professionals, or technicians supervised by an NFI certified professional.

**Read this manual before installing or operating this appliance.  
Please retain this owner's manual for future reference.**

**Congratulations**

Congratulations on selecting a Heatilator gas appliance—an elegant and clean alternative to wood burning appliances. The Heatilator gas appliance you have selected is designed to provide the utmost in safety, reliability, and efficiency.

As the owner of a new appliance, you'll want to read and carefully follow all of the instructions contained in this owner's manual. Pay special attention to all cautions and warnings.

This owner's manual should be retained for future reference. We suggest you keep it with your other important documents and product manuals.


The information contained in this owner's manual, unless noted otherwise, applies to all models and gas control systems.

Your new Heatilator gas appliance will give you years of durable use and trouble-free enjoyment. Welcome to the Heatilator family of appliance products!

<b>Homeowner Reference Information</b>	<i>We recommend that you record the following pertinent information about your appliance:</i>
Model Name: _____	Date purchased/installed: _____
Serial Number: _____	Location on appliance: _____
Dealership purchased from: _____	Dealer phone: _____
Notes: _____	
_____	
_____	

**Listing Label Information/Location**

The model information regarding your specific appliance can be found on the rating plate located in the control area of the appliance.



# Table of Contents

<b>1 Listing and Code Approvals</b>	<b>4</b>	<b>10 Electrical Information</b>	<b>43</b>
A. Appliance Certification . . . . .	4	A. Recommendation for Wire . . . . .	43
B. Glass Specifications . . . . .	4	B. Connecting to the Appliance . . . . .	43
C. BTU Specifications . . . . .	4	C. Intellifire Ignition System Wiring . . . . .	43
D. High Altitude Installations . . . . .	4	D. Standing Pilot Ignition System Wiring . . . . .	44
E. Non-Combustible Materials . . . . .	4	E. Junction Box Installation . . . . .	45
F. Combustible Materials . . . . .	4	F. Wall Switch Installation for Fan (Optional) . . . . .	45
G. Requirements for the Commonwealth of Massachusetts . . . . .	5	<b>11 Finishing</b>	<b>46</b>
<b>2 Getting Started</b>	<b>6</b>	A. Mantel Projections . . . . .	46
A. Design and Installation Considerations . . . . .	6	B. Facing Material . . . . .	46
B. Tools and Supplies Needed . . . . .	6	<b>12 Appliance Setup</b>	<b>47</b>
C. Inspect the Appliance and Components . . . . .	6	A. Remove Clean Face Components . . . . .	47
<b>3 Framing and Clearances</b>	<b>7</b>	B. Remove Glass Assembly . . . . .	47
A. Select Appliance Location . . . . .	7	C. Remove the Shipping Materials . . . . .	47
B. Construct the Appliance Chase . . . . .	8	D. Clean the Appliance . . . . .	47
C. Clearances . . . . .	9	E. Accessories . . . . .	47
<b>4 Termination Locations</b>	<b>11</b>	F. Install the Refractory . . . . .	47
A. Vent Termination Minimum Clearances . . . . .	11	G. Lava Rock, Vermiculite, Rockwool Placement . . . . .	47
<b>5 Vent Information and Diagrams</b>	<b>14</b>	H. Log Assembly . . . . .	48
A. Vent Table Key . . . . .	14	I. Glass Assembly . . . . .	49
B. Use of Elbows . . . . .	14	J. Install Trim . . . . .	49
C. Measuring Standards . . . . .	14	K. Install Clean Face Components . . . . .	49
D. Vent Diagrams . . . . .	15	L. Air Shutter Setting . . . . .	51
E. Installing Vertical Termination Baffle . . . . .	24	<b>13 Operating Instructions</b>	<b>52</b>
<b>6 Vent Clearances and Framing</b>	<b>25</b>	A. Before Lighting Appliance . . . . .	52
A. Pipe Clearances to Combustibles . . . . .	25	B. Lighting the Appliance . . . . .	53
B. Wall Penetration Framing . . . . .	25	C. After the Appliance is Lit . . . . .	55
C. Install the Ceiling Firestop . . . . .	26	D. Frequently Asked Questions . . . . .	55
D. Install Attic Insulation Shield . . . . .	27	<b>14 Troubleshooting</b>	<b>56</b>
<b>7 Appliance Preparation</b>	<b>28</b>	A. Standing Pilot Ignition System . . . . .	56
A. Convert from Top Vent to Rear Vent . . . . .	28	B. Intellifire Ignition System . . . . .	58
B. Securing and Leveling the Appliance . . . . .	32	<b>15 Maintaining and Servicing the Appliance</b>	<b>60</b>
<b>8 Installing Vent Pipe</b>	<b>33</b>	<b>16 Reference Materials</b>	<b>62</b>
A. Assemble Vent Sections . . . . .	33	A. Appliance Dimension Diagram . . . . .	62
B. Disassemble Vent Sections . . . . .	36	B. Vent Components Diagrams . . . . .	63
C. Install the Heat Shield and Horizontal Termination Cap . . . . .	37	C. Service Parts List . . . . .	70
D. Install Roof Flashing and Vertical Termination Cap . . . . .	39	D. Optional Components . . . . .	78
E. Assemble and Install Storm Collar . . . . .	40	E. Limited Lifetime Warranty . . . . .	83
<b>9 Gas Information</b>	<b>41</b>	F. Contact Information . . . . .	84
A. Fuel Conversion . . . . .	41		
B. Gas Pressure . . . . .	41		
C. Gas Connection . . . . .	41		
D. High Altitude Installations . . . . .	42		

**Note:** An arrow (➔) found in the text signifies change in content.

# 1 Listing and Code Approvals

## A. Appliance Certification

**MODELS:** CD4236MR, CD4236MLR, CD4236MIR, CD4236MILR, CD4842MR, CD4842MLR, CD4842MIR, CD4842MILR  
**LABORATORY:** Underwriters Laboratories, Inc. (UL)  
**TYPE:** Direct Vent Gas Appliance  
**STANDARD:** ANSI Z21.88-2005/CSA2.33-2005/UL307B

This product is listed to ANSI standards for "Vented Gas Fireplace Heater" and applicable sections of "Gas Burning Heating Appliances for Manufactured Homes and Recreational Vehicles", and "Gas Fired Appliances for Use at High Altitudes".

**NOT INTENDED FOR USE AS A PRIMARY HEAT SOURCE.** This appliance is tested and approved as either supplemental room heat or as a decorative appliance. It should not be factored as primary heat in residential heating calculations.

## B. Glass Specifications

Hearth & Home Technologies appliances manufactured with tempered glass may be installed in hazardous locations such as bathtub enclosures as defined by the Consumer Product Safety Commission (CPSC). The tempered glass has been tested and certified to the requirements of **ANSI Z97.1** and **CPSC 16 CFR 1202** (Safety Glazing Certification Council **SGCC# 1595** and **1597**. Architectural Testing, Inc. Reports **02-31919.01** and **02-31917.01**).

This statement is in compliance with **CPSC 16 CFR Section 1201.5** "Certification and labeling requirements" which refers to **15 U.S. Code (USC) 2063** stating "...Such certificate shall accompany the product or shall otherwise be furnished to any distributor or retailer to whom the product is delivered."

Some local building codes require the use of tempered glass with permanent marking in such locations. Glass meeting this requirement is available from the factory. Please contact your dealer or distributor to order.

**Note:** This installation must conform with local codes. In the absence of local codes you must comply with the **National Fuel Gas Code, ANSI Z223.1-latest edition** in the U.S.A. and the **CAN/CGA B149 Installation Codes** in Canada.

## C. BTU Specifications

Caliber CD Mesh Series	CD4236M	CD4842M
Standing Pilot or IPI		
Max/Min Input Rate (NG)	30,000/20,000	33,000/22,000
Orifice Size (NG)	.104 in./2.64 mm	.109 in./2.77 mm
Max/Min Input Rate (LP)	29,500/20,000	32,500/20,500
Orifice Size (LP)	.065 in./1.65 mm	.067 in./1.70 mm

## D. High Altitude Installations

U.L. Listed gas appliances are tested and approved without requiring changes for elevations from 0 to 2000 feet in the U.S.A. and Canada.

When installing this appliance at an elevation above 2000 ft, it may be necessary to decrease the input rating by changing the existing burner orifice to a smaller size. Input rate should be reduced by 4% for each 1000 ft above a 2000 ft elevation in the U.S.A., or 10% for elevations between 2000 and 4500 ft in Canada. If the heating value of the gas has been reduced, these rules do not apply. To identify the proper orifice size, check with the local gas utility.

If installing this appliance at an elevation above 4500 ft (in Canada), check with local authorities.

### WARNING

Do NOT use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

## E. Non-Combustible Materials

Material which will not ignite and burn. Such materials are those consisting entirely of steel, iron, brick, tile, concrete, slate, glass or plasters, or any combination thereof.

Materials that are reported as passing **ASTM E 136, Standard Test Method for Behavior of Materials in a Vertical Tube Furnace at 750° C**, shall be considered non-combustible materials.

## F. Combustible Materials

Materials made of or surfaced with wood, compressed paper, plant fibers, plastics, or other material that can ignite and burn, whether flame proofed or not, or whether plastered or unplastered shall be considered combustible materials.

**NOTE:** The following requirements reference various Massachusetts and national codes not contained in this document.

## G. Requirements for the Commonwealth of Massachusetts

For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

### Installation of Carbon Monoxide Detectors

At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors.

In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.

In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

### Approved Carbon Monoxide Detectors

Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.

### Signage

A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "**GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS**".

## Inspection

The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.

## Exemptions

The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:

- The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
- Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

## MANUFACTURER REQUIREMENTS

### Gas Equipment Venting System Provided

When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

- Detailed instructions for the installation of the venting system design or the venting system components; and
- A complete parts list for the venting system design or venting system.

### Gas Equipment Venting System NOT Provided

When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:

- The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
- The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

**See Gas Connection section for additional Commonwealth of Massachusetts requirements.**

# 2 Getting Started

## A. Design and Installation Considerations

Heatilator direct vent gas appliances are designed to operate with all combustion air siphoned from outside of the building and all exhaust gases expelled to the outside. No additional outside air source is required.

### CAUTION

- Check building codes prior to installation.
- Installation **MUST** comply with local, regional, state and national codes and regulations.
  - Consult insurance carrier, local building, fire officials or authorities having jurisdiction about restrictions, installation inspection, and permits.

When planning an appliance installation, it's necessary to determine the following information before installing:

- Where the appliance is to be installed.
- The vent system configuration to be used.
- Gas supply piping.
- Electrical wiring.
- Framing and finishing details.
- Whether optional accessories—devices such as a fan, wall switch, or remote control—are desired.



### WARNING

- Keep appliance dry.
- Mold or rust may cause odors.
  - Water may damage controls.



## B. Tools and Supplies Needed

Before beginning the installation be sure that the following tools and building supplies are available.

- |  |                                   |
|--|-----------------------------------|
| Reciprocating saw                                      | Framing material                  |
| Pliers   | Hi temp caulking material         |
| Hammer   | Gloves                            |
| Phillips screwdriver                                   | Framing square                    |
| Flat blade screwdriver                                 | Electric drill and bits (1/4 in.) |
| Plumb line   | Safety glasses                    |
| Level  | Manometer                         |
| Voltmeter  | Tape measure                      |
| Non-corrosive leak check solution                      |                                   |
| 1/2 - 3/4 in. length, #6 or #8 Self-drilling screws    |                                   |
| One 1/4 in. female spade connection (for optional fan) |                                   |

## C. Inspect the Appliance and Components

### WARNING



Inspect appliance and components for damage. Damaged parts may impair safe operation.



- Do NOT install damaged components.
- Do NOT install incomplete components.
- Do NOT install substitute components.

Report damaged parts to dealer.

- Carefully remove the appliance and components from the packaging.
- The vent system components and trim doors are shipped in separate packages.
- The gas logs may be packaged separately and must be field installed.
- Report to your dealer any parts damaged in shipment, particularly the condition of the glass.
- **Read all of the instructions before starting the installation. Follow these instructions carefully during the installation to ensure maximum safety and benefit.**

### WARNING



Hearth & Home Technologies disclaims any responsibility for, and the warranty will be voided by, the following actions:

- Installation and use of any damaged appliance or vent system component.
- Modification of the appliance or vent system.
- Installation other than as instructed by Hearth & Home Technologies.
- Improper positioning of the gas logs or the glass door.
- Installation and/or use of any component part not approved by Hearth & Home Technologies.

**Any such action may cause a fire hazard.**

# 3 Framing and Clearances

**Note:**

- Illustrations reflect typical installations and are FOR DESIGN PURPOSES ONLY.
- Illustrations/diagrams are not drawn to scale.
- Actual installation may vary due to individual design preference.

**WARNING**

**Fire Risk**

Provide adequate clearance:


- Around air openings.
- For service access.

Locate appliance away from traffic areas.

## A. Select Appliance Location

When selecting a location for your appliance it is important to consider the required clearances to walls (See Figure 3.1).

**Note:** For actual appliance dimensions refer to Section 16.



Model #		A	B	C	D	E	F	G	H	I
CD4236	<i>in.</i>	42	50-5/8	23-1/2	71-5/8	50-5/8	52-5/8	43	48	59-3/4
	<i>mm</i>	1067	1286	597	1819	1286	1337	1092	1220	1518
CD4842	<i>in.</i>	48	55-1/4	23-1/2	78-1/4	55-1/4	55-1/4	49	48	59-3/4
	<i>mm</i>	1219	1403	597	1988	1403	1403	1245	1220	1518

Figure 3.1 Appliance Locations

## B. Construct the Appliance Chase

A chase is a vertical boxlike structure built to enclose the gas appliance and/or its vent system. Vertical vents that run on the outside of a building may be, but are not required to be, installed inside a chase.

Construction of the chase may vary with the type of building. These instructions are not substitutes for the requirements of local building codes. Local building codes **MUST** be checked.

Chases should be constructed in the manner of all outside walls of the home to prevent cold air drafting problems. The chase should not break the outside building envelope in any manner.

Walls, ceiling, base plate and cantilever floor of the chase should be insulated. Vapor and air infiltration barriers should be installed in the chase as per regional codes for the rest of the home. Additionally, in regions where cold air infiltration may be an issue, the inside surfaces may be sheetrocked and taped (or the use of an equivalent method) for maximum air tightness.

To further prevent drafts, the ceiling firestops should be caulked with high temperature caulk to seal gaps. Gas line holes and other openings should be caulked with high temperature caulk or stuffed with unfaced insulation. If the appli-


	<b>WARNING</b>
	<b>Fire Risk</b> <ul style="list-style-type: none"><li>• Construct chase to all clearance specifications in manual.</li><li>• Locate and install appliance to all clearance specifications in manual.</li></ul>

## C. Clearances



### WARNING

**Fire Risk**  
**Odor Risk**

- Install appliance on hard metal or wood surfaces extending full width and depth of appliance.
- Do NOT install appliance directly on carpeting, vinyl, tile or any combustible material other than wood.





**Note:** If the inside of the framed cavity is to be finished, the framing dimensions **must** include the finished surface. If drywall is to be attached to the rear wall, the depth must be measured from the drywall surface.



Model		A Rough Opening (Width)	B Rough Opening (Height)	C Rough Opening (Depth)	D Rough Opening (DVP Pipe)
CD4236	<i>in.</i>	42	38-3/4	23-1/2	10
	<i>mm</i>	1067	984	597	254
CD4842	<i>in.</i>	48	38-3/4	23-1/2	10
	<i>mm</i>	1219	984	597	254

Figure 3.2 Clearances to Combustibles

ance is being installed on a cement slab, a layer of plywood may be placed underneath to prevent conducting cold up into





## WARNING



**Fire Risk**

- Comply with all minimum clearances to combustibles as specified.
- Framing or finishing material used on the front of, or in front of, the appliance closer than the minimums listed, must be constructed entirely of noncombustible materials (i.e., steel studs, concrete board, etc.).

Failure to comply may cause fire.

# 4 Termination Locations

## A. Vent Termination Minimum Clearances

	<b>WARNING</b>
	<b>Fire Risk</b>
	<b>Explosion Risk</b>
	Inspect external vent cap regularly.
	<ul style="list-style-type: none"><li>• Ensure no debris blocks cap.</li><li>• Combustible materials blocking cap may ignite.</li><li>• restricted air flow affects burner operation.</li></ul>

	<b>WARNING</b>
	<b>Fire Risk</b>
	<b>Explosion Risk</b>
	Maintain vent clearance to combustibles as specified.
	<ul style="list-style-type: none"><li>• Do not pack air space with insulation or other materials.</li></ul>
	Failure to keep insulation or other materials away from vent pipe may cause fire.




Figure 4.2 specifies minimum vent heights for various pitched roofs.




Figure 4.2 Minimum Height from Roof to Lowest Discharge Opening





Figure 4.3 Multiple Vertical Termination



**Dimension Descriptions**

- A Clearance above the ground, a veranda, porch, deck or balcony - 12 in. (30 cm) minimum. \*
- B Clearance to window or door that may be opened – 10,000 BTUs or less, 6 in. (15 cm) minimum; 10,000-50,000 BTUs, 9 in. (23 cm) minimum; over 50,000 BTUs, 12 in. (30 cm) minimum. \*
- C Clearance to permanently closed window – 12 in. (30 cm) minimum - recommended to prevent condensation on window.
- D Vertical clearance to ventilated soffit located above the termination within a horizontal distance of 2 ft (60 cm) from the centerline of the termination – 18 in. (46 cm) minimum. \*\*
- E Vertical clearance to unventilated soffit - 12 in. (30 cm) minimum. \*\*
- F Clearance to outside corner - 6 in. (15 cm) minimum.
- G Clearance to inside corner - 6 in. (15 cm) minimum.
- H Not to be installed above a meter/regulator assembly within 3 ft (90 cm) horizontally\* from the center line of the regulator (Canada only)
- I Clearance to service regulator vent outlet – 3 ft (.91 m) U.S. minimum and 3 ft (.91 m) Canada minimum. \*
- J Clearance to non-mechanical air supply inlet into building or the combustion air inlet to any other appliance – 9" (23 cm) U.S. minimum and 12 in. (30 cm) Canada minimum. \*
- K Clearance to mechanical air supply inlet - 3 ft (.91 m) U.S. minimum and 6 ft (1.8 m) Canada minimum. \*
- L Clearance above a paved sidewalk or paved driveway located on public property - 7 ft (2.1 m) minimum.  
A vent may not terminate directly above a sidewalk or paved driveway which is located between two single family dwellings and serves both dwellings.
- M Clearance under veranda, porch, deck or balcony - 12 in. (30 cm) minimum. \* Recommended 30 in. (76 cm) for vinyl or plastic.  
Only permitted if veranda, porch, deck or balcony is fully open on a minimum of 2 sides beneath the floor. \*
- N Vertical clearance between two horizontal termination caps – 12 in. (30 cm) minimum.
- O Horizontal clearance between two horizontal termination caps – 12 in. (30 cm) minimum.

- P 6" - Non-vinyl sidewalls  
12" – Vinyl sidewalls
- Q 18" – Non-vinyl soffit and overhang  
42" – Vinyl soffit and overhang
- R 8 ft.

	<b>S<sub>min</sub></b>	<b>T<sub>max</sub></b>
1 cap	3 ft	2 x S actual
2 caps	6 ft	1 x S actual
3 caps	9 ft	2/3 x S actual
4 caps	12 ft	1/2 x S actual
S <sub>min</sub> = # term caps x 3		T <sub>max</sub> = (2/# term caps) x S (actual)

- U 6" min. – Clearance from sides of electrical service.
- W 12" min. – Clearance above electrical service.
- \* As specified in CGA B149 Installation Codes  
Note: Local codes or regulations may require different clearances.
- \*\* Clearance required to vinyl soffit material – 30 in. (76 cm) minimum.  
Note: Location of the vent termination must not interfere with access to the electrical service.

**WARNING!**

In the U.S.: Vent system termination is NOT permitted in screened porches. You must follow side wall, overhang and ground clearances as stated in the instructions.

In Canada: Vent system termination is NOT permitted in screened porches. Vent system termination is permitted in porch areas with two or more sides open. You must follow all side wall, overhang and ground clearances as stated in the instructions.

Hearth & Home Technologies assumes no responsibility for the improper performance of the appliance when the venting system does not meet these requirements.

**Figure 4.4 Minimum Clearances for Terminations**

# 5 Vent Information and Diagrams

## A. Vent Table Key

The abbreviations listed in this vent table key are used in the vent diagrams.

Symbol	Description
V <sub>1</sub>	First section (closest to appliance) of vertical length
V <sub>2</sub>	Second section of vertical length
H <sub>1</sub>	First section (closest to appliance) of horizontal length
H <sub>2</sub>	Second section of horizontal length


**WARNING**





**Fire Risk**  
**Explosion Risk**  
**Asphyxiation Risk**

Do NOT connect this gas appliance to a chimney flue serving a separate solid-fuel or gas burning appliance.

- Vent this appliance directly outside.
- Use separate vent system for this appliance.

May impair safe operation of this appliance or other appliances connected to the flue.

## B. Use of Elbows

**CAUTION**

ALL vent configuration specifications MUST be followed.

- This product is tested and listed to these specifications.
- Appliance performance will suffer if specifications are not followed.

Diagonal runs have both vertical and horizontal vent aspects when calculating the effects. Use the rise for the vertical aspect and the run for the horizontal aspect (see Figure 5.1).

Two 45° elbows may be used in place of one 90° elbow. On 45° runs, 1 ft of diagonal is equal to 8-1/2 in. horizontal run and 8-1/2 in. vertical run. A length of straight pipe is allowed between two 45° elbows (see Figure 5.1).





Figure 5.1 Using Two 45° Elbows

## C. Measuring Standards

Vertical and horizontal measurements listed in the vent diagrams were made using the following standards.

- Pipe measurements are shown using the effective length of pipe (see Figure 5.2).
- Measurements are made from the appliance outer wrap, not from the standoffs.
- Horizontal terminations are measured to the outside mounting surface (flange of termination cap) (see Figure 4.1).
- Vertical terminations are measured to top of last pipe before termination cap.
- Horizontal pipe installed level with no rise.



**DVP Pipe**  
(see chart)

Pipe	Effective Length
DVP4	4 in. (102 mm)
DVP6	6 in. (152 mm)
DVP12	12 in. (305 mm)
DVP24	24 in. (610 mm)
DVP36	36 in. (914 mm)
DVP48	48 in. (1219 mm)
DVP6A	3 to 6 in. (76 to 152 mm)
DVP12A	3 to 12 in. (76 to 305 mm)
DVP12MI	3 to 12 in. (76 to 305 mm)
DVP24MI	3 to 24 in. (76 to 610 mm)

Figure 5.2 DVP Pipe Effective Length

## D. Vent Diagrams

<b>⚠ WARNING</b>	
	<b>Fire Risk</b> <b>Explosion Risk</b>
	Do NOT pack insulation or other combustibles between firestops. <ul style="list-style-type: none"> <li>• ALWAYS maintain specified clearances around venting and firestop systems.</li> <li>• Install firestops as specified.</li> </ul> Failure to keep insulation or other material away from vent pipe may cause fire.

The first 90° elbow MUST be a starter elbow.

To replace the first starter elbow with two 45° elbows, refer to Figure 5.4. All other 90° elbows can be replaced with two 45° elbows.

General Rules:

- SUBTRACT 3 ft from the total H measurement for each 90° elbow installed horizontally.  
SUBTRACT 1-1/2 ft from the total H measurement for each 45° elbow installed horizontally.
- A maximum of three 90° elbows (or six 45° elbows) may be used in any vent configuration. Some elbows may be installed horizontally. See Figure 5.6.
- Elbows may be placed back to back anywhere in the system except as shown in Figure 5.4.
- When penetrating a combustible wall, a wall shield firestop must be installed.
- When penetrating a combustible ceiling, a ceiling firestop must be installed.

### Top Vent—Horizontal Termination—One Elbow

V <sub>1</sub> min.	V <sub>1</sub> max.	H <sub>1</sub> max.
0*	-	18 in./457 mm
6 in./152 mm	-	6 ft/1.83 m
12 in./305 mm	-	11 ft/3.35 m
18 in./457 mm	-	18 ft/5.49 m
24 in./610 mm	-	25 ft/7.62 m
-	25 ft/7.62 m	25 ft/7.62 m

\* You may install the elbow directly on top of the CD4236. The CD4842 requires the DVP6 vent section prior to the elbow.





Figure 5.3 Top Vent-Horizontal Termination-One Elbow


### Top Vent—Horizontal Termination—Two 45° Elbows

Installation requirements to replace the first 90° elbow with two 45° elbows:



### Top Vent—Horizontal Termination—Three Vertical Elbows

See Figure 5.6 for information about installing elbows horizontally.



### Top Vent—Horizontal Termination—Two or Three Elbows

You may use a maximum of three 90° elbows (or six 45° elbows) in any vent configuration, Some may be installed horizontally.

**Note: Subtract 3 ft (914 mm) from the total horizontal measurement for each 90° elbow installed horizontally. Subtract 1-1/2 ft (457 mm) from the total horizontal measurement for each 45° elbow installed horizontally.**

V <sub>1</sub> min.	V <sub>1</sub> max.	H <sub>1</sub> +H <sub>2</sub> max.	H <sub>1</sub> +H <sub>2</sub> +H <sub>3</sub> max.
6 in./152 mm	x	6 ft/1.83 m	x
12 in./305 mm	x	11 ft/3.35 m	11 ft/3.35 m
18 in./457 mm	x	18 ft/5.49 m	18 ft/5.49 m
24 in./610 mm	x	25 ft/7.62 m	25 ft/7.62 m
x	25 ft/7.62 m	25 ft/7.62 m	25 ft/7.62 m




Figure 5.6 Two or Three Elbows, some Horizontal

## Top Vent—Vertical Termination—No Elbows

**Note:** If installing a vertical vent/termination run off the top of the appliance, the vertical termination baffle supplied with the appliance may be used. See Section E.




Figure 5.7 Vertical Termination - No Elbows

## Top Vent—Vertical Termination—Two Elbows

**Note:** If installing a vertical vent/termination run off the top of the appliance, the vertical termination baffle supplied with the appliance may be used. See Section E.






Figure 5.8 Vertical Termination - Two Elbows


### Top Vent—Vertical Termination—Three Elbows




### Rear Vent—Horizontal Termination—No Elbows




**Rear Vent—Horizontal Termination—One 45° Elbow**



**Rear Vent—Horizontal Termination—Two Elbows**



## Rear Vent—Horizontal Termination—Three Elbows



## Rear Vent—Vertical Termination—One Elbow

**Note:** If installing a vertical vent/termination run off the rear of the appliance, the vertical termination baffle supplied with the appliance may be used. See Section E.




Figure 5.14 Vertical Termination - One Elbow

## Rear Vent—Vertical Termination—Two Elbows

**Note:** Subtract 3 ft (914 mm) from the total horizontal measurement for each 90° elbow installed horizontally. Subtract 1-1/2 (457 mm) ft from the total horizontal measurement for each 45° elbow installed horizontally.

12 ft (3.66 m) min.  
60 ft (18.29 m) max.


0 min.  
6 ft (1.83 m) max.

Maximum horizontal run is 100% of vertical, but cannot exceed 26 ft (7.92 m)

**Note:** If installing a vertical vent/termination run off the rear of the appliance, the vertical termination baffle supplied with the appliance may be used. See Section E.

Figure 5.15 Vertical Termination - Two Elbows

## Rear Vent—Vertical Termination—Three Vertical Elbows



## E. Installing Vertical Termination Baffle

**Note:** For vertically terminated installations only.

**Note:** If installing a vertical vent/termination run off the top or rear of the appliance, the vertical termination baffle supplied with the appliance may be used.

1. Remove the glass (refer to Section 12.H.) to access the firebox and 5 in. inner flue.
2. Fold the baffle (Figure 5.17) to an approximate 90° angle (see Figure 5.18).




Figure 5.17 Flat Baffle




Figure 5.18 Baffle Bent to 90° Angle

3. Squeeze the open end of the bent baffle with one hand. Insert the baffle bent side up into the inner flue so that the bottom of the baffle is above the bead on the inside of the collar. See Figure 5.19.




Figure 5.19 Placing the Baffle

4. Release pressure on the baffle so that it is wedged against the sides of the flue collar. See Figure 5.20.




Figure 5.20 Baffle in Place

5. Replace the glass (refer to Section 12.H.).
6. Start the appliance.

# 6 Vent Clearances and Framing

## A. Pipe Clearances to Combustibles


**WARNING**

**Fire Risk**  
**Explosion Risk**

Maintain vent clearance to combustibles as specified.



- Do not pack air space with insulation or other materials.

Failure to keep insulation or other materials away from vent pipe may cause fire.





## B. Wall Penetration Framing

- Wherever a combustible wall is penetrated, the hole must be framed with a wall shield firestop. This shield maintains minimum clearances and restricts cold air infiltration.
- If the wall being penetrated is of noncombustible materials (material which will not ignite or burn, or has a UL fire rating of zero), a 9 in. (229 mm) diameter hole is acceptable.
- Whenever a wall is penetrated the wall shield firestop is only required on one side and no heat shield is necessary.
- If your local inspector requires the wall shield firestop on both sides of the wall, then both wall shield firestops must have a heat shield attached to them.



### C. Install the Ceiling Firestop

- Frame an opening 10 in. by 10 in. whenever the vent system penetrates a ceiling/floor (see Figure 6.4).
- Frame the area with the same sized lumber as used in ceiling/floor joist.
- When installing a top vent vertical termination appliance the hole should be directly above the appliance, unless the flue is offset.
- The ceiling firestop may be installed above or below the ceiling. Refer to Figure 6.5.
- Secure with three fasteners on each side.
- Do not pack insulation around the vent. Insulation must be kept away from the pipe.



## D. Install Attic Insulation Shield


	<b>WARNING</b>
<b>Fire Risk</b>	
Keep loose materials or blown insulation from touching the vent pipe.	
<ul style="list-style-type: none"><li>• National building codes recommend using attic shield to keep loose materials/blown insulation from contacting vent.</li><li>• Hearth &amp; Home Technologies requires the use of an attic shield.</li></ul>	

### Flat Ceiling Installation

- Remove one shield from box.  
**Note:** Cut previously installed batt insulation to make room for the attic insulation shield.
- Wrap shield around pipe if pipe is already installed in area to be insulated.
- Match the three holes in each side and fasten with three screws to form a tube.
- ➔ • Bend four tabs inward on bottom of shield where it rests on the ceiling firestop to maintain the air space between the pipe and shield. Set the shield on the ceiling firestop.
- Bend all tabs inward 90° around the top of the shield. These tabs must be used to prevent blow-in insulation from getting between the shield and vent pipe, and to maintain clearance.

### Vaulted Ceiling Installation

- The attic insulation shield has been laser-etched with cut lines and ceiling pitches to make field trimming easier.
- Remove one shield from box.  
**Note:** Cut previously installed batt insulation to make room for the attic insulation shield.
- Cut the attic insulation shield (if application is for vaulted ceiling) using a laser-etched cut line, to fit your ceiling pitch. Snip cut edge to create three bend tabs.
- Wrap shield around pipe if pipe is already installed in area to be insulated.
- Match the three holes in each side and fasten with three screws to form a tube.
- Bend four of the remaining tabs inward 90° on bottom of shield to maintain the air space between the pipe and shield. Cover the resulting holes with aluminum tape. Set the shield on the ceiling firestop.
- Bend all tabs inward 90° around the top of the shield. These tabs must be used to prevent blow-in insulation from getting between the shield and vent pipe, and to maintain clearance.



# 7 Appliance Preparation

## CAUTION



Sharp Edges

- Wear protective gloves and safety glasses during installation.



- Remove three remaining screws holding the plate surrounding flue. See Figure 7.3. Remove plate and set aside.




Figure 7.3 Cover Plate, Remove Screws

### A. Convert from Top Vent to Rear Vent

- Remove the screw holding heat shield cover plate to top of appliance and set aside. See Figure 7.1

**Note:** If the appliance is to be top vented discard this plate and replace the screw you removed. If the appliance is to be rear vented, continue to the next step and Figure 7.2.




Figure 7.1 Cover Plate, Top of Appliance

- Remove the white insulation and set aside. See Figure 7.2.




Figure 7.2 Remove White Insulation

- Remove four screws holding inner plate surrounding the flue. See Figure 7.4. Remove inner plate and discard.






Figure 7.4 Inner Plate, Top of Appliance

- Remove four screws holding outer collar to appliance top. See Figure 7.5. Remove outer collar.




**Figure 7.5 Outer Collar, Remove Four Screws**

- Remove four screws holding inner collar to appliance top. See Figure 7.6. Remove inner collar.




**Figure 7.6 Remove Four Inner Collar Screws**

- Remove four screws holding outer shell cover. See Figure 7.7. Remove outer shell cover and set aside.




**Figure 7.7 Outer Shell Cover**

- Remove four screws holding outer cover plate to appliance back. See Figure 7.8. Remove outer cover.




**Figure 7.8 Outer Cover, Rear - Remove Plate**

- Remove four screws holding inner cover plate to appliance back. See Figure 7.9. Remove inner cover.



**Figure 7.9 Remove Inner Cover Plate**

- Place inner collar on appliance back and replace four screws to hold this collar in place. See Figure 7.10. Make sure insulation is attached to the collar base!




**Figure 7.10 Place inner collar on Rear of Appliance**

- Place outer collar on rear of appliance and replace four screws to hold collar in place. See Figure 7.11. Make sure insulation is attached to the collar base!




**Figure 7.11 Place Outer Collar on Rear of Appliance**

- Place inner cover plate on appliance top and replace four screws to hold inner cover plate in place. See Figure 7.14. Make sure gasket is replaced with the cover plate!



**Figure 7.14 Inner Cover-Top**

- Locate the cover plate removed in the second step. Place plate around rear vented collars and replace four screws to hold plate in place. See Figure 7.12.



**Figure 7.12 Cover Plate Placed on Rear of Appliance**

- Place outer cover plate on appliance top and replace four screws to hold outer cover plate in place. See Figure 7.15. Make sure insulation is replaced with cover plate!




**Figure 7.15 Outer Cover-Top**

- Place the white insulation with the slot around the outer collar. See Figure 7.13.




**Figure 7.13 Place Insulation over the Cover Plate**

- Locate heat shield cover plate removed in the first step. Place the heat shield cover plate on top of heat shield. Replace four screws to hold this plate in place. See Figure 7.16.




**Figure 7.16 Cover Plate-Replace**



**Figure 7.18 Screw Cover into Place**

- Locate outer shell cover removed in the sixth step (Figure 7.7). Place the cover on top of appliance. See Figure 7.17. Replace four screws to hold plate in place. See Figure 7.18.



**Figure 7.17 Place Cover Plate on Top of Appliance**

- The appliance should look like the one shown in Figure 7.19 after it has been converted to a rear vent appliance.



**Figure 7.19 Completed Conversion**

## B. Securing and Leveling the Appliance



### ⚠ WARNING

#### Fire Risk!

- Prevent contact with sagging, loose insulation.
- Do NOT install against combustible materials such as exposed insulation, plastic and insulation backer.

The diagram shows how to properly position, level, and secure the appliance (see Figure 7.20). Nailing tabs are provided to secure the appliance to the framing members.

- Rear venting - refer to Vent Clearances and Framing (Section 6) for hole location.
- Place the appliance into position.
- Level the appliance from side to side and front to back.
- Shim the appliance as necessary. It is acceptable to use wood shims.
- Bend out nailing tabs on each side.
- Keep nailing tabs flush with the framing.
- Secure the appliance to the framing by using nails or screws through the nailing tabs.

### CAUTION

Do NOT notch into the framing around the appliance spacers.



### ⚠ WARNING

#### Fire Risk!

- ALWAYS maintain specified clearances around the appliance.
- Do NOT notch into the framing around the appliance spacers.

Failure to keep insulation, framing or other material away from the appliance may cause fire.




Figure 7.20 Proper Positioning, Leveling and Securing of an Appliance

# 8 Installing Vent Pipe

## A. Assemble Vent Sections

	<b>⚠ WARNING</b>	
<b>Fire Risk Explosion Risk.</b>		
Do not mix pipe, fittings or joining methods from different manufacturers		

	<b>⚠ WARNING</b>	
<b>Fire Risk Exhaust Fumes Risk</b>		
	<ul style="list-style-type: none"><li>• Overlap pipe slip sections at least 1-1/2 in.</li><li>• Use pilot holes for screws.</li><li>• Screws must not exceed 1 in. long.</li><li>• Pipe may separate if not properly joined.</li></ul>	

	<b>⚠ WARNING</b>	
<b>Fire Risk Explosion Risk</b>		
	If slip section seals are broken during the removal of the termination cap, gas will leak and a fire or explosion may occur.	
do not break silicone seals on slip sections.		

## Attaching Vent to the Firebox Assembly

To attach the first pipe section to the collars, slide the male end of the inner vent of the pipe section over the inner collar on the firebox assembly. At the same time, slide the outer flue over the outer collar on the appliance. Push the pipe section into the appliance collar until all the lances (see Figure 8.1) have snapped in place. Tug slightly on the section to confirm it has completely locked into place.

## Commercial, Multi-family (multi-level exceeding two stories), or High-rise Applications

For installation into a commercial, multi-family (multi-level exceeding two stories), or high-rise application: All outer pipe joints must be sealed with high temperature silicone, including the slip section that connects directly to the horizontal termination cap.

- Apply a bead of silicone sealant inside the female outer pipe joint prior to joining sections. See Figure 8.1.
- Only outer pipes are to be sealed, do not seal the inner flue. All unit collar, pipe, slip section, elbow and cap outer flues shall be sealed in this manner, unless otherwise stated.

**Note:** The end of the pipe sections with the lances/tabs on it will face towards the appliance.





## Assemble Pipe Sections

Insert the inner flue of section A into the flared inner flue of section B.

Start the outer flue of section A over the outer flue of section B (see Figure 8.2).

Once both inner and outer flues are started, press section A onto section B firmly until all lances have snapped into place. Check to make sure they have snapped together (see Figure 8.3) and the seams are not aligned (see Figure 8.4). Tug slightly on section A to confirm it has completely locked into place. It is acceptable to use screws no longer than 1 in. (25 mm) to hold outer pipe sections together. If predrilling holes, do NOT penetrate inner pipe

For 90° and 45° elbows that are changing the vent direction from horizontal to vertical, one screw minimum should be put in the outer flue at the horizontal elbow joint to prevent the elbow from rotating. Use screws no longer than 1 in. (25 mm). If predrilling holes, do NOT penetrate inner pipe.



## Assemble Minimum Installation (MI) Sections

MI sections are non-unitized so that they can be cut to a certain length. Cut these sections to length from the non-expanded end (see Figure 8.5).

They can then be attached by first connecting the expanded end of the MI inner flue with the inner pipe from the adjacent pipe section and securing with three screws. The expanded portion of the MI inner flue must overlap completely with the unexpanded end of the adjacent pipe section.

The outer flue can then be inserted into the adjacent outer flue expanded end and attached to the next pipe section with three screws. The other end of the MI pipe section can then be attached by fitting another pipe section to it and snapping it together, as normal.

## Assemble Slip Sections

The outer flue of the slip section should slide over the outer flue of the pipe section and into (inner flue) the last pipe section (see Figure 8.6).

Slide together to the desired length, making sure that a 1-1/2 in. outer flue overlap is maintained between the pipe section and slip section.

The pipe and slip section need to be secured by driving two screws through the overlapping portions of the outer flues using the pilot holes (see Figure 8.7).

This will secure the slip section to the desired length and prevent it from separating. The slip section can then be attached to the next pipe section.

If the slip section is too long, the inner and outer flues of the slip section can be cut to the desired length.

**Note:** When installing a vent system with an HRC termination cap, all pipe system joints shall be sealed using a high-temperature silicone sealant.

- Apply a bead of silicone sealant inside the female outer pipe joint prior to joining sections.
- Only outer pipes are sealed, sealing the inner flue is not required. All unit collar, pipe, slip section, elbow and cap outer flues shall be sealed in this manner.




Figure 8.5 MI Sections




Figure 8.6 Slip Section Pilot Holes




Figure 8.7 Screws into Slip Section

## Secure the Vent Sections

Vertical sections of pipe must be supported every 8 ft after the 25 ft maximum unsupported rise. The vent support or plumber's strap (spaced 120° apart) may be used to do this (see Figures 8.8 and 8.9).

Horizontal sections of vent must be supported every 5 ft with a vent support or plumber's strap.

## B. Disassemble Vent Sections

To disassemble any two pieces of pipe, rotate either section (see Figure 8.10), so that the seams on both pipe sections are aligned (see Figure 8.11). They can then be carefully pulled apart.




Figure 8.8 Securing Vertical Pipe Sections




Figure 8.9 Securing Horizontal Pipe Sections

	<b>WARNING</b>
	<b>Fire Risk</b> <b>Explosion Risk</b> <b>Asphyxiation Risk</b>
	Use vent run supports per installation instructions. Connect vent sections per installation instructions
	<ul style="list-style-type: none"><li>• Maintain all clearances to combustibles.</li><li>• Do NOT allow vent to sag below connection point to appliance.</li></ul>
	Improper support may allow vent to sag or separate.




Figure 8.10 Rotate Seams for Disassembly




Figure 8.11 Align and Disassemble Vent Sections

## C. Install the Heat Shield and Horizontal Termination Cap

	<b>⚠ WARNING</b>
	<b>Fire Risk</b> Impaired performance of appliance.
	<ul style="list-style-type: none"><li>• Telescoping flue section of termination cap <b>MUST</b> be used when connecting pipe section to termination cap.</li><li>• Maintain a 1-1/2 in. minimum overlap on telescoping flue section of termination cap.</li></ul>

	<b>⚠ WARNING</b>
	<b>Fire Risk</b> <b>Exhaust Fumes Risk</b> Impaired performance of appliance.
	<ul style="list-style-type: none"><li>• Overlap pipe slip sections at least 1-1/2 in.</li><li>• Use pilot holes for screws.</li><li>• Screws must not exceed 1 in. long.</li><li>• Pipe may separate if not properly joined.</li></ul>

	<b>⚠ WARNING</b>
	Do <b>NOT</b> connect a pipe section to a termination cap without using the telescoping flue section found on the termination cap.

### Heat Shield Requirements for Horizontal Termination

For all horizontally vented appliances, a heat shield **MUST** be placed 1 in. (25 mm) above the top of the vent between the wall shield firestop and the base of the termination cap.

There are two sections of the standard heat shield. One section is factory-attached to the wall shield firestop. The other section is factory-attached to the cap. See Figure 3.1.

If the wall thickness does not allow the required 1-1/2 in. (38 mm) heat shield overlap when installed, an extended heat shield must be used.

**Important Notice:** Heat shields may NOT be field constructed.

The extended heat shield may need to be cut to length. You will attach the cut heat shield to the existing cap heat shield or wall shield firestop heat shield (refer to Figure 3.1) using the supplied screws. You **MUST** maintain a 1-1/2 in. (38 mm) overlap of the extended heat shield and the existing shields (both ends of the heat shield). The small leg on the extended heat shield should rest on the top of the vent (pipe section) to properly space it from the pipe section.

## Install the Horizontal Termination Cap

Vent termination must not be recessed in the wall. Siding may be brought to the edge of the cap base.

Flash and seal as appropriate for siding material at outside edges of cap.


When installing a horizontal termination cap, follow the cap location guidelines as prescribed by current **ANSI Z223.1** and **CAN/CGA-B149** installation codes.



### ⚠ WARNING

**Burn Risk**

- Local codes may require installation of a cap shield to prevent anything or anyone from touching the hot cap.



**Cap Specification Chart (depth without using additional pipe sections)**

<b>CD-M Series</b>	<b>DVP-TRAP1 Top Vent Depth</b>	<b>DVP-TRAP1 Rear Vent Depth</b>	<b>DVP-TRAP2 Top Vent Depth</b>	<b>DVP-TRAP2 Rear Vent Depth</b>
	4-1/8 to 6 in.	3-5/8 to 5-1/2 in.	6-1/2 to 10-1/2 in.	7 to 11 in.
	<b>DVP-HPC1 Top Vent Depth</b>	<b>DVP-HPC1 Rear Vent Depth</b>	<b>DVP-HPC2 Top Vent Depth</b>	<b>DVP-HPC2 Rear Vent Depth</b>
	4-1/8 to 6-1/4 in.	3-5/8 to 5-3/4 in.	6-1/4 to 10-3/8 in.	5-3/4 to 9-7/8 in.

DVP-TRAP1 can adjust 1-7/8 in. (4-3/16 to 6-1/16)

DVP-TRAP2 can adjust 4 in. (6-9/16 to 10-9/16)

DVP-HPC1 can adjust 2-1/8 in. (4-1/4 to 6-3/8)

DVP-HPC2 can adjust 4-1/8 in. (6-3/8 to 10-1/2)


**Figure 8.12 Venting through the Wall**

**Note:** Where required, an exterior wall flashing is available. When penetrating a brick wall, a brick extension kit is available for framing the brick.

## D. Install Roof Flashing and Vertical Termination Cap

To install roof flashing see Figures 8.13 and 8.14.

For installation of vertical termination cap see minimum vent heights for various pitched roofs (Figure 8.13) .



Roof Pitch	H (Min.) Ft.	Roof Pitch	H (Min.) Ft.
Flat to 6/12	1.0*	Over 11/12 to 12/12	4.0
Over 6/12 to 7/12	1.25*	Over 12/12 to 14/12	5.0
Over 7/12 to 8/12	1.5*	Over 14/12 to 16/12	6.0
Over 8/12 to 9/12	2.0*	Over 16/12 to 18/12	7.0
Over 9/12 to 10/12	2.5	Over 18/12 to 20/12	7.5
Over 10/12 to 11/12	3.25	Over 20/12 to 21/12	8.0

\* 3 ft. minimum in snow regions

Figure 8.13 Minimum Height from Roof to Lowest Discharge Opening

Caulk the gap between the roof flashing and the outside diameter of the pipe. Caulk the perimeter of the flashing where it contacts the roof surface. See Figure 4.4.




Figure 8.14 Caulk the Gap

To attach the vertical termination cap, slide the inner collar of the cap into the inner flue of the pipe section and place the outer collar of the cap over the outer flue of the pipe section.

Secure with three screws into the outer flue. Secure the cap by driving the three self-tapping screws (supplied) through the pilot holes in the outer collar of the cap into the outer flue of the pipe (see Figure 8.14).




Figure 8.15 Secure with Screws

### ⚠ WARNING



#### Fire Risk

#### Explosion Risk

Inspect external vent cap regularly.

- Ensure no debris blocks cap.
- Combustible materials blocking cap may ignite.
- Restricted air flow affects burner operation.



## E. Assemble and Install Storm Collar

<b>CAUTION</b>	
	<b>Sharp Edges!</b> <ul style="list-style-type: none"><li>• Wear protective gloves and safety glasses during installation.</li></ul> 

Connect both halves of the storm collar with two screws (see Figure 8.16).

Wrap the storm collar around the exposed pipe section and align brackets. Insert a bolt (provided) through the brackets and tighten the nut to complete the storm collar assembly. Make sure the collar is tight against the pipe section. See Figure 8.17.

Slide the assembled storm collar down the pipe section until it rests on the roof flashing.

Caulk around the top of the storm collar (see Figure 8.15).




Figure 8.16 Assembling the Storm Collar



Figure 8.17 Assembling the Storm Collar Around the Pipe

# 9 Gas Information

## A. Fuel Conversion

Before making gas connections ensure appliance being installed is compatible with the available gas type.

Any natural or propane gas conversions necessary to meet the appliance and locality needs must be made by a qualified technician using Hearth & Home Technologies specified and approved parts.

## B. Gas Pressure

Proper input pressures are required for optimum appliance performance. Gas line sizing requirements need to be made following **NFPA51**.

 **WARNING**



**Fire Risk**  
**Explosion Risk**

High pressure will damage valve.

- Disconnect gas supply piping **BEFORE** pressure testing gas line at test pressures above 1/2 psig.
- Close the manual shutoff valve **BEFORE** pressure testing gas line at test pressures equal to or less than 1/2 psig.

 **WARNING**



**Fire Risk**  
**Explosion Risk**

Verify inlet pressures.

- High pressure may cause overfire condition.
- Low pressure may cause explosion.
- Verify minimum pressures when other household gas appliances are operating.

Install regulator upstream of valve if line pressure is greater than 1/2 psig.

Pressure requirements for appliance are shown in the table below. Minimum pressures must be met when other household gas appliances are operating.

Pressure	Natural Gas	Propane
Minimum Inlet Pressure	5.0 in. w.c.	11.0 in. w.c.
Maximum Inlet Pressure	7.0 in. w.c.	14.0 in. w.c.
Manifold Pressure	3.5 in. w.c.	10.0 in. w.c.

**Note:** Have the gas supply line installed in accordance with local building codes, if any. If not, follow **ANSI 223.1**. Installation should be done by a qualified installer approved and/or licensed as required by the locality. (In the Commonwealth of Massachusetts installation must be performed by a licensed plumber or gas fitter.)

**Note:** A listed (and Commonwealth of Massachusetts approved) 1/2 in. (13 mm) T-handle manual shut-off valve and flexible gas connector are connected to the 1/2 in. (13 mm) control valve inlet.

- If substituting for these components, please consult local codes for compliance.

## C. Gas Connection

**Note:** Gas line may be run from either side or through the bottom of appliance through the gas knockouts provided.

 **WARNING**



**Gas Leak Risk**

- Support control when attaching pipe to prevent bending gas line.

**Note:** The gap between supply piping and gas access hole may be caulked with high temperature caulk or stuffed with non-combustible, unfaced insulation to prevent cold air infiltration.

Refer to Reference Section 16 for location of gas line access in appliance.

- Ensure that gas line does not come in contact with outer wrap of appliance. Follow local codes.

 <b>WARNING</b>	
	<b>Fire Risk</b>
	<b>Explosion Risk</b>
	<ul style="list-style-type: none"> <li>• Gas build-up during line purge may ignite.</li> <li>• Purge should be performed by qualified technician.</li> <li>• Ensure adequate ventilation.</li> <li>• Ensure there are no ignition sources such as sparks or open flames.</li> </ul>

- Incoming gas line should be piped into the valve compartment and connected to the 1/2 in. connection on the manual shutoff valve.
- A small amount of air will be in the gas supply lines. When first lighting appliance it will take a short time for air to purge from lines. When purging is complete the appliance will light and operate normally.

 <b>WARNING</b>	
	<b>CHECK FOR GAS LEAKS</b>
	<b>Fire Risk</b>
	<b>Explosion Risk</b>
	<b>Asphyxiation Risk</b>
	<ul style="list-style-type: none"> <li>• Check all fittings and connections.</li> <li>• Do not use open flame.</li> <li>• After the gas line installation is complete, all connections must be tightened and checked for leaks with a commercially available, non-corrosive leak check solution. Be sure to rinse off all leak check solution following testing.</li> </ul> <p>Fittings and connections may have loosened during shipping and handling.</p>

 <b>WARNING</b>	
	<b>Fire Risk</b>
	Do NOT change the valve settings.
	<ul style="list-style-type: none"> <li>• This valve has been preset at the factory.</li> <li>• Changing valve settings may result in fire hazard or bodily injury.</li> </ul>

## D. High Altitude Installations

U.L. listed gas appliances are tested and approved without requiring changes for elevations from 0 to 2000 ft in the USA and Canada.

When installing this appliance at an elevation above 2000 ft, it may be necessary to decrease the input rating by changing the existing burner orifice to a smaller size. Input rate should be reduced by 4% for each 1000 ft above a 2000 ft elevation in the U.S.A., or 10% for elevations between 2000 and 4500 ft in Canada. If the heating value of the gas has been reduced, these rules do not apply. To identify the proper orifice size, check with the local gas utility.

If installing this appliance at an elevation above 4500 ft (in Canada), check with local authorities.

# 10 Electrical Information

## A. Recommendation for Wire

This appliance requires 110-120 VAC to be wired to the junction box either for use of optional accessories (standing pilot ignition) or for proper operation of the appliance (Intellifire ignition). Refer to Figure 10.1 to determine if the appliance uses an Intellifire ignition system or standing pilot ignition system.

Open the control access panel to view wiring system and gas valve. If this appliance has a red or black ignitor button (as noted in Figure 10.1) this appliance has a standing pilot ignition system. If there is no red or black ignitor button, this appliance has an Intellifire ignition system.




Figure 10.1 Ignitor Button

**Note:** This appliance must be electrically wired and grounded in accordance with local codes or, in the absence of local codes, with **National Electric Code ANSI/NFPA 70-latest edition** or the **Canadian Electric Code CSA C22.1**.

- This appliance may be used with a wall switch, wall mounted thermostat and/or a remote control.
- If using thermostat use one compatible with a millivolt gas valve system.
- Follow parameters for locating thermostat (see individual thermostat instructions) to ensure proper operation of appliance.
- Use low resistance thermostat wire for wiring from ignition system to the wall switch and thermostat.
- Keep wire lengths short as possible by removing any excess wire length.
- Low voltage and 110 VAC voltage cannot be shared within the same wall box.

## C. Intellifire Ignition System Wiring

This appliance requires a 110 VAC supply to the appliance junction box for operation. A wiring diagram is shown in Figure 10.2.

This appliance is equipped with an Intellifire control valve which operates on a 3 volt system.

This appliance is supplied with a battery pack and a 3 volt AC transformer, which requires the installation of the supplied junction box. It is highly recommended that the junction box be wired at this time to avoid reconstruction.

The battery pack requires two D cell batteries (not included). Batteries cannot be placed in the battery pack while using the 3 volt AC transformer. Conversely, the transformer must be unplugged if the battery pack is used.

### CAUTION

Battery polarity must be correct or module damage will occur.

## B. Connecting to the Appliance

	<b>WARNING</b>
	<b>Shock Risk</b> <b>Explosion Risk</b> Do NOT wire 110V to valve. Do NOT wire 110V to wall switch
	<ul style="list-style-type: none"><li>• Incorrect wiring will damage millivolt values.</li><li>• Incorrect wiring will override IPI safety lockout and may cause explosion.</li></ul>

## Optional Accessories Requirements

Wiring for optional accessories should be done now to avoid reconstruction.



## E. Junction Box Installation

If the box is being wired from the **OUTSIDE** of the appliance:

- Remove the cover plate located on the outer shell - right side (see Figure 10.4).
- Install the supplied Romex™ connector in the cover plate.
- Feed the necessary length of wire through the connector.
- Make all necessary wire connections and reattach the cover plate to the outer shell.

If the box is being wired from the **INSIDE** of the appliance:

- Remove the screw attaching the junction box/receptacle to the outer shell, rotate the junction box inward to disengage it from the outer shell (see Figure 10.4).
- Pull the electrical wires from outside the appliance through this opening into the valve compartment.
- Feed the necessary length of wire through the connector.
- Make all necessary wire connections to the junction box/receptacle and reassemble the junction box/receptacle to the outer shell.




Figure 10.4 Junction Box Detail

## F. Wall Switch Installation for Fan (Optional)

If the box is being wired to a wall mounted switch for use with a fan (See Figure 10.5):

- The power supply for the appliance must be brought into a switch box.
- The power can then be supplied from the switch box to the appliance using a minimum of 14-3 with ground wire.
- At the switch box connect the black (hot) wire and red (switch leg) wire to the wall switch as shown.
- At the appliance connect the black (hot), white (neutral) and green (ground) wires to the junction box as shown.
- Add a 1/4 in. insulated female connector to the red (switch leg) wire, route it through the knockout in the face of the junction box, and connect to the top fan switch connector (1/4 in. male) as shown.






Figure 10.5 Junction Box Wired to Wall Switch or BC10

# 11 Finishing

## A. Mantel Projections

Figure 11.1 shows the minimum vertical and corresponding maximum horizontal dimensions of appliance mantels or other combustible projections above the top front edge of the appliance.



**⚠ WARNING**

**Fire Risk**

**Explosion Risk**

- Facing and/or finishing materials must never overhang into the glass opening.
- Overhanging materials may ignite.
- May interfere with proper operation of glass assembly.

## B. Facing Material

**⚠ WARNING**


**Fire Risk**

Do NOT obstruct air inlet or outlet grilles.  
Do NOT modify grilles.

- Modifying or covering grilles could cause temperature rise and fire hazard.

Finishing materials must not interfere with:

- Air flow through grilles or louvers.
- Operation of louvers or doors.
- Access for service.



**⚠ WARNING**

**Fire Risk**

Finish all edges and fronts to clearances and specifications listed in manual.

- Black metal appliance front may be covered with non-combustible material only.
- Do NOT overlap combustible materials onto appliance front.
- Install combustible materials only up to specified clearances on top, front and sides.
- Seal joints between the finished wall and appliance top and sides using only a 300° F minimum sealant.

# 12 Appliance Setup

## A. Remove Clean Face Components

## B. Remove Glass Assembly

See Section 12.1.

## C. Remove the Shipping Materials

Remove shipping materials from inside or underneath the firebox.

## D. Clean the Appliance

Clean/vacuum any sawdust that may have accumulated inside the firebox or underneath in the control cavity.

## E. Accessories

Install approved accessories per instructions included with accessories. Refer to Section 16.


	<b>⚠ WARNING</b>
	<b>Shock Risk</b> <b>Fire Risk</b> Use ONLY optional accessories approved for this appliance. <ul style="list-style-type: none"><li>• Using non-listed accessories voids warranty.</li><li>• Using non-listed accessories may result in a safety hazard.</li><li>• Only Hearth &amp; Home Technologies approved accessories may be used safely.</li></ul>

## F. Install the Refractory

A weathered brick refractory is available as an optional accessory. Install the WTBC36D in the CD4236 Series appliances and the WTBC42D in the CD4842 Series appliances. Follow the installation instructions provided with the specific accessory part.



	<b>⚠ WARNING</b>
	<b>Explosion Risk</b> <ul style="list-style-type: none"><li>• Follow rockwool placement instructions in this manual.</li><li>• Do NOT place rockwool directly over burner ports.</li><li>• Replace rockwool material annually.</li></ul> Improperly placed rockwool interferes with proper burner operation.

## G. Lava Rock, Vermiculite, Rockwool Placement



Place the lava rock and vermiculite.

- See Figures 12.1 - 12.3.
- It is not necessary to use the entire bag. Save the remaining amount for future use.



Place the rockwool.

- See Figures 12.1 and 12.4.
- Place a small amount of 1/2 in. diameter pieces (dime-size) of rockwool on the burner pan so that rockwool touches but does not cover the holes in the burner pan.
- It is not necessary to use the entire bag. Save the remaining amount for future use.



Figure 12.4 Placement of Rockwool

## H. Log Assembly

- Base logs have been permanently mounted on the grate assembly and should not be moved. See Figure 12.5.



Figure 12.5 Base Logs

- Install "Y" log on left hand side of grate using locating pins to position. See Figure 12.6



Figure 12.6 Placing Left Top Log

- Install right top log as shown in Figure 12.7 using locating pins to position log properly.



Figure 12.7 Placing Right Top Log

## I. Glass Assembly



### ⚠ WARNING

Handle glass doors with care.

- Inspect the gasket to ensure it is undamaged.
- Inspect the glass for cracks, chips or scratches.
- Do NOT strike, slam or scratch glass.
- Do NOT operate appliance with glass door removed, cracked, broken or scratched.
- Replace glass door assembly as a complete assembly.


### • Removing Glass Assembly

Lift and pull the upper latch cover towards you to expose the two (36 in. model) or three (42 in. model) Quick Access Latches. Lift and pull lower latch cover to expose the two (36 in. model) or three (42 in. model) Quick Access Latches. Rotate the bottom of the screen assembly away from the appliance and lower out of the top retainers. Release the top and bottom access latches and rotate the top of the glass assembly away from the top of the appliance. Place the glass assembly on a surface that will not scratch the surface of the glass assembly.

### • Replacing Glass Assembly

Replace the glass assembly on the lower access latches and rotate the upper portion of the glass assembly into place. Engage the top access latches. Engage the lower access latches.

- Reinstall upper latch cover (see Figure 12.12).
- Reinstall lower latch cover (see Figure 12.14).
- Reinstall mesh firescreen (see Figure 12.15).




## J. Install Trim

- Install optional marble and brass trim surround kits using the installation instructions included with them.
- Marble, brass, brick, tile or other non-combustible materials can be used to cover gap between sheet rock and appliance.
- Do not obstruct or modify the air inlet/outlet latch covers.
- Allow space to lower and remove the bottom latch cover.


## K. Install Clean Face Components

Carefully remove components from skin pack. See Figure 12.9 for identification of components.



## Install Hood

- Bend screen rod tabs down at a 90-deg. angle. See Figure 12.10.



- Install above the glass panel.
- Hood must be attached or a fire hazard may result.
- Locate the four screws (for 4236) or five screws (for 4842) just inside the upper section of the appliance.
- Loosen the screws, but do NOT remove.
- Position hood and slide notches over screw heads, ensuring hood also slips into the clips.
- Tighten the screws to hold hood firmly in place.
- See Figure 12.11.




Figure 12.11 Installing the Hood

### Install Top Latch Cover

- Insert top latch cover over existing shoulder screws. See Figure 12.12.
- Push down until the tabs lock in place.




Figure 12.12 Installing Top Latch Cover

### Install Floor Cover

- Install floor cover. See Figure 12.13. Floor cover must be installed with brake flange UP and going towards components with notched end to the left of the unit. Do not place cover on top of any components. Move components back if necessary.
- When using the RCTS-MLT-HTL Remote for SIT Valve, the hand tab bend must be bent down for clearance of the solenoid.



Figure 12.13 Installing Floor Cover

### Install Bottom Latch Cover

- Insert bottom latch cover over existing shoulder screws. See Figure 12.14.
- Push down till the tabs lock in place.




Figure 12.14 Installing Bottom Latch Cover

## Install Firescreen Assembly

- Thread screen onto screen rod making sure to thread all screen rings.
- Hold the mesh firescreen in one hand until you get the rod inserted into the side columns to prevent the mesh from falling off the rod.
- Insert one end of screen rod into the hole located in the column as far as it will go. See Figure 12.15




Figure 12.15 Insert Rod Into Side Columns

- Flex the rod and insert it into the hole in the column on the other side.
- Hook the center of the rod into the screen rod tabs (shown in Figure 12.10).
- Spread firescreen to the edges of the firebox opening.
- Hairpin clips are shipped in place in a hole in the bottom of each column. After the screen is in place, squeeze clips and remove from holes. Thread clip through screen (one on each side), squeeze slip and re-insert into holes.

**Note:** The floor cover in the bottom front of the fireplace may be covering the UL labels. It is loose and can be removed/replaced.

## L. Air Shutter Setting

This appliance has an adjustable air shutter (which controls the primary air mixture) that can be accessed from under the valve compartment located under the firebox assembly (see Figure 12.16). If your installation has more than the minimum vertical vent length, adjustments to the air shutter may be required to obtain the optimal flame appearance. **A qualified installer should adjust this at the time of installation.**

It takes 16 full turns of the shutter adjustment handle to move the air shutter from fully open to fully closed. In the event of soot accumulation inside your appliance, the air shutter should be opened further. When the shutter adjustment handle is all the way **down**, the air shutter is in the **closed** position. When the shutter adjustment handle is all the way **up**, the air shutter is in the fully **open** position.




Figure 12.16 Air Shutter

# 13 Operating Instructions

## A. Before Lighting Appliance

Before lighting this appliance, determine if it has a standing pilot or Intellifire ignition system by opening the control access panel to view wiring system and gas valve. If this appliance has a red or black ignitor button (See Figure 10.1) this appliance has a standing pilot ignition system. If there is no red or black ignitor button, this appliance has an Intellifire ignition system.

### CAUTION

If installing Intellifire Ignition battery backup:

- Do not install batteries if the backup mode may not be used for extended time.
- Batteries may leak.
- Install batteries only when needed for power outage.

**Before operating this appliance, have a qualified technician:**

- Verify all shipping materials have been removed from inside and/or underneath the firebox.
- Review proper placement of logs, rockwool, lava rock and vermiculite.
- Check the wiring.
- Check the air shutter adjustment.
- Ensure that there are no gas leaks.
- Ensure that the glass is sealed and in the proper position.
- Ensure that the flow of combustion and ventilation air is not obstructed (front grilles and vent caps).



### WARNING

#### Fire Risk Asphyxiation Risk

Glass door **MUST** be in place when appliance is operating. Do NOT operate appliance with glass door removed.

- Open viewing glass for servicing only.
- Glass door **MUST** be in place and sealed before operating appliance.
- Only use glass doors certified for use with the appliance.
- Glass replacement should be done by qualified technician.



### WARNING



#### HOT SURFACES!

Glass and other surfaces are hot during operation and cool down.

#### Hot glass will cause burns.

- Do not touch glass until it is cooled
  - NEVER allow children to touch glass
  - Keep children away
- CAREFULLY SUPERVISE children in same room as appliance.
  - Alert children and adults to hazards of high temperatures.
- High temperatures may ignite clothing or other flammable materials.**
- Keep clothing, furniture, draperies and other combustibles away.

***This appliance has been supplied with an integral barrier to prevent direct contact with the fixed glass panel. Do NOT operate the appliance with the barrier removed.***

Contact your dealer or Hearth & Home Technologies if the barrier is not present or help is needed to properly install one.

### WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

### WARNING

Do NOT use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

## B. Lighting the Appliance Intellifire Ignition

<h1>FOR YOUR SAFETY READ BEFORE LIGHTING</h1>	<p><b>WARNING:</b> If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.</p>	<p>A. This appliance is equipped with an ignition device which automatically lights the pilot. Do not try to light the pilot by hand.</p> <p>B. <b>BEFORE LIGHTING</b> smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.</p> <p><b>WHAT TO DO IF YOU SMELL GAS</b></p> <ul style="list-style-type: none"> <li>Do not try to light any appliance.</li> <li>Do not touch any electric switch; do not use any phone in your building.</li> <li>Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.</li> </ul>	<p>This appliance needs fresh air for safe operation and must be installed so there are provisions for adequate combustion and ventilation air.</p>
<p>This appliance must be installed in accordance with local codes, if any; if not, follow ANSI Z223.1 or, in Canada, current CAN/CGA-B149.</p>	<p>This appliance must be properly connected to a venting system in accordance with the manufacturer's installation instructions.</p>	<p><b>WARNING:</b> Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with the appliance. For assistance or additional information consult a qualified installer, service agency or the gas supplier.</p>	<p><b>CAUTION:</b> Hot while in operation. Do not touch. Keep children, clothing, furniture, gasoline and other liquids having flammable vapors away.</p>
<h1>LIGHTING INSTRUCTIONS</h1> <ol style="list-style-type: none"> <li><b>STOP!</b> Read the safety information above on this label.</li> <li>Turn wall switch to the "OFF" position or thermostat to the lowest setting.</li> <li>Turn off all electric power to the appliance.</li> <li>This appliance is equipped with an ignition device which automatically lights the pilot. Do NOT try to light the pilot by hand.</li> <li>Wait five minutes to clear out any gas. If you then smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.</li> <li>To turn on the burner, turn on all electric power to this appliance and turn on the wall switch or set the thermostat to the desired setting. If the appliance will not operate, follow the instructions "TO TURN OFF GAS TO APPLIANCE" and call your service technician or gas supplier.</li> </ol>	<p><b>WARNING RISK OF FIRE</b> This appliance is intended to burn a specified gas fuel only. Do not attempt to use with solid wood fuel or another type of fuel. Do not attempt to modify or use any other type of gas burner system.</p>	<p><b>WARNING:</b> Disconnect the electric power before servicing. If for any reason the original wire supplied with the appliance must be replaced, it must be replaced with 105° C or its equivalent.</p> <p>For use with natural gas or propane. A conversion kit as supplied by the manufacturer shall be used to convert this appliance to the alternative fuel.</p>	<p>* Also certified for installation in a bedroom or a bed-sitting room. * For U.S. only!</p>
<h1>TO TURN OFF GAS TO APPLIANCE</h1> <ol style="list-style-type: none"> <li>Turn off wall switch or set thermostat to lowest setting.</li> <li>Turn off all electric power to the appliance if service is to be performed.</li> <li>Push the gas control lever in and move to the "OFF" position or push the gas control lever to the "OFF" position. Do not force.</li> <li>Replace the control access panel.</li> </ol>	<p><b>NATURAL GAS</b></p>	<p>* Also certified for installation in a bedroom or a bed-sitting room. * For U.S. only!</p>	<p>Due to high surface temperatures, keep children, clothing and furniture away. Keep burner and control compartment clean. See installation and operating instructions accompanying the appliance.</p>

# FOR YOUR SAFETY READ BEFORE LIGHTING

**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.


- A. This appliance has a pilot which must be lighted by hand. When lighting the pilot, follow these instructions exactly.
    - If you cannot reach your gas supplier, call the fire department.
  - B. **BEFORE LIGHTING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
    - C. Use only your hand to push in or turn knob. Never use tools. If the manual gas valve will not push in or turn by hand, don't try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.
    - D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- WHAT TO DO IF YOU SMELL GAS**
- Do not try to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.

## LIGHTING INSTRUCTIONS

Stop! Read the safety information above on this label.

1. Turn wall switch to the "OFF" position or thermostat to the lowest setting.
2. Remove control access panel.
3. Turn manual gas valve to CLOSED. Wait five [5] minutes to clear out any gas. If you then smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to next step.
4. Turn gas line to "OPEN".
5. Turn pilot knob clockwise to "OFF". (Knob may have to be depressed to pass "PILOT" position.)
6. Locate pilot assembly inside appliance.
7. Locate red ignitor button.
8. Turn pilot knob to "PILOT" and push in.
9. Continue to hold in pilot knob and push the red ignitor button 12-15 times until small blue pilot flame appears.
10. Continue to hold in pilot knob for approximately one minute. Pilot should remain lit. If pilot goes out, wait 5 minutes and repeat Steps 3-9.
11. Release and turn knob counterclockwise to "ON".
12. If appliance will not operate, follow the instructions "TO TURN OFF GAS TO APPLIANCE" and call your service technician or gas supplier.

**NOTE:** To light main burner, turn wall switch to "ON". Do not light by hand.



## TO TURN OFF GAS TO APPLIANCE

1. Turn off wall switch or set thermostat to lowest setting.
2. Remove control access panel.
3. Turn manual gas valve to "CLOSED" position. Do not force.
4. Replace control access panel.

Due to high surface temperatures, keep children, clothing and furniture away. Keep burner and control compartment clean. See installation and operating instructions accompanying the appliance.

29097D

This appliance needs fresh air for safe operation and must be installed so there are provisions for adequate combustion and ventilation air.

This appliance must be installed in accordance with local codes, if any, if not, follow ANSI Z223.1 or, in Canada, current CAN/CGA-B149.

This appliance must be properly connected to a venting system in accordance with the manufacturer's installation instructions.

**WARNING:** Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with the appliance. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

**CAUTION:** Hot while in operation. Do not touch. Keep children, clothing, furniture, gasoline and other liquids having flammable vapors away.

**WARNING RISK OF FIRE**  
This appliance is intended to burn a specified gas fuel only. Do not attempt to use with solid wood fuel or another type of fuel. Do not attempt to modify or use any other type of gas burner system.

**WARNING:** Disconnect the electric power before servicing. If for any reason the original wire supplied with the appliance must be replaced, it must be replaced with 105° C or its equivalent.

For use with natural gas or propane. A conversion kit as supplied by the manufacturer shall be used to convert this appliance to the alternative fuel.

\* Also certified for installation in a bedroom or a bed-sitting room.  
\* For U.S. only!

**NATURAL GAS**

## C. After the Appliance is Lit

### Initial Break-in Procedure

When you light the appliance, you may notice that it produces heat which does have an associated odor or smell. If you feel this odor is excessive it may require the initial three to four hour continuous burn on high followed by a second burn up to 12 hours to fully drive off any odor from paint and lubricants used in the manufacturing process. Condensation of the glass is normal

**Note:** This appliance should be run three to four hours on the initial start-up. Turn it off and let it cool completely. Remove and clean the glass. Replace the glass and run the appliance for an additional 12 hours. This will help cure the products used in the paint and logs.

During this break-in period it is recommended that some windows in the house be opened for air circulation. This will help avoid setting off smoke detectors, and help eliminate any odors associated with the appliance's initial burning.





### WARNING

**Fire Risk**  
**High Temperatures**  
 Keep combustible household items away from appliance.  
 Do NOT obstruct combustion and ventilation air.

- Do NOT place combustible items on top of or in front of appliance.
- Keep furniture, draperies away from appliance.

### CAUTION

- Prevent accidental appliance operation when not attended.
- Unplug or remove batteries from remote control if absent or if appliance will not be used for an extended period of time.
- Property damage possible from elevated temperatures.

### CAUTION

Smoke and odors are released during initial operation.

- Open windows for air circulation.
- Leave room during initial operation.
- Smoke may set off smoke detectors.

Smoke and odors may be irritating to sensitive individuals.





### WARNING

**Fire Risk**  
 Keep combustible materials, gasoline and other flammable vapors and liquids clear of appliance.

- Do NOT store flammable materials in the vicinity of the appliance.
- Do NOT use gasoline, lantern fuel, kerosene, charcoal lighter fluid or similar liquids in this appliance.

Combustible materials may ignite.

## D. Frequently Asked Questions

Issue	Solutions
1. Condensation on the glass.	1. This is a result of gas combustion and temperature variations. As the appliance warms, this condensation should disappear.
2. Blue flames.	2. This is a result of normal operation and the flames will begin to yellow as the appliance is allowed to burn for 20-40 minutes.
3. Odor from appliance.	3. When first operated, this appliance may release an odor for the first several hours. This is caused by the curing of the paint and the burning off any oils remaining from manufacturing.
4. Film on the glass.	4. This is a normal result of the curing process of the paint and logs. Glass should be cleaned within 3-4 hours of initial burning to remove deposits left by oils from the manufacturing process. A non-abrasive cleaner such as a gas fireplace glass cleaner may be necessary. See your dealer.
5. Metallic noise.	5. Noise is caused by metal expanding and contracting as it heats up and cools down, similar to the sound produced by a furnace or heating duct. This noise does not affect the operation or longevity of the appliance.
6. Is it normal to see the pilot flame burn continually?	6. In an Intellifire ignition system it is normal to see the pilot flame, but it should turn off when ON/OFF switch is turned off. In a standing pilot system the pilot will always stay on.

# 14 Troubleshooting

With proper installation, operation and maintenance your gas appliance will provide years of trouble-free service. If you do experience a problem, this troubleshooting guide will assist a qualified service person in the diagnosis of a problem and the corrective action to be taken. This troubleshooting guide can only be used by a qualified service technician.

## A. Standing Pilot Ignition System

Symptom		Possible Causes		Corrective Actions
1.	After repeated triggering of the red or black piezo ignitor button, the spark ignitor will not light the pilot.	A.	Defective ignitor.	Check the spark at the electrode and pilot. If there is no spark and the electrode wire is properly connected, replace the ignitor.
		B.	Defective pilot or misaligned electrode (spark at electrode).	Using a match, light the pilot. If the pilot lights, turn off the pilot and trigger the red or black piezo ignitor button again. If the pilot lights, an improper gas/air mixture caused the bad lighting and a longer purge period is recommended. If the pilot will not light, ensure the gap at the electrode and pilot is 1/8 in. to have a strong spark. If the gap is OK, replace the pilot.
		C.	No gas or low gas pressure.	Check the remote shut-off valves from the appliance. There is usually a valve near the gas main. There can be more than one valve between the appliance and the main.
		D.	No LP in tank.	Check the LP (propane) tank. You may be out of fuel.
2.	The pilot will not stay lit after carefully following the lighting instructions	A.	Defective thermocouple.	Check that the pilot flame impinges on the thermocouple. Clean and/or adjust the pilot for maximum flame impingement. Ensure that the thermocouple connection at the gas valve is fully inserted and tight (hand tighten plus 1/4 turn). Disconnect the thermocouple from the valve, place one millivolt meter lead wire on the tip of the thermocouple and the other meter lead wire on the thermocouple copper lead. Start the pilot and hold the valve knob in. If the millivolt reading is less than 15mV, replace the thermocouple.
		B.	Defective valve.	If the thermocouple is producing more than 15 millivolts, replace faulty valve.
3.	The pilot is burning, there is no gas burning, the valve knob is in the ON position, and the ON/OFF switch is in the ON position.	A.	ON/OFF switch or wires are defective.	Check the ON/OFF switch and wires for proper connections. Place the jumper wires across the terminals at the switch. If the burner comes on, replace the defective switch. If the switch is OK, place the jumper wires across the switch wires at the gas valve. If the burner comes on, the wires are faulty or connections are bad.
		B.	Thermopile may not be generating sufficient millivoltage.	If the pilot flame is not close enough physically to the thermopile, adjust the pilot flame. Be sure the wire connections from the thermopile at the gas valve terminals are tight and that the thermopile is fully inserted into the pilot bracket. Check the thermopile with a millivolt meter. Take the reading at TH-TP&TP terminals of the gas valve. The meter should read 325 millivolts minimum while holding the valve knob depressed in the pilot position, with the pilot lit, and the ON/OFF switch in the OFF position. Replace the faulty thermopile if the reading is below the specified minimum. With the pilot in the ON position, disconnect the thermopile leads from the valve. Take a reading at the thermopile leads. The reading should be 325 millivolts minimum. Replace the thermopile if the reading is below the minimum.
		C.	Defective valve.	Turn the valve knob to the ON position. Place the ON/OFF switch in the ON position. Check the millivolt meter at the thermopile terminals. The millivolt meter should read greater than 125mV. If the reading is acceptable, and if the burner does not come on, replace the gas valve.
		D.	Plugged burner orifice.	Check the burner orifice for stoppage. Remove stoppage.
		E.	Wall switch or wires are defective.	Follow the corrective action in Symptom and Possible Cause 1.A. above. Check the switch and wiring. Replace where defective.

(A. Standing Pilot Ignition System Troubleshooting con't)

Symptom		Possible Causes		Corrective Actions
4.	Frequent pilot outage problem.	A.	Pilot flame may be too high, too low, or blowing (high), causing pilot safety to drop out.	Clean and adjust the pilot flame for maximum flame impingement on thermocouple. Follow lighting instructions carefully.
5.	The pilot and main burner extinguish while in operation.	A.	No LP in the tank.	Check the LP (propane) tank. Refill the fuel tank.
		B.	Inner vent pipe is leaking exhaust gases back into the system.	Check venting system for damage. Replace/repair improperly assembled pipe sections.
		C.	Glass panel loose or gasket worn.	Replace glass panel assembly.
		D.	Bad thermopile or thermocouple.	Replace if necessary.
		E.	Improper vent cap installation.	Check for proper installation and freedom from debris or blockage.
6.	Glass soots.	A.	Flame impingement.	Adjust the log set so that the flame does not excessively impinge on it.
		B.	Improper air shutter setting.	Adjust the air shutter located on the control panel.
		C.	Debris around air shutter.	Inspect the opening at the base of the burner. <b>NO MATERIAL SHOULD BE PLACED IN THIS OPENING.</b>
7.	Flame burns blue and lifts off burner.	A.	Insufficient oxygen being supplied.	Ensure that the vent cap is installed properly and free of debris. Ensure that the vent system joints are tight and have no leaks. Ensure that no debris has been placed at the base of, or in the area of the air holes in the center of, the base pan beneath the burner. Ensure that the glass is tightened properly on the appliance, particularly on top corners.

## B. Intellifire Ignition System

Symptom		Possible Causes		Corrective Actions
1.	The ignitor/module makes noise, but no spark.	A.	Incorrect wiring.	Verify "S" wire (white) for sensor and "I" wire (orange) for ignitor are connected to the correct terminals on the module and the pilot assembly. Reversed wires at the module may cause the system to make a sparking noise, but the spark may not be present at pilot hood.
		B.	Loose connections or electrical shorts in the wiring.	Verify there are no loose connections or electrical shorts in wiring from module to pilot assembly. The rod closest to the pilot hood should be ignitor. Verify connections underneath pilot assembly are tight; also verify the connections are not grounding out to the metal chassis, pilot burner, pilot enclosure, mesh screen if present, or any other metal object.
		C.	Ignitor gap is too large.	Verify gap of ignitor to pilot hood. The gap should be approximately .17 in. or 1/8 in.
		D.	Faulty module.	Turn ON/OFF rocker switch or wall switch to OFF position. Remove ignitor wire "I" from module. Place ON/OFF rocker switch or wall switch in ON position. Hold ground wire about 3/16 in. away from "I" terminal on module. If there is no spark at "I" terminal, module must be replaced. If there is a spark at "I" terminal, module is fine. Inspect pilot assembly for shorted sparker wire or cracked insulator around electrode.
2.	Pilots won't light, there is no noise or spark.	A.	Transformer installed correctly.	Verify that transformer is installed and plugged into module. Check voltage of transformer under load at space connection on module with ON/OFF switch in ON position. Acceptable readings of a good transformer are between 3.2 and 2.8 volts AC.
		B.	A shorted or loose connection in wiring configuration or wiring harness.	Remove and reinstall the wiring harness that plugs into module. Verify there is a tight fit. Verify pilot assembly wiring to module. Remove and verify continuity of each wire in wiring harness.
		C.	Improper wall switch wiring.	Verify wall switch is wired correctly.
		D.	Module not grounded.	Verify black ground wire from module wire harness is grounded to metal chassis of appliance.
		E.	Faulty module.	Turn ON/OFF rocker switch or wall switch to OFF position. Remove ignitor wire "I" from module. Place ON/OFF rocker switch or wall switch in ON position. Hold ground wire about 3/16 in. away from "I" terminal on module. If there is no spark at "I" terminal module must be replaced. If there is a spark at "I" terminal, module is fine. Inspect pilot assembly for shorted sparker wire or cracked insulator around electrode.
3.	Pilot lights but continues to spark, and main burner will not ignite. (If the pilot continues to spark after the pilot flame has been lit, flame rectification has not occurred.)	A.	A shorted or loose connection in sensor rod.	Verify all connections to wiring diagram in manual. Verify connections underneath pilot assembly are tight. Verify connections are not grounding out to metal chassis, pilot burner, pilot enclosure or screen if present, or any other metal object.
		B.	Poor flame rectification or contaminated sensor rod.	Verify flame is engulfing sensor rod. If the pilot assembly does not have a ground strap, consider installing one to increase flame rectification. Verify correct pilot orifice is installed and inlet gas specifications are met. Flame carries rectification current, not the gas. If flame lifts from pilot hood, the circuit is broken. A wrong orifice or too high an inlet pressure can cause pilot flame to lift. The sensor rod may be contaminated. Clean sensor rod with emery cloth.
		C.	Module is not grounded.	Verify that module is securely grounded to metal chassis of appliance. Verify that the wire harness is firmly connected to module.
		D.	Damaged pilot assembly or dirty sensor rod.	Verify that ceramic insulator around the sensor rod is not cracked, damaged, or loose. Verify connection from sensor rod to white sensor wire. Clean sensor rod with emery cloth to remove any contaminants that may have accumulated on sensor rod. Verify continuity with a multimeter with ohms set at lowest range.
		E.	Faulty module.	Turn ON/OFF rocker switch or wall switch to OFF position. Remove ignitor wire "I" from module. Place ON/OFF rocker switch or wall switch in ON position. Hold ground wire about 3/16 in. away from "I" terminal on module. If there is no spark at "I" terminal, module must be replaced. If there is a spark at "I" terminal, module is fine. Inspect pilot assembly for shorted sparker wire or cracked insulator around electrode.

(B. Intellifire Ignition System Troubleshooting con't)

Symptom		Possible Causes		Corrective Actions
4.	Pilot sparks, but pilot will not light.	A.	Correct gas supply.	Verify that incoming gas line ball valve is "open". Verify that inlet pressure reading is within acceptable limits, inlet pressure must not exceed 14 in. w.c.
		B.	Ignitor gap is too large.	Verify that spark gap from ignitor to pilot hood is .17 in. or 1/8 in.
		C.	Module is not grounded.	Verify module is securely grounded to metal chassis of appliance.
		D.	Module voltage output/valve/pilot solenoid ohms readings.	Verify battery voltage is at least 2.7 volts. Replace batteries if voltage is below 2.7.

Mountain View Hearth Products  
manuals.stove-parts-unlimited.com

# 15 Maintaining and Servicing the Appliance

Although the frequency of appliance servicing and maintenance will depend on use and the type of installation, a qualified service technician should perform an appliance check-up at the beginning of each heating season.

## WARNING

### Risk of injury or property damage


#### Before servicing:

- Turn off gas.
- Turn off electricity to appliance.
- Disable remote control, if one is present.
- Ensure appliance is completely cooled.

#### After Servicing:

- Replace any screen or barrier that was removed.
- Reseal and reinstall any venting removed for servicing.

## CAUTION



Handle glass assembly with care.

**Note:** Clean glass after initial 3-4 hours operation. **Longer operation without cleaning glass may cause a permanent white film on glass.**

#### When cleaning glass door:

- Avoid striking, scratching or slamming doors.
  - Do NOT use abrasive cleaners.
  - Use a hard water deposit glass cleaner on white film.
  - Do NOT clean glass when it is hot.
  - Turn off appliance after 3-4 hours of operation and ALLOW TO COOL.
  - Remove and clean glass assembly.
  - Replace glass assembly and operate appliance for an additional 12 hours.
- Refer to maintenance instructions.

## WARNING



Annual inspection by qualified technician recommended.

#### Check:

- Condition of doors, surrounds and fronts.
- Condition of glass, glass assembly and glass seal.
- Obstructions of combustion and ventilation air.
- Condition of logs.
- Condition of firebox.
- Burner ignition and operation.
- Burner air shutter adjustment.
- Gas connections and fittings.
- Obstructions of termination cap.

#### Clean:

- Glass.
- Air passageways, grilles, control compartment.
- Burner, burner ports.

#### Risk of:

- Fire
- Delayed ignition or explosion
- Exposure to combustion fumes
- Odors



## WARNING



#### Fire Risk

#### Explosion Risk

Inspect external vent cap regularly.

- Ensure no debris blocks cap.
- Combustible materials blocking cap may ignite.
- Restricted air flow affects burner operation.



## Maintenance and Service Tasks:

Inspect	Maintenance Tasks
Doors, surrounds and fronts	<ol style="list-style-type: none"> <li>1. Access condition of screen and replace as necessary. <b>Recommend addition of screen if one is not present.</b></li> <li>2. Inspect for scratches, dents or other damage and repair as necessary.</li> <li>3. Verify no obstructions to airflow through the louvers.</li> <li>4. Verify proper clearance to combustible household objects is maintained.</li> </ol>
Gasket seal, glass assembly and glass	<ol style="list-style-type: none"> <li>1. Inspect gasket seal and its condition.</li> <li>2. Inspect glass panels for scratches and nicks that can lead to breakage when exposed to heat.</li> <li>3. Confirm there is no damage to glass or glass frame. Replace as necessary.</li> <li>4. Verify that latches engage properly, clip studs are not stripped, and glass attachment components are intact and operating properly. Replace as necessary.</li> <li>5. Clean glass using a nonabrasive cleaner such as Brasso®. Replace glass assembly if severely coated with silicate deposits that cannot be removed.</li> </ol>
Valve compartment and firebox top	<ol style="list-style-type: none"> <li>1. Vacuum and wipe out dust, cobwebs, debris or pet hair. Use caution when cleaning these areas. Screw tips that have penetrated the sheet metal are sharp and should be avoided.</li> <li>2. Remove any foreign objects.</li> <li>3. Verify unobstructed air circulation.</li> </ol>
Logs	<ol style="list-style-type: none"> <li>1. Inspect for broken, damaged, or missing logs. Replace as necessary.</li> <li>2. Verify correct log placement and no flame impingement causing sooting. Correct as necessary.</li> </ol>
Firebox	<ol style="list-style-type: none"> <li>1. Inspect for paint condition, warpage, corrosion or perforation. Sand and repaint as necessary.</li> <li>2. Replace appliance if firebox has been perforated.</li> </ol>
Burner ignition and operation	<ol style="list-style-type: none"> <li>1. Verify burner is properly secured and aligned with pilot or ignitor.</li> <li>2. Clean off burner top, inspect for plugged ports, corrosion or deterioration. Replace burner if necessary.</li> <li>3. Replace rockwool with new dime-sized and shaped pieces. Do not block ports or obstruct lighting paths.</li> <li>4. Check for smooth lighting and ignition carryover to all ports. Verify there is no ignition delay.</li> <li>5. Inspect for lifting or other flame problems.</li> <li>6. Verify air shutter is clear of dust and debris.</li> <li>7. Inspect orifice for soot, dirt or corrosion.</li> <li>8. Verify manifold and inlet pressures. Adjust regulator as required.</li> <li>9. Inspect pilot flame strength. Clean or replace orifice as necessary.</li> <li>10. Inspect thermocouple/thermopile or IPI sensor rod for soot, corrosion and deterioration. Clean with emery cloth or replace as required.</li> <li>11. Verify millivolt output. Replace as necessary.</li> </ol>
Venting	<ol style="list-style-type: none"> <li>1. Inspect venting for blockage or obstruction such as birds' nests, leaves, etc.</li> <li>2. Confirm that termination cap remains clear and unobstructed by plants, etc.</li> <li>3. Verify that termination cap clearance to subsequent construction (building additions, decks, fences or sheds) has been maintained.</li> <li>4. Inspect for corrosion or separation.</li> <li>5. Verify weather stripping sealing and flashing remain intact.</li> <li>6. Inspect draft shield to verify it is not bent, damaged or missing.</li> </ol>
Remote controls	<ol style="list-style-type: none"> <li>1. Verify operation of remote.</li> <li>2. Replace batteries in remote transmitters and battery-powered receivers.</li> <li>3. Verify batteries have been removed from battery back-up in IPI systems to prevent premature battery failure or leaking.</li> </ol>

# 16 Reference Materials

## A. Appliance Dimension Diagram

Dimensions are actual appliance dimensions. Use for reference only. For framing dimensions and clearances refer to Section 3.





Figure 16.1 Appliance Dimensions



## B. Vent Components Diagrams

Components	Description
DVP4	4 in. length Vent Pipe
DVP6	6 in. length Vent Pipe
DVP12	12 in. length Vent Pipe
DVP24	24 in. length Vent Pipe
DVP6A	3 in. - 6 in. Slip Section Vent Pipe (to be used with another piece of pipe)
DVP36	36 in. length Vent Pipe
DVP48	48 in. length Vent Pipe
DVP12A	3 in. - 12 in. Slip Section Vent Pipe (to be used with another piece of pipe)
DVP12MI	12 in. Vent Pipe - non-unitized (can be cut to length)
DVP24MI	24 in. Vent Pipe - non-unitized (can be cut to length)
DVP45	45° Elbow
DVP90ST	90° Elbow
DVP-AS2	Attic Insulation Shield
DVP-FS	Ceiling Firestop
DVP-HVS	Vent Support - Horizontal
DVP-WS	Wall shield firestop (used to ensure horizontal clearances)
RF6M	Roof Flashing (vertical termination for 0/12 to 6/12 pitch) - pack of four
RF12M	Steep Pitch Roof Flashing (for 7/12 to 12/12 pitch) - pack of six
BEK	Brick Extension Kit - 10 pcs.
DVP-BEK2	Brick Extension Kit for High Performance Cap
DVP-TRAPFL	Trap Cap Rain Flashing - qty. 4
COOL-ADDM	Cap Shield (for DVP-TRP) - pack of six
DRC-RADIUS	Cap Shield (for DVP-TRAP and DVP-HPC)
DVP-TVHW	Vertical Termination Cap (High Wind). Includes storm collar and fastener pack.
PVK-80	Power Vent Kit
DVP-TV	Vertical Termination Cap - Includes storm collar & fastener pack.
DVP-TB1	Basement/window well termination cap. Includes fastener pack.
DVP-FBHT	Fire Brick Termination Cap
DVP-TRAP	Rear Vent Horizontal Termination Cap
DVP-TRAP1	Horizontal Termination Cap with 1-7/8 in. telescoping flue, wall shield firestop with heat shield & fastener. pack.
DVP-TRAPK1	Top Vent Horizontal Kit with DVP-TRAP1 Termination Cap, wall shield firestop with heat shield, 90° elbow & fastener pack.
DVP-TRAP2	Horizontal Termination Cap with 4 in. telescoping flue, wall shield firestop with heat shield & fastener pack.
DVP-TRAPK2	Top Vent Horizontal Kit with DVP-TRAP2 Termination Cap, wall shield firestop with heat shield, 90° elbow & fastener pack.
DVP-HPC1	Horizontal Termination Cap with 2-1/8 in. telescoping flue, wall shield firestop with heat shield & fastener pack.
DVP-HPC2	Horizontal Termination Cap with 4-1/8 in. telescoping flue, wall shield firestop with heat shield & fastener pack.
DVP-HSM-B	Extended Heat Shield
DVP-HRC-SS	High Rise Termination Cap - Unpainted Stainless Steel (not approved for all units)
DVP-HRC-ZC-SS	High Rise Termination Cap - Zero Clearance - Unpainted Stainless Steel (not approved for all units)
4033-016	DVP-TRAP to DVP-HPC Side Filler Kit

## Vent Components Diagrams (con't)




Pipe	Effective Length
DVP4	4 in. (102 mm)
DVP6	6 in. (152 mm)
DVP12	12 in. (305 mm)
DVP24	24 in. (610 mm)
DVP36	36 in. (914 mm)
DVP48	48 in. (1219 mm)
DVP6A	3 to 6 in. (76 to 152 mm)
DVP12A	3 to 12 in. (76 to 305 mm)
DVP12MI	3 to 12 in. (76 to 305 mm)
DVP24MI	3 to 24 in. (76 to 610 mm)





**Assembled**  
Height: 24 in./610 mm  
Diameter: 10 in./254 mm


**DVP-AS2**



**DVP-FS**  
**Ceiling Firestop**




**DVP-HVS**  
**Vent Support**




**DVP-WS**  
**Wall Shield Firestop**


# Vent Components Diagrams (con't)




**RF6M**  
Roof Flashing Multi-pak




**RF12M**  
Roof Flashing Multi-pak




**BEK**  
Trap Cap Brick Extension




**DVP-BEK2**  
DVP-HPC Cap Brick Extension



**DVP-TRAPFL**  
Flashing




**COOL-ADD**  
Cap Shield





**DRC-RADIUS**  
Cap Shield


## Vent Components Diagrams (con't)




**DVP-TB1**  
Basement Vent Cap




**PVK-80**  
(For use with IPI and DSI appliances only.)




**DVP-TV**  
Vertical Termination Cap




**DVP-TVHW**  
Vertical Termination Cap (High wind)



**DVP-FBHT**  
Fire Brick Termination Cap




**DVP-HPC**  
High Performance Cap




## Vent Components Diagrams (con't)


Note: Heat shields **MUST** overlap by a minimum of 1-1/2 in. (38 mm). **The heat shield is designed to be used on a wall 4 in. to 7-1/4 in. (102 mm to 184 mm) thick.** If wall thickness is less than 4 in. (102 mm) the existing heat shields must be field trimmed. If wall thickness is greater than 7-1/4 in. (184 mm) a DVP-HSM-B will be required.




**DVP-TRAP**  
Horizontal Termination Cap




**DVP-TRAP1**




**DVP-TRAPK1**




**DVP-TRAP2**




**DVP-TRAPK2**




**DVP-HPC1**




**DVP-HPC2**



**DVP-TRAP to DVP-HPC Side Filler Kit**



**DVP-HRC-SS**



**DVP-HRC-ZC-SS**

**This page intentionally left blank.**

Mountain View Hearth Products  
manuals.stove-parts-unlimited.com

➔ C. Service Parts List

**heatilator**  
The first name in fireplaces




*Service Parts*

**CD4236M Series**

Service Parts Diagram  
36 in. Caliber - DV Clean Face


Beginning Manufacturing Date: 12/06  
Ending Manufacturing Date: Active

#22 Log/Grate Assembly




#	Description of Part	Serial # Cutoff	CD4236MR	CD4236MLR	CD4236MIR	CD4236MILR	Qty.
1	Flue Adapter Plate		25882	25882	25882	25882	1
2	Flue Cover		34916	34916	34916	34916	1
3	Flue Adapter Plate w/Hole		4000-226	4000-226	4000-226	4000-226	1
4	Intake Collar Assembly		4040-041	4040-041	4040-041	4040-041	1
5	Exhaust Collar Assembly		4040-042	4040-042	4040-042	4040-042	1
6	Glass Clip Support Assembly		33858	33858	33858	33858	4
7	Junction Box Radiation Shield		4031-193	4031-193	4031-193	4031-193	1
8	Junction Box (Plastic)		4021-013	4021-013	4021-013	4021-013	1
9	Junction Box Cover Plate		4031-222	4031-222	4031-222	4031-222	1
10	Flue Baffle		4040-197	4040-197	4040-197	4040-197	1
11	Burner Pan Assembly		4040-093	4040-093	4040-093	4040-093	1
12	Hearth Pan		4040-255	4040-255	4040-255	4040-255	1
13	Burner Support		4040-259	4040-259	4040-259	4040-259	1
14	Glass Heat Shield		4040-153	4040-153	4040-153	4040-153	1
15	Glass/Frame Assembly		4040-087	4040-087	4040-087	4040-087	1
16	Mesh Face Assembly		4040-850	4040-850	4040-850	4040-850	1
17	Hood		4040-852	4040-852	4040-852	4040-852	1
18	Top Latch Cover		4040-856	4040-856	4040-856	4040-856	1
19	Screen Assembly		4040-862	4040-862	4040-862	4040-862	1
20	Bottom Latch Cover		4040-858	4040-858	4040-858	4040-858	1
21	Floor Cover		4040-860	4040-860	4040-860	4040-860	1
	Screen Rod		4040-866	4040-866	4040-866	4040-866	1
	Grate Retainer		4040-272	4040-272	4040-272	4040-272	1
	Glass Kit w/Screen		4040-033	4040-033	4040-033	4040-033	1
	Screen Bracket		28159	28159	28159	28159	2
	Back Refractory		4040-294	4040-294	4040-294	4040-294	1
22	Log/Grate Assembly		4040-051	4040-051	4040-051	4040-051	1
23	Front Y Log		4040-200	4040-200	4040-200	4040-200	1
24	Front Log		4040-201	4040-201	4040-201	4040-201	1
	Top Log Assembly		4040-038	4040-038	4040-038	4040-038	1
25	Top Y Log		4040-202	4040-202	4040-202	4040-202	1
26	Top Log		4040-203	4040-203	4040-203	4040-203	1
27	Middle Log	Pre GA1647700	4040-206	4040-206	4040-206	4040-206	1
		Post GA1647700	4000-316	4000-316	4000-316	4000-316	1
28	Back Log Assembly		4040-207	4040-207	4040-207	4040-207	1
29	Gasket		4031-252	4031-252	4031-252	4031-252	1
30	Valve Assembly		4040-061	4040-062	4040-063	4040-064	1
31	Valve Plate Gasket		4040-198	4040-198	4040-198	4040-198	1
	Lava Rock Bag Assembly		4040-094	4040-094	4040-094	4040-094	1
	Mineral Wool		14333B	14333B	14333B	14333B	1
	Vermiculite (small)		28746	28746	28746	28746	1
	Lava Rock (3lbs. Bag)		4021-297	4021-297	4021-297	4021-297	1
	Caliber II Installation Instructions		4040-849	4040-849	4040-849	4040-849	1

Standing Pilot Valve Assembly






Intermittent Pilot Ignition (IPI) Valve Assembly






#22 Log/Grate Assembly




#	Description of Part	Serial # Cutoff	CD4842MR	CD4842MLR	CD4842MIR	CD4842MILR	Qty.
1	Flue Adapter Plate		25882	25882	25882	25882	1
2	Flue Cover		34916	34916	34916	34916	1
3	Flue Adapter Plate w/Hole		4000-226	4000-226	4000-226	4000-226	1
4	Intake Collar Assembly		4040-041	4040-041	4040-041	4040-041	1
5	Exhaust Collar Assembly		4040-042	4040-042	4040-042	4040-042	1
6	Glass Clip Support Assembly		33858	33858	33858	33858	6
7	Junction Box Radiation Shield		4031-193	4031-193	4031-193	4031-193	1
8	Junction Box (Plastic)		4021-013	4021-013	4021-013	4021-013	1
9	Junction Box Cover Plate		4031-222	4031-222	4031-222	4031-222	1
10	Flue Baffle		4040-197	4040-197	4040-197	4040-197	1
11	Burner Pan Assembly		4040-093	4040-093	4040-093	4040-093	1
12	Hearth Pan		4040-256	4040-256	4040-256	4040-256	1
13	Burner Support		4040-259	4040-259	4040-259	4040-259	1
14	Glass Heat Shield		4040-154	4040-154	4040-154	4040-154	1
15	Glass/Frame Assembly		4040-088	4040-088	4040-088	4040-088	1
16	Mesh Screen Assembly		4040-851	4040-851	4040-851	4040-851	1
17	Hood		4040-853	4040-853	4040-853	4040-853	1
18	Top Latch Cover		4040-857	4040-857	4040-857	4040-857	1
19	Screen Assembly		4040-863	4040-863	4040-863	4040-863	1
20	Bottom Latch Cover		4040-859	4040-859	4040-859	4040-859	1
21	Floor cover		4040-861	4040-861	4040-861	4040-861	1
	Screen Rods		4040-867	4040-867	4040-867	4040-867	1
	Glass Kit w/Screen		4040-034	4040-034	4040-034	4040-034	1
	Screen Bracket		28159	28159	28159	28159	2
	Back Refractory		4040-295	4040-295	4040-295	4040-295	1
22	Log/Grate Assembly		4040-052	4040-052	4040-052	4040-052	1
23	Front Y Log		4040-200	4040-200	4040-200	4040-200	1
24	Front Log		4040-201	4040-201	4040-201	4040-201	1
	Top Log Assembly		4040-038	4040-038	4040-038	4040-038	1
25	Top Y Log		4040-202	4040-202	4040-202	4040-202	1
26	Top Log		4040-203	4040-203	4040-203	4040-203	1
27	Middle Log	Pre GA1647700	4040-206	4040-206	4040-206	4040-206	1
		Post GA1647700	4000-316	4000-316	4000-316	4000-316	1
28	Back Log Assembly		4040-208	4040-208	4040-208	4040-208	1
29	Gasket		4031-252	4031-252	4031-252	4031-252	1
30	Valve Assembly		4040-061	4040-062	4040-063	4040-064	1
31	Valve Plate Gasket		4040-198	4040-198	4040-198	4040-198	1
	Lava Rock Bag Assembly		4040-094	4040-094	4040-094	4040-094	1
	Mineral Wool		14333B	14333B	14333B	14333B	1
	Vermiculite (small)		28746	28746	28746	28746	1
	Lava Rock (3lbs. Bag)		4021-297	4021-297	4021-297	4021-297	1
	Caliber II Installation Instructions		4040-849	4040-849	4040-849	4040-849	1

Standing Pilot Valve Assembly




Intermittent Pilot Ignition (IPI) Valve Assembly







## D. Optional Components




**WTBC36D 36 in. Weathered Brick Refractory Liner Kit**  
**WTBC42D 42 in. Weathered Brick Refractory Liner Kit**



**Arts & Crafts Faux Front**  
**FFCAC**



**Modernist Faux Front**  
**FFCM**



**Jamestown Faux Front**  
**FFCJ**

## (D. Optional Components con't)

### CD4236 41 in. Caliber Top/Rear Direct Vent Circulating Gas Appliance

Model #	Description
FFCM36	Modernist-style black decorative faux front
FFCM36PT	Modernist-style pewter decorative faux front
FFCM36BN	Modernist-style brushed nickel decorative faux front
FFCAC36	Arts & Crafts-style black decorative faux front
FFCAC36PT	Arts & Crafts-style pewter decorative faux front
FFCAC36BN	Arts & Crafts-style brushed nickel decorative faux front
FFCJ36	Jamestown-style black decorative faux front
FFCJ36PT	Jamestown-style pewter decorative faux front
GFK4B	Transaxial fan kit
GFK4MB	Multi-pack of 12 GFK4B transaxial fan kits
GFK160B	160 CFM transaxial fan kit
GFK160MB	Multi-pack of 12 GFK160B 160 CFM transaxial fan kits
WTBC36D	36 in. weathered refractory
WSK-MLT-HTL	Multi-function wall switch
RC-BATT-HTL	Battery operated remote control
RC-SMART-HTL	Remote control (requires 110v or prewiring)
RCT-MLT-HTL	Multi-functional remote: ON/OFF, high/low flame, room temp, fan speed
SMART-STAT-HTL	Multi-functional remote: ON/OFF, room temp, thermostat temp, timer
SMART-BATT-HTL	Multi-functional remote: ON/OFF, thermostat temp, timer
CKVP	LP gas conversion kit for standing pilot ignition system
CKVN	Natural gas conversion kit for standing pilot ignition system
DCKVP	LP gas conversion kit for Intellifire ignition system
DCKVN	Natural gas conversion kit for Intellifire ignition system
SCKVP-B	LP SIT conversion kit
SCKVN-B	NG SIT conversion kit
TK302B	Polished brass front trim kit (5 bars, 1 hood, 1 upper trim)
TK302S	Stainless steel front trim kit (5 bars, 1 hood, 1 upper trim)
TKN65B	Polished brass accent trim kit (2 pieces)
TKN65S	Stainless steel accent trim kit (2 pieces)
TKN65PT	Pewter accent trim kit (2 pieces)
TKN65BN	Brushed nickel accent trim kit (2 pieces)
TK6B	Polished brass louver trim kit (4 bars)
TK6S	Stainless steel louver trim kit (4 bars)
TK6PT	Pewter louver trim kit (4 bars)
TK6BN	Brushed nickel louver trim kit (4 bars)

### CD4842 47 in. Caliber Top-Rear Direct Vent Circulating Gas Appliance

Model #	Description
FFCM42	Modernist-style black decorative faux front
FFCM42PT	Modernist-style pewter decorative faux front
FFCM42BN	Modernist-style brushed nickel decorative faux front
FFCAC42	Arts & Crafts-style black decorative faux front
FFCAC42PT	Arts & Crafts-style pewter decorative faux front
FFCAC42BN	Arts & Crafts-style brushed nickel decorative faux front
FFCJ42	Jamestown-style black decorative faux front
FFCJ42PT	Jamestown-style pewter decorative faux front
GFK4B	Transaxial fan kit
GFK4MB	Multi-pack of 12 GFK4B transaxial fan kits
GFK160B	160 CFM transaxial fan kit
GFK160MB	Multi-pack of 12 GFK160B 160 CFM transaxial fan kits
WTBC42D	42 in. weathered refractory
WSK-MLT-HTL	Multi-function wall switch
RC-BATT-HTL	Battery operated remote control
RC-SMART-HTL	Remote control (requires 110v or prewiring)
RCT-MLT-HTL	Multi-functional remote: ON/OFF, high/low flame, room temp, fan speed
SMART-STAT-HTL	Multi-functional remote: ON/OFF, room temp, thermostat temp, timer
SMART-BATT-HTL	Multi-functional remote: ON/OFF, thermostat temp, timer
CKVP	LP gas conversion kit for standing pilot ignition system
CKVN	Natural gas conversion kit for standing pilot ignition system
DCKVP	LP gas conversion kit for Intellifire ignition system
DCKVN	Natural gas conversion kit for Intellifire ignition system
SCKVP-B	LP SIT conversion kit
SCKVN-B	NG SIT conversion kit
TK402B	Polished brass front trim kit (5 bars, 1 hood, 1 upper trim)
TK402S	Stainless steel front trim kit (5 bars, 1 hood, 1 upper trim)
TKN25B	Polished brass accent trim kit (2 pieces)
TKN25S	Stainless steel accent trim kit (2 pieces)
TKN25PT	Pewter accent trim kit (2 pieces)
TKN25BN	Brushed nickel accent trim kit (2 pieces)
TK7B	Polished brass louver trim kit (4 bars)
TK7S	Stainless steel louver trim kit (4 bars)
TK7PT	Pewter louver trim kit (4 bars)
TK7BN	Brushed nickel louver trim kit (4 bars)

**This page intentionally left blank.**

Mountain View Hearth Products  
manuals.stove-parts-unlimited.com

**This page intentionally left blank.**

Mountain View Hearth Products  
manuals.stove-parts-unlimited.com

**This page intentionally left blank.**

Mountain View Hearth Products  
manuals.stove-parts-unlimited.com

## E. Limited Lifetime Warranty

# heatilator®

*The first name in fireplaces*

## Gas Appliance (Fireplace) Limited Lifetime Warranty

**HEARTH & HOME TECHNOLOGIES INC. ("HHT")** extends the following warranty for HEATILATOR® gas appliances installed in the United States of America or Canada (the "Appliance"). Dealers and employees of HHT have no authority to make any warranty or authorize any remedies in addition to or inconsistent with the terms of this warranty.

### Limited Lifetime Warranty

HHT warrants the Appliance for component failure due to a manufacturing defect of any of the following components: combustion chamber, burner pan, and logs. The Limited Lifetime Warranty specified above is subject to the conditions, exclusions and limitations listed below, is for the period the Appliance is owned by the original homeowner only, and is nontransferable.

### 1 Year Limited Warranty

HHT warrants the Appliance to be free from failure of any of the following components for a period of one year after installation: valve, flexible gas line connector, glass panel, fan, direct vent chimney components, factory paint, gasket, piezo ignitor, thermopile, thermocouple, junction box, pilot assembly, shutoff valve, high limit switch, refractory liners, transformer, and control box. If the Heatilator Appliance is found to be defective in either material or workmanship within one year of the date of original installation, HHT will provide replacement parts at no charge and pay reasonable labor and freight costs, and is for the period of one year following the date of original installation of the Appliance.

### Conditions, Exclusions, & Limitations of Liability

- A. Both the Limited Lifetime and 1 Year Limited Warranties supplied by HHT apply only while the Appliance is in its location of original installation. HHT's obligation under this warranty does not extend to damages resulting from (1) installation, operation or maintenance of the Appliance not in accordance with the Installation Instructions, Operating Instructions, and the Listing Agent Identification Label furnished with the Appliance; (2) installation which does not comply with local building codes; (3) shipping, improper handling, improper operation, abuse, misuse, accident or unworkmanlike repairs; (4) environmental conditions, inadequate ventilation or drafting caused by tight sealing construction of the structure, air handling devices such as exhaust fans or forced air furnaces, or other causes; (5) use of fuels other than those specified in the Operating Instructions; (6) installation or use of components not supplied with the Appliance or any other components not expressly authorized and approved by HHT; and/or (7) modification of the Appliance not expressly authorized and approved by HHT in writing. This warranty is limited to only the component parts manufactured or supplied by HHT.
- B. HHT's liability under both the Limited Lifetime Warranty and the 1 Year Limited Warranty is limited to the replacement and repair of defective components or workmanship during the applicable period. HHT may fully discharge all of its obligations under such warranties by repairing the defective component(s) or at HHT's discretion, providing replacement parts at no charge and paying reasonable labor and freight costs.
- C. **EXCEPT TO THE EXTENT PROVIDED BY LAW, HHT MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY SPECIFIED HEREIN. THE DURATION OF ANY IMPLIED WARRANTY IS LIMITED TO DURATION OF THE WARRANTY SPECIFIED ABOVE.**
- D. Some states do not allow exclusions or limitations of incidental or consequential damages, so those limitations may not apply to you. This warranty gives you specific rights; you may also have other rights which vary from state to state.

### How to Obtain Service

To obtain service under this warranty you must:

1. Send written notice of the claimed condition to Heatilator Technical Service Department, Hearth & Home Technologies, 1915 W. Saunders Street, Mt. Pleasant, Iowa 52641-1563. You may also register your claim online at [www.heatilator.com](http://www.heatilator.com).
2. Provide proof of purchase, model number, serial number, and manufacturing date code to HHT.
3. Provide HHT reasonable opportunity to investigate the claim, including reasonable opportunity to inspect the Appliance prior to any repair or replacement work and before the Appliance or any component of the Appliance has been removed from the place of original installation.
4. Obtain HHT's consent to any warranty work before the work is done.

### ADDITIONAL INFORMATION:

If you would like information on current HEATILATOR products or want to locate a dealer in your area, call 1-800-927-6841.

©2003 Heatilator® is a Registered Trademark of Hearth & Home Technologies Inc.

