




OWNER'S MANUAL

Installation, Operation and Maintenance Instructions

**SAHARA CATALYTIC CIRCULATOR HEATER
MODELS AHS1 (GRAY) AND AHS1B (BROWN)
FOR USE WITH SOLID WOOD FUEL ONLY**



TESTED TO UL1482 AND CERTIFIED
BY
WARNOCK HERSEY INTERNATIONAL, INC.

IMPORTANT GENERAL INFORMATION

- ° READ ALL INSTRUCTIONS BEFORE STARTING THE INSTALLATION.
- ° FAILURE TO FOLLOW SAFETY INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR EVEN DEATH.
- ° SAVE MANUAL FOR FUTURE REFERENCE.

SAFETY NOTICE

If this heater is not properly installed, a house fire may result. For your safety, follow the installation directions. Contact local building or fire officials about restrictions and installation inspection requirements in your area.

This heater must be connected to a Listed Factory-Built Residential Type and Building Heating Appliance Chimney or an approved masonry chimney with a flue liner.

MANUFACTURED BY: THE ASHLEY HEATER COMPANY
A DIVISION OF MARTIN INDUSTRIES, INC.
P.O. BOX 128
FLORENCE, AL. 35631
PH NO. 205/767-0330

SUMMARY OF RULES FOR SAFE INSTALLATION, USE AND CARE

PLEASE READ THIS ENTIRE MANUAL BEFORE YOU INSTALL AND USE YOUR NEW HEATER. FAILURE TO FOLLOW INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY OR EVEN DEATH.

SAFE INSTALLATION

1. **Qualified Installer/Codes.** Your heater should be installed only by an experienced wood burning heater installer in strict accordance with this manual. Even though the work is done by a qualified installer, you should be familiar with your installation and be sure the work is done in accordance with this manual. Contact local building or fire officials about restrictions and installation inspection in your area. Make sure the installation meets all local codes and that all needed permits are obtained. Many home fires are caused by too little clearance or improper installation of the venting system. This manual gives necessary information to safely install your heater.
2. **Dangerous Uses/Locations.** Due to fire risk, do not install this heater in a mobile home, modular home or trailer. Do not install it in a garage or area where any flammable liquids are stored. An explosion or fire could result. Due to risk of persons being injured by contacting the hot surfaces of the heater, locate the heater away from traffic areas such as halls.
3. **Chimney and Flue Pipe.** This heater must be connected to a separate flue pipe and chimney system vented to the outside. The chimney may be either an approved Class "A" Masonry Chimney or a 6" diameter Listed Factory-Built Residential Type and Building Heating Appliance Chimney. These two chimney types will be described in detail in this manual. The heater must be connected to the chimney using a flue pipe that is at least 24 gauge black or blued steel. Do not use a Class "B" aluminum gas vent pipe for either the flue pipe or the chimney. This is unsafe, is a fire risk, and is prohibited by the National Fire Protection Association. To avoid the risk of fire, masonry chimneys must be at least 4" thick (12" if built of rubble stone) and must have a 5/8" fireclay or stainless steel lining.

Review the seven methods of venting shown by Figure 12 through 18. Follow the method that best suits your home. Failure to vent the heater in accordance with the instructions can result in fire or smoke damage and bodily injury including death.

DANGER: FLUE PIPE (CHIMNEY PIPE) GETS SO HOT IT CAN CATCH YOUR WALL OR CEILING ON FIRE IF NOT PROPERLY INSTALLED. THEREFORE, YOU MUST USE AN APPROPRIATE METHOD TO PASS THROUGH A COMBUSTIBLE WALL TO A CHIMNEY (SEE FIGS. 13, 14, 17, and 18) OR A CHIMNEY SUPPORT OR FINISH SUPPORT PACKAGE TO PASS THROUGH A CEILING (SEE FIGS. 15 and 16). OTHERWISE, THE WALL OR CEILING WILL CATCH FIRE FROM THE HOT FLUE PIPE.

DANGER: DO NOT CONNECT THIS UNIT TO A CHIMNEY FLUE SERVING ANOTHER APPLIANCE. THERE IS A SERIOUS SAFETY RISK IF TWO APPLIANCES OR HEATERS ARE CONNECTED TO THE SAME FLUE.

4. **Floor Protector.** The heater must be placed on a listed floor protector if the floor is wood or other combustible flooring. If carpet is present, it must be removed. Place the heater on a listed floor protector or a floor protector made of a noncombustible, inorganic material equal to 3/8 inch thick millboard having a thermal conductivity of $K = 0.84 \text{ BTU/In/Ft}^2/\text{Hr}/^\circ\text{F}$ to prevent the floor from catching fire from sparks or glowing embers that might escape the heater or drop from the joints of the chimney connector pipe. The floor protector must protect the floor beneath and around the heater and chimney connector flue pipe as shown by figures 1 through 5.
5. **Safe Clearances.** To prevent wall or ceiling fires, ALWAYS maintain the designated clearance dimensions to combustible walls or combustible ceilings as noted for each type of heater installation shown by Figures 12 through 18. Failure to observe these clearances can cause walls or ceilings to catch fire. All other combustible items: (drapes, furniture, clothing, etc.) should be kept even further away from the heater to avoid a fire. NFPA 211 defines combustible material as material made of or surfaced with wood, compressed paper, plant fibers, plastics, or other material that will ignite and burn, whether flameproofed or not, or whether plastered or unplastered.
6. **Hot Surfaces.** Keep children away from the heater. Do not touch the heater until it is cool to avoid burns.
7. **Smoke Detector.** Install a smoke detector on each floor of your home. In case of accidental fire it can provide time to escape.
8. **Inspection After Installation, But Before Use.** Have the entire installation inspected by the local fire department, building code inspector or fire marshal to be sure your installation is safe. Have this manual on hand for a reference if needed. Keep the manual in a safe place where it can be found when needed.

SAFE USE

1. **Dangerous Fuels.** This heater is designed to burn only natural wood. (See the "Wood Facts" section of this manual for additional information about wood.) This heater is not designed to burn artificial logs, processed fuels, coal, charcoal, plywood, trash, garbage, wrapping paper, preformed wood, or treated wood. These prohibited fuels may cause the heater and chimney to dangerously overheat or release poisonous gases into the dwelling. These prohibited fuels also contain elements such as lead, zinc and sulfur that will "poison" or deactivate the catalytic combustor. A poisoned catalytic combustor will not operate effectively and must be replaced.

Never use gasoline, gasoline type lantern fuels, kerosene, charcoal lighter fluid, or any similar liquids to start or freshen up a fire in this heater. The use or presence of these type fuels in or around the heater can cause an explosion and house fire resulting in personal injuries and property damage.

INTRODUCTION

Many home fires result from not following installation, operation and maintenance instructions supplied by manufacturers of heating appliances. For your safety please read and follow our instructions before installation and use of the heater.

TABLE OF CONTENTS

SECTION 1 . . . SUMMARY OF SAFETY RULES FOR SAFE INSTALLATION, USE AND CARE	
SAFE INSTALLATION	1
SAFE USE	1
SAFE CARE	2
SECTION 2 . . . LOCATING AND INSTALLING THE HEATER	
SELECTING A LOCATION FOR THE HEATER	2
TOOLS AND SUPPLIES NEEDED FOR INSTALLATION	3
INSTALLATION EQUIPMENT NEEDED FOR YOUR SAFETY	3
IMPORTANT INFORMATION ABOUT THE VENTING SYSTEM	6
REAR VENTED HEATER OR TOP VENTED HEATER?	6
HEATER INSPECTION	7
HEATER INSTALLATION	7
MASONRY CHIMNEY REQUIREMENTS	8
CONNECTION OF FLUE PIPE INTO A MASONRY FIREPLACE	10
CONNECTION OF FLUE PIPE TO A MASONRY CHIMNEY THROUGH A COMBUSTIBLE WALL	11
METAL PREFABRICATED CHIMNEY REQUIREMENTS	16
METAL PREFABRICATED CHIMNEY INSTALLATION	16
SECTION 3 . . . HOW TO USE THE HEATER, SAFE OPERATION	
SAFETY REMINDERS	21
WOOD BURNING FACTS	21
HEATER OPERATION	22
How This Heater Operates	22
Building A Fire	22
Fire Tending	23
Catalytic Combustor Operating Temperatures	23
Ashes Removal and Disposal	24
Blower Operation	24
SECTION 4 . . . HOW TO TAKE CARE OF YOUR HEATER AND CHIMNEY, SAFE MAINTENANCE	
CREOSOTE FORMATION AND REMOVAL, CHIMNEY FIRE, CHIMNEY MAINTENANCE	24
ICE FORMATION AND PREVENTION	24
HEATER MAINTENANCE	25
WHEN AND HOW TO REPLACE THE CATALYTIC COMBUSTOR(S)	25
CATALYTIC COMBUSTOR PLUGGING	26
SECTION 5 . . . TROUBLE SHOOTING, FINAL CHECKLIST, REPAIR PARTS, WARRANTY	
THE VENTING SYSTEM-KEY TO GOOD HEATER PERFORMANCE	26
WHAT TO DO IF THE HEATER SMOKES OR BURNS POORLY OR EXCESSIVE CREOSOTE ACCUMULATES IN THE CHIMNEY	26
WHAT TO DO IF THE HEATER BURNS TOO RAPIDLY OR OVERHEATS	26
FINAL CHECKLIST OF DO'S AND DON'TS	27
REPAIR PARTS	29
WARRANTY	32

2. **Dangerous Overfiring.** DO NOT OVERFIRE THIS HEATER. Overfiring can damage the catalytic combustor or cause chimney fire or a house fire. A catalytic combustor that has been damaged by excessive temperatures caused by overfiring will not operate effectively and must be replaced. Overfiring can also greatly shorten the life of the heater. The following conditions will cause your heater to overfire:

- Leaving the heater's fuel feed door open during heater operation.
- Leaving the heater's ash removal door open during heater operation.
- Burning improper fuel. (See Dangerous Fuels above).

If any part of the heater or chimney connector glows or becomes red hot, the heater is overfired. Immediately close any heater door that might be open, completely close the heater's primary combustion air inlet which is built into the ash removal door, and move the heater's secondary air inlet control lever to its most closed position. (See figure 19.)

3. **In Case of a Chimney Fire.** A chimney fire is usually indicated by a roaring noise within the chimney and/or a pinging noise within the chimney connector, and the emission of sparks and ash from the top of the chimney. If a chimney fire occurs, immediately close any heater door that might be open and completely close the heater's combustion air inlet. (See figure 19). Get everyone out of the house, and call the fire department. Protect the roof by wetting it with a garden hose or buckets of water.

A chimney fire may cause structural damage to the chimney. After the chimney fire is over, thoroughly inspect the chimney, chimney connector and surrounding materials for damage and make any necessary repairs before using the heater again. Most fire departments make free chimney inspections and can provide assistance in locating chimney cleaning or repair services.

TO REDUCE THE RISK OF A CHIMNEY FIRE:

- BURN ONLY WELL SEASONED WOOD.
- DO NOT OVERFIRE THE HEATER.
- KEEP THE CHIMNEY'S FLUE LINING CLEAN OF CREOSOTE AS NOTED BY THE FOLLOWING SAFE CARE SECTION OF THIS MANUAL.

For additional information on safe use of this heater, see the "HOW TO USE THE HEATER" section of this manual.

SAFE CARE

1. **Creosote Formation and Need For Removal.** When wood is burned slowly it produces tar and other organic vapors which combine with expelled moisture to form creosote. The creosote vapors condense in the relatively cool chimney flue of a slow burning fire. As a result, creosote residue accumulates on the flue lining. When ignited, this creosote makes an extremely hot fire in the chimney called a chimney fire.

The chimney connector and chimney should be inspected at least twice monthly during the heating season to determine if a creosote buildup has occurred. If creosote has accumulated it should be removed to reduce the risk of a chimney fire.

2. **Disposal of Ashes.** Even though reduction of creosote is one of the primary advantages of a heater employing a catalytic combustor, some creosote residue will escape the heater during normal heater operation and accumulate on the flue lining. Also, in the event the catalytic combustor ceases to function, creosote can be expected to accumulate on the flue lining at an increased rate.

When a catalytic combustor ceases to function, you will notice an increase in wood usage, sluggish operation of the heater, and an increase in creosote accumulation on the flue lining. However, with proper care and usage, a new catalytic combustor should last for many heating seasons.

When a catalytic combustor does stop functioning, it should be replaced as soon as possible, or at least removed from the heater until a replacement is obtained.

Ashes should be placed in a metal container with a tight fitting lid. The closed container of ashes should be placed on a noncombustible floor or on the ground, well away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise locally dispersed, they should be retained in the closed container until all cinders have thoroughly cooled.

3. **Annual Inspection.** Have a qualified person inspect your complete system before cold weather each year. Make sure creosote is removed. Replace all damaged or worn parts before using.

For additional information on safe care of this heater, see the "HOW TO TAKE CARE OF THE HEATER" section of this manual.

SAFETY NOTICE: IF THIS HEATER IS NOT PROPERLY INSTALLED, A HOUSE FIRE MAY RESULT. FOR YOUR SAFETY, FOLLOW THE INSTALLATION DIRECTIONS. CONTACT LOCAL BUILDING OR FIRE OFFICIALS ABOUT RESTRICTIONS AND INSTALLATION INSPECTION REQUIREMENTS IN YOUR AREA.

SECTION 2

LOCATING AND INSTALLING THE HEATER

SELECTING A LOCATION FOR THE HEATER

1. When locating your heater, consider safety, convenience, traffic flow, and the fact that the heater will need a chimney and chimney connector.
2. Your heater should be located away from doors and hallways or other areas where drafts could blow, smoke, fire or ashes out of the heater during fire tending.
3. The heater should be located in an open area to allow for necessary clearances as specified within this manual.

- 5. Keep furniture, drapes, curtains, wood, paper, and other combustibles far away from the heater.
- 6. Never install the heater in locations where gasoline, kerosene, charcoal lighter, or any other flammable liquids are used or stored.
- 6. DO NOT INSTALL THIS HEATER IN A MOBILE HOME, MODULAR HOME OR TRAILER.

TOOLS AND SUPPLIES NEEDED FOR INSTALLATION

Pencil	Electric drill	Rag or several paper towels
Ruler or tape	Drill bits	No. 8 sheet metal screws
Tin snips	Screwdriver	(3 each for each joint of chimney connector pipe)
Adjustable wrench	Furnace cement	

INSTALLATION EQUIPMENT NEEDED FOR YOUR SAFETY

1. Chimney Connector: (Also known as flue pipe or stove pipe) - The chimney connector joins the heater to the chimney. The chimney connector should be 6-inch diameter black or blued steel, 24 gauge minimum.
2. Thimble: A manufactured or site-constructed device installed in combustible walls through which the chimney connector passes to the chimney. It is intended to keep walls from igniting. A thimble is needed only if chimney connector must pass through a combustible wall between the heater and the chimney.
3. Chimney (Approved Masonry Chimney or a Listed Factory-Built Residential and Building Heating Appliance Chimney): A Masonry Chimney (constructed to the National Fire Protection Association and local code standards) with at least 5/8-inch fire clay lining joined with refractory cement or other listed lining system suitable for use with wood burning heaters. See the "MASONRY CHIMNEY REQUIREMENTS" section of this manual for masonry chimney specifications.

OR

A prefabricated 6-inch diameter Listed Factory-Built Residential and Building Heating Appliance Chimney. Associated components required for installation such as the chimney support base, firestop (as appropriate), attic insulation shield, insulated tee, etc., are necessary to assure a safe chimney installation. Use only components manufactured for the chimney.

AVOID FIRE: Maintain the designated clearance distance to combustibles. Insulation must NOT touch the chimney. There must be the designated air space clearance around the chimney. This air space around a chimney is necessary to allow natural heat removal from the area. Insulation in this space will cause a heat buildup which may ignite wood framing.

4. Floor Protector: To prevent floor from catching fire, a listed floor protector or a floor protector made of a noncombustible inorganic material equal to 3/8-inch thick millboard having a thermal conductivity of $K = 0.84 \text{ BTU/In/Ft}^2/\text{Hr}/^\circ\text{F}$ must be used. Depending on the type of heater installation you use, the floor protector must protect the floor beneath and beyond the heater and chimney connector pipe as shown by figures 1 through 5.

WARNING: MINIMUM CLEARANCES AND FLOOR PROTECTOR SHOWN BY FIGURES 1 THROUGH 5 ARE TO PREVENT WALLS AND FLOOR FROM CATCHING FIRE. MINIMUM CLEARANCES TO CEILING TO PREVENT THE CEILING FROM CATCHING FIRE ARE SHOWN BY FIGURES 13, 14, 17, and 18.

PLAN VIEW SHOWING MINIMUM CLEARANCE AND THE FLOOR PROTECTOR REQUIRED WHEN CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER INTO A MASONRY FIREPLACE. ALSO SEE FIGURE 12.





FIGURE 1

PLAN VIEW SHOWING MINIMUM CLEARANCE AND THE FLOOR PROTECTOR REQUIRED WHEN CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER TO A MASONRY CHIMNEY THROUGH A COMBUSTIBLE WALL OR WHEN CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY THROUGH A COMBUSTIBLE WALL FOR AN OUTSIDE INSTALLATION. ALSO SEE FIGURES 13 AND 17.



PLAN VIEW SHOWING MINIMUM CLEARANCE AND THE FLOOR PROTECTOR REQUIRED WHEN CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY THROUGH A COMBUSTIBLE CEILING AND A COMBUSTIBLE ROOF FOR AN INSIDE INSTALLATION. ALSO SEE FIGURE 15.




FIGURE 4

PLAN VIEW SHOWING MINIMUM CLEARANCE AND THE FLOOR PROTECTOR REQUIRED WHEN CONNECTING THE FLUE PIPE OF A TOP VENTED HEATER TO A MASONRY CHIMNEY THROUGH A COMBUSTIBLE WALL OR WHEN CONNECTING THE FLUE PIPE OF A TOP VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY THROUGH A COMBUSTIBLE WALL FOR AN OUTSIDE INSTALLATION. ALSO SEE FIGURES 14 AND 18.





FIGURE 5

PLAN VIEW SHOWING MINIMUM CLEARANCE AND THE FLOOR PROTECTOR REQUIRED WHEN CONNECTING THE FLUE PIPE OF A TOP VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY THROUGH A COMBUSTIBLE CEILING AND A COMBUSTIBLE ROOF FOR AN INSIDE INSTALLATION. ALSO SEE FIGURE 16.



IMPORTANT INFORMATION ABOUT THE VENTING SYSTEM

1. The venting system consists of a chimney connector (also known as flue pipe or stove pipe) and a chimney. The entire venting system gets extremely hot during use. Temperatures inside the chimney may exceed 2000 degrees in the event of a creosote fire. To protect against the possibility of a home fire, the chimney connector and the chimney must be properly installed and maintained. A thimble must be used when a connection is made through a combustible wall to a chimney. A chimney support package must be used when a connection is made through the ceiling to a prefabricated chimney. These accessories are absolutely necessary to provide safe clearances to combustible wall and ceiling material.
2. The chimney connector stove pipe must be 6-inch diameter, 24 gauge minimum blued or black steel. DO NOT use aluminum or galvanized steel. They cannot properly withstand the extreme temperatures of a wood fire. DO NOT use chimney connector pipe as a chimney. You MUST connect this heater to a chimney comparable to those illustrated in this manual.
3. The joints of the chimney connector (stove pipe) must be assembled so the crimped end is toward the heater and each joint must be sealed with furnace cement and fastened with a minimum of three sheet metal screws.
4. The heater must be connected to a prefabricated Listed Factory-Built Residential Type and Building Heating Appliance chimney or an approved Class "A" masonry chimney with flue liner.
5. NEVER connect this heater to an aluminum type "B" gas vent. It is not safe, is a fire hazard and is prohibited by National Fire Protection Association code (N.F.P.A. 211).
6. Do not connect this heater to a chimney flue serving another appliance. There is a serious safety risk if two appliances or heaters are connected to the same flue.
7. A copy of the N.F.P.A. 211 codes (Chimney, Fireplace, Vents and Solid Fuel Burning Appliances) may be obtained from N.F.P.A., Inc., Batterymarch Park, Quincy, MA. 02269.


REAR VENTED HEATER OR TOP VENTED HEATER?

This heater may be installed as either a rear vented heater or a top vented heater. The heater was manufactured and sold as a rear vented heater; with its flue collar (the part of the heater to which the chimney connector is attached) extending from the rear of the heater. However, the heater may easily be converted into a top vented heater; with its flue collar extending from the top of the heater.

Seven methods of installing the venting system have been approved for this heater and are shown on the following pages. (See figures 12 through 18.) Four of the installation methods are for rear vented heaters and three are for top vented heaters. Study the seven venting system installation methods and decide which is best for your home.

Should you choose a venting system installation for a rear vented heater, you may proceed with the installation since the heater is already rear vented.

FIGURE 6



If you choose a venting system installation for a top vented heater, you will have to convert the heater for top venting before proceeding.

The following procedure should be followed when converting a rear vented heater to a top vented heater (Refer to figure 6.)

1. Be sure the heater's blower power supply cord (Key No. 1) is unplugged.
2. Remove the louvered top assembly (Key No. 2) by lifting it up and out of the top frame assembly (Key No. 3).
3. Remove the top frame assembly (Key No. 3) from the heater by removing the two screws, washers, and nuts which secure it to the heater's firebox top (Key No. 4).
4. Remove the heater's left cabinet side (Key No. 5) by lifting it upward while pulling it toward the left. It will snap loose.
5. Remove the spring handle (Key No. 6) from the bypass damper control lever by turning the spring handle counterclockwise while pulling on it.
6. Remove the rear cabinet assembly (Key No. 7) by removing the six nuts and washers which attach the rear cabinet assembly to the firebox. There are three nuts and washers attaching the rear cabinet assembly to the right rear of the firebox and there are three nuts and washers attaching the rear cabinet assembly to the left rear of the firebox.
NOTE: The rear cabinet assembly (Key No. 7) includes the rear cabinet, the cabinet door assembly and the blower shroud through which the blower's power cord passes.
CAUTION: When removing the rear cabinet assembly, (Key No. 7) from the heater and lying it flat in the floor, care should be taken not to damage nor loosen any of the power supply cord's internal wiring.
7. Remove the flue collar and its gasket attached to the rear of the firebox by removing the flue collar's eight flathead attachment screws. Care should be taken not to damage the flue collar gasket.
8. Remove the firebox cover plate (Key No. 8) and its gasket attached to the top of the firebox by removing the cover plate's eight hex head attachment screws. Care should be taken not to damage the firebox cover plate gasket.
9. Use the flue collar's eight flathead attachment screws to securely attach the flue collar and its gasket to the top of the firebox where the firebox cover plate (Key No. 8) was previously attached. Care should be taken to ensure an airtight seal between the flue collar, the flue collar gasket, and the firebox top.
10. Use the firebox cover plate's eight hex head attachment screws to securely attach the firebox cover plate (Key No. 8) and its gasket to the rear of the firebox where the flue collar was previously attached. Care should be taken to ensure an airtight seal between the firebox cover plate, the firebox cover plate gasket, and the rear of the firebox.
11. Reattach the rear cabinet assembly (Key No. 7) removed by Step 6.
CAUTION: When reattaching the rear cabinet assembly to the firebox, care should be taken not to damage nor loosen any of the power supply cord's internal wiring.
12. Reattach the spring handle (Key No. 6) to the bypass damper control lever by turning the spring handle counterclockwise while pushing it onto the lever.
13. Reattach the left cabinet side (Key No. 5) by positioning it in place, pulling up on its top flange while pushing it into place. The left cabinet side will snap snugly into place.
14. Reattach the top frame assembly (Key No. 3) to the firebox top (Key No. 4). Care should be taken because the same two screws, washers, and nuts which secure the top frame assembly to the firebox top also secures the heater's flame impingement shield inside the heater's firebox.
15. Use the two screws (Key No. 9) provided in the top vent conversion kit furnished with the heater to attach the rear cabinet cover plate (Key No. 10) over the vacated flue collar hole in the rear cabinet.
NOTE: The rear cabinet cover plate (Key No. 10) is provided in the top vent conversion kit furnished with the heater.
16. Replace the center louvered top (key No. 11) in the louvered top assembly (Key No. 2) with the center louvered top (Key No. 12) which has a hole for the flue collar to protrude through. This may be accomplished as follows:
First - Loosen the set screws which hold the louvered top assembly together.
Second - Replace the center louvered top.
Third - Reassemble the louvered top assembly containing the center louvered top (Key No. 12) which has a hole for the flue collar to protrude through. Be sure to securely retighten any set screws previously loosened.
NOTE: The center louvered top (Key No. 12) which has a hole for the flue collar to protrude through is provided in the top vent conversion kit furnished with the heater.
17. Place the assembled louvered top assembly into the cavity of the top frame assembly (Key No. 3).

HEATER INSPECTION

Before installing the heater, check the heater for external damage or missing parts. Check the glass for any cracks. Turn the blower control knob to HIGH and place the power supply cord into a 120 volt, 60 Hz, 15 amp properly fused and grounded receptacle and check the operation of the blower. Check inside the heater for damaged or missing parts.

If any damage or missing parts are detected, report it to the dealer from whom you purchased the heater and get the deficiency corrected before installing and using the heater.

HEATER INSTALLATION

CAUTION: IF THIS HEATER IS NOT PROPERLY INSTALLED, A HOUSE FIRE MAY RESULT. FOR YOUR SAFETY, FOLLOW THE INSTALLATION DIRECTIONS. CONTACT LOCAL BUILDING OR FIRE OFFICIALS ABOUT RE-

RESTRICTIONS AND INSTALLATION INSPECTION REQUIREMENTS IN YOUR AREA.

CAUTION: MOST WALLS AND CEILINGS CONTAIN WOOD EVEN THOUGH THEY ARE MADE OF SHEETROCK OR PLASTER ON THE OUTSIDE. THESE WALLS AND CEILINGS CAN CATCH FIRE FROM THE HOT FLUE PIPE UNLESS PROTECTED AS SHOWN IN THIS MANUAL.

CAUTION: MINIMUM CLEARANCES TO COMBUSTIBLE WALLS AND CEILINGS AS NOTED IN THE MANUAL MUST BE MAINTAINED.


CAUTION: THE HEATER MUST BE PLACED ON A LISTED FLOOR PROTECTOR AS NOTED IN THIS MANUAL IF THE FLOOR IS WOOD OR OTHER COMBUSTIBLE FLOORING. IF CARPET IS PRESENT, IT MUST BE REMOVED. THE FLOOR PROTECTOR MUST NOT BE PLACED ON CARPET.

CAUTION: DO NOT CONNECT THIS HEATER TO A CHIMNEY FLUE SERVING ANOTHER APPLIANCE. THERE IS A SERIOUS SAFETY RISK IF TWO APPLIANCES OR HEATERS ARE CONNECTED TO THE SAME FLUE.

To safely and properly install this heater:

1. Install a Factory-Built Listed Residential Type and Building Heating Appliance Chimney, build an approved masonry chimney with flue liner, or adapt an existing masonry chimney with flue liner to vent this heater. (See figures 12 through 18.)
2. Purchase the 6-inch diameter chimney connector pipes that are required. The pipe should be black or blued steel, 24 gauge minimum. If elbows are needed, use only seamless elbows because seamed elbows can leak smoke. Do not use more than two elbows or the chimney draft will be restricted.
3. If the heater is to be installed on a combustible floor, purchase a listed noncombustible floor protector as described in this manual and install it in the proper location. (See figures 1 through 5.)
4. Assemble the chimney connector pipe sections to determine if the chimney connector pipe will correctly extend from the heater flue collar to the chimney. Any horizontal section of chimney connector pipe must slope upward at least 1/4" rise to the horizontal foot to maintain adequate draft. (See figure 7). Always install the chimney connector pipe with the crimped end toward the heater to prevent creosote from leaking out of the joints. (See figure 7). Always use the least number of chimney connector pipe sections possible. Minimum clearance to combustible walls and ceilings as noted in this manual MUST always be maintained.


NOTE: The inside diameter of some chimney thimbles are too small to accept a standard six-inch diameter chimney connector pipe. If you encounter this problem, the last joint pipe included with this heater can be used as shown by figure 7.
5. After it is determined that the assembled chimney connector will properly connect the heater to the chimney, disassemble all sections of the chimney connector in preparation for the final assembly procedures.
6. Place the crimped end of the first chimney connector pipe or elbow into the heater's flue collar and mark it through each of the holes in the heater's flue collar.
7. Remove the pipe or elbow from the flue collar and drill 1/8-inch diameter holes at the points marked by step 7.
8. Apply furnace cement to the inside surface of the heater's flue collar, reinstall the first pipe or elbow and fasten in place with No. 8 sheet metal screws. Apply additional furnace cement to the outside of the chimney connector flue collar joint if an airtight seal was not achieved when the pipe or elbow was installed.
9. Assemble the remaining chimney connector pipes, by applying furnace cement to the joints, drilling 1/8-inch diameter holes for and attaching each joint with three No. 8 sheet metal screws.
10. Remove all excess furnace cement from the outside surface of the chimney connector with a rag or paper towels. Allow the cement to dry for at least 12 hours before building the first fire in the heater.
11. Route the heater's blower power supply cord away from the heater to avoid damage to the power supply cord from heat or dropped objects. Do not route the power supply cord under the heater's floor protector or rugs of any type. Always keep the power supply cord away from hot surfaces. Plug the power supply cord into a 120 volt, 60 Hz, 15 amp properly fused and grounded receptacle.



MASONRY CHIMNEY REQUIREMENTS

If the heater is to be attached to a masonry chimney, the heater should not be installed until it is determined that the chimney is safe for use. Before installing the heater, have the chimney inspected by a building inspector, fire department, or qualified heating engineer. To prevent risk of walls, roof, or other combustibles catching fire from the extremely hot fire, smoke, and flue

FIGURE 8



FIRESTOPPING

FIGURE 9

*Minimum 1 Inch Clearance for Exterior Chimney to Sheathing




FIGURE 10

Minimum 2 Inch Clearance From Combustible Material and Insulation





FIGURE 12



CONNECTION OF FLUE PIPE TO A MASONRY CHIMNEY THROUGH A COMBUSTIBLE WALL


Figure 13 shows how to connect the flue pipe of a rear vented heater to a masonry chimney through a combustible wall. Figure 14 show how to connect the flue pipe of a top vented heater to a masonry chimney through a combustible wall. There are four allowable ways that a flue pipe can be connected to a masonry chimney by passing through a combustible wall. NFPA 211 allows the following:

1. Use a 3 1/2" thick brick wall built into a combustible wall. A fireclay thimble must be used and it must be at least 12" away from any material that could catch fire. See and study part A of Figure 13 or Figure 14.
2. Use an 8" inside diameter, Listed 1" solid insulation, factory-built chimney. The chimney section must be at least 12" long. The chimney section serves as a pass-through tube for the 6" 24 ga. chimney connector. Steel supports at the ends of the chimney section must hold the 6" pipe 1" away from the inside wall of the chimney section. The chimney section must be at least 2" away from any material that could catch fire. It also must be supported by at least 24 ga. steel supports firmly attached to the wall surface on both sides of the wall. See and study part B of Figures 13 and 14.
3. Use a ventilated thimble, at least 24 ga. steel with two 1" air channels. This means the thimble must be 10" in diameter. The thimble must be surrounded by glass fiber insulation 6" thick. Two 24 ga. wall supports are used to keep 6" between the outer wall of the thimble and any material that can catch fire. The supports must be firmly attached on both sides of the wall. See and study part C of Figures 13 and 14.
4. Use a 6" inside diameter, listed 1" solid insulation, factory-built chimney. The chimney section must be at least 12" long. The chimney section must be 9" away from any material that can catch fire. The section must be supported by 24 ga. steel supports firmly attached to both sides of the wall. See and study part D of Figures 13 and 14.

FIGURE 13

CONNECTION OF REAR VENTED FLUE PIPE TO MASONRY CHIMNEY THROUGH COMBUSTIBLE WALL

NOTE: In addition to the methods shown on this page, a Listed factory built wall pass through accessory may be purchased and installed according to the instructions packaged with it to provide a safe method of passing the flue pipe through a combustible wall.



(FIGURE 13 CONTINUED ON NEXT PAGE)

(FIGURE 13 CONTINUED)






FIGURE 14

CONNECTION OF TOP VENTED FLUE PIPE TO MASONRY CHIMNEY THROUGH COMBUSTIBLE WALL



NOTE: In addition to the methods shown on this page, a Listed factory built wall pass through accessory may be purchased and installed according to the instructions packaged with it to provide a safe method of passing the flue pipe through a combustible wall.



(FIGURE 14 CONTINUED ON NEXT PAGE)

(FIGURE 14 CONTINUED)

D



METAL PREFABRICATED CHIMNEY REQUIREMENTS

Any metal prefabricated chimney that this heater or any woodburning heater is connected to must be a listed high temperature HT residential type and building heating appliance chimney.

When a metal prefabricated chimney is used, the manufacturer's installation instructions must be followed precisely. You must also purchase (from the same manufacturer) and install the ceiling support package or wall pass through and "T" section package, firestops (when needed), insulation shield, roof flashing, chimney cap, etc. Maintain the proper clearance to the structure as recommended by the manufacturer. This clearance is usually a minimum of 2 inches, although it may vary by manufacturer or for certain components.

A Listed chimney cap should be installed to prevent entrance of rain and help eliminate down drafts. An unapproved chimney cap, protector or spark arrestor can become clogged with creosote, leaves or other matter. This blocks the chimney and causes smoke, and the dangerous carbon monoxide in smoke, to spill back into your home where it can kill you.

The proper size chimney is important. Be sure the Listed chimney has an inside diameter of 6". A smaller size chimney will result in poor draft and inefficient operation.

If the chimney has insufficient draft, the draft may be improved by extending the height of the chimney, making certain the chimney is clean and not blocked, checking for overhanging limbs, and reducing the number of elbows in the flue pipe connecting to the chimney.

The top of the chimney should be at least three feet above the point it comes through the roof and at least two feet higher than any part of the roof or house within a ten foot radius. See Figure 11.

A straight up chimney is best because it will draw better. A 15 degree offset, if necessary, is better than a 30 degree offset.

METAL PREFABRICATED CHIMNEY INSTALLATION

There are basically two methods of metal chimney installation. One method is to install the chimney inside the residence through the ceiling and the roof. The other method is to install an exterior chimney that runs up the outside of the residence.

Figure 15 shows how to connect the flue pipe of a rear vented heater to a Listed Factory-Built Residential Type and Building Heating Appliance chimney installed inside the residence through the ceiling and the roof.

Figure 16 shows how to connect the flue pipe of a top vented heater to a Listed Factory-Built Residential Type and Building Heating Appliance chimney installed inside the residence through the ceiling and roof.

Figure 17 shows how to connect the flue pipe of a rear vented heater to an exteriorly installed Listed Factory-Built Residential Type and Building Heating Appliance chimney that runs up the outside of the residence.

Figure 18 shows how to connect the flue pipe of a top vented heater to an exteriorly installed Listed Factory-Built Residential Type and Building Heating Appliance chimney that runs up the outside of the residence.


The components illustrated by figures 15 through 18 may not look exactly like the system you purchase, but they demonstrate the basic components you will need for a proper and safe installation.

REMEMBER: Follow the manufacturer's installation instructions and maintain the manufacturer's specified clearance distances.


FIGURE 15

CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY INSTALLED INSIDE THE RESIDENCE THROUGH THE CEILING AND THE ROOF. ALSO SEE FIGURE 3.

INSTALL AN ATTIC INSULATION SHIELD TO MAINTAIN THE SPECIFIED CLEARANCE TO INSULATION. INSULATION IN THIS AIR SPACE WILL CAUSE A HEAT BUILDUP WHICH MAY IGNITE THE CEILING JOISTS.



MAINTAIN 2 INCH CLEARANCE





THIS METHOD OF INSTALLATION REQUIRES AT A MINIMUM A CEILING SUPPORT PACKAGE, A SECTION OF CHIMNEY, AN INSULATION SHIELD, A ROOF FLASHING, AND A CHIMNEY CAP.

FIGURE 16

CONNECTING THE FLUE PIPE OF A TOP VENTED HEATER TO A LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY INSTALLED INSIDE THE RESIDENCE THROUGH THE CEILING AND THE ROOF. ALSO SEE FIGURE 5.


INSTALL AN ATTIC INSULATION SHIELD TO MAINTAIN THE SPECIFIED CLEARANCE TO INSULATION. INSULATION IN THIS AIR SPACE WILL CAUSE A HEAT BUILDUP WHICH MAY IGNITE THE CEILING JOISTS.




THIS METHOD OF INSTALLATION REQUIRES AT A MINIMUM A CEILING SUPPORT PACKAGE, A CHIMNEY SECTION, AN INSULATION SHIELD, A ROOF FLASHING, AND A CHIMNEY CAP.

CONNECTING THE FLUE PIPE OF A REAR VENTED HEATER TO AN EXTERIORLY INSTALLED LISTED RESIDENTIAL TYPE AND BUILDING HEATING APPLIANCE CHIMNEY THATS RUNS UP THE OUTSIDE OF THE RESIDENCE. ALSO SEE FIGURE 2.

FIGURE 17




MAINTAIN 2 INCH CLEARANCE THROUGH EAVE




CONNECTING THE FLUE PIPE OF A TOP VENTED HEATER TO AN EXTERIORLY INSTALLED LISTED RESIDENTIAL TYPE BUILDING HEATING APPLIANCE CHIMNEY THATS RUNS UP THE OUTSIDE OF THE RESIDENCE. ALSO SEE FIGURE 4.

FIGURE 18



MAINTAIN 2 INCH CLEARANCE THROUGH EAVE



HOW TO USE THE HEATER SAFE OPERATION

IMPORTANT: DO NOT USE THE HEATER UNTIL A PROFESSIONAL INSPECTION HAS BEEN MADE OF THE ENTIRE INSTALLATION BY YOUR LOCAL FIRE DEPARTMENT, FIRE MARSHAL OR BUILDING CODE INSPECTOR. INSTALL A SMOKE DETECTOR ON EACH FLOOR OF YOUR HOME IN CASE OF ACCIDENTAL FIRE FROM ANY CAUSE. IT CAN PROVIDE TIME FOR ESCAPE.

SAFETY REMINDERS

- A correctly installed heater can still pose a fire hazard if it is not used properly.
- Only after the heater is installed properly, attached to an approved chimney in good condition and has been inspected by a qualified person, it is ready for operation.
- Remember not to place any combustibles near the heater. In addition to furniture, rugs and clothing, this includes paper which you might use to start the fire. A hot coal could fall from the heater and cause a fire.
- Never use flammable liquids to start or freshen a fire. Gasoline, kerosene, lantern fuel and other such liquids can explode.
- Don't touch a heater to see if it's hot. Use insulated and fireproof gloves when tending the heater.
- When the heater is operating, children must be closely supervised. Unaware of the potential danger of a hot heater, children may accidentally bump into or touch the heater and be burned.
- Make sure you do not wear loose or flowing garments when tending the heater. Clothing like this could ignite. Be careful that hot coals don't fall on your clothing.
- Open a window to allow fresh air into the room when you use the heater for long periods of time to prevent asphyxiation.
- Do not use this heater as a trash disposal. This can cause dangerous overheating.
- Do not overfire this heater. Overfiring can cause a chimney fire or house fire. Overfiring can also shorten the life of the heater.
- Burn natural wood only in this heater. See the "WOOD FACTS" section of this manual for detailed information. Burning anything other than natural wood in this heater may damage the catalytic combustor.
- The small amounts of wood used for daily fire tending should be kept in a non-combustible container at least 36 inches away from the heater.
- Use only metal containers with tight fitting lids to remove ashes.

WOOD BURNING FACTS

The amount of heat you receive from the heater, the degree of control you have over its heat output, how safely you operate your heater, and how often you have to clean your chimney are all somewhat dependent on how much you know about wood and burning wood. This section is devoted to providing you with a few basic facts about firewood, how to prepare it for use, and how to burn it. For more specific information on how to select and obtain good firewood, write the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. and request a copy of Forest Service Leaflet No. 559.

The two factors that determine the amount of heat you get from a quantity of wood is its density and moisture content. All species of wood when oven dried and burned will produce approximately 8,600 BTU's per pound of wood, but because hardwoods are more dense than soft woods, a piece of hardwood will produce more heat than a piece of soft wood of equal size and moisture content.

Before wood can burn the water trapped in the wood must be boiled away. As anyone who has ever boiled water knows, it takes a considerable amount of heat to boil even a cup of water until it is all boiled away. Because freshly cut green wood or wet wood may be 50% water by weight a considerable amount of the heat produced by burning green or wet wood is consumed by boiling the water out of the wood before it will burn. For this reason, green or wet wood is likely to produce a smoldering smokey fire and chimney temperatures that are cool enough to cause rapid accumulation of creosote. Burning green or wet wood can also waste up to 50% of the heat you should be getting in your home.

To prepare wood for the most economical and trouble free burning, it should be cut, split, and stacked out of the rain with its ends exposed for at least 6 months before it is burned. Wood that has been "seasoned" in this fashion will normally dry naturally until it is approximately 20% water by weight.

When a wood log is laid on a burning fire, several process take place. First as the temperature of the surface of the logs reaches 212 degrees Fahrenheit, water at the surface begins to boil away. Until most of the water is boiled out of the surface of the log, the log is consuming heat and is not producing any heat. After sufficient water is boiled away and the temperature of the logs surface begins to get hotter, hydrocarbon gases begin to flow out of the wood. These gases will burn if they reach a temperature of 900 to 1100 degrees Fahrenheit and there is sufficient oxygen present in the air around them. This is a critical point in the burning of wood because if there is not enough oxygen present or the area around the log is being cooled by nearby logs that are not burning and only using heat to boil away water, these hydrocarbon gases will go up the chimney unburned. This means a significant amount of the wood's heat value is lost and if these gases cool to 250 degrees Fahrenheit before they get out of the chimney they will condense to form **creosote**.

Your Ashley heater has been designed to burn the wood cleanly but it cannot do so unless you add seasoned wood to the fire in reasonable quantities and leave the combustion air opening open enough to assure a supply of oxygen to the fire. You will get the most out of your wood and your heater if you; add small quantities of wood to the fire frequently rather than large quantities infrequently, keep the fire burning at a rate to assure there is adequate heat to boil away the water and burn the gases, and keep enough air flowing through the heater to burn the quantity of gases being released from the wood. **Remember heavy smoke from a fire means poor use of the wood.**

HEATER OPERATION

HOW THIS HEATER OPERATES:

The chimney draft draws combustion air into the heater through an adjustable opening controlled by the inlet air control lever located on the lower front of the heater. (See figure 19). The gases driven out of the burning wood are either drawn through the catalytic combustor or by-pass the combustor through a passageway that may be opened or closed by a by-pass damper control handle that protrudes through the back of the heater. If the by-pass damper is closed and the temperature and oxygen content of the gases is sufficient, the gases driven out of the wood will be consumed as they pass through the combustor. The by-pass damper must be open during the initial start up of a fire. The by-pass damper must be opened prior to opening the fuel feed door to tend a fire or add more wood to a fire. **FAILURE TO OPEN THE BY-PASS DAMPER PRIOR TO OPENING THE FUEL FEED DOOR WILL CAUSE SMOKE OR POSSIBLY FIRE TO SPILL FROM THE HEATER THROUGH THE FUEL FEED DOOR OPENING.**

THE PAINT ON THE EXTERIOR OF THE FIREBOX WILL GO THROUGH A CURING PROCESS DURING THE FIRST FIRING OF THE HEATER AND WILL EMIT SOME SMOKE AND ODOR. BE PREPARED FOR THIS BY RAISING A WINDOW OR OPENING A DOOR TO PROVIDE VENTILATION.

The first time the heater is fired, the fire would be regulated so as to increase intensity gradually to allow the paint to cure slowly and the other components to adjust to their expanded size.

Some residue may accumulate on the heater's glass during the first firing of the heater. This is normal and should diminish during subsequent firings.





FIGURE 19

BLOWER CONTROL KNOB:
TURN CLOCKWISE TO
TURN ON BLOWER.

INLET AIR CONTROL LEVER:
MOVE TO RIGHT TO OPEN. MOVE
TO LEFT TO CLOSE.

BUILDING A FIRE

1. Be sure the room is adequately ventilated and the flue unobstructed before building a fire in the heater.
2. Open the inlet air control by moving the control lever to the right as far as possible.
3. Fully open the by-pass damper by pulling the by-pass damper control rod (the rod which protrudes through the cabinet back of the heater) to its outermost position.
4. Open the heater's fuel feed door and place several wadded grapefruit-size newspaper balls toward the back of the firebox beneath the by-pass damper. Be sure the ash removal door is securely closed.
5. Cover the newspaper balls with dry kindling sticks. Place the kindling sticks close enough to one another so the flames can move easily from one stick to the other. If the kindling is packed too tightly, the fire will suffocate, smoke and then die out. (NOTE: Softwoods make better kindling than hardwoods because the softwoods burn faster than the hardwoods.)
NOTE: If the heater tends to smoke when first lit, a draft may be induced by holding a torch of rolled-up newspaper at the opening of the by-pass damper. Occasionally, this must be done two or three times to establish an updraft. It may also help to open a house door or window slightly.
6. Light the wadded balls of paper in the heater. Leave the fuel feed door slightly ajar (approximately 1 to 2 inches) to allow plenty of oxygen to reach the fire, but DO NOT LEAVE THE HEATER UNATTENDED.
WARNING: NEVER LIGHT OR REKINDLE A HEATER FIRE WITH KEROSENE, GASOLINE, OR CHARCOAL LIGHTER FLUID: RESULTS CAN BE FATAL.
7. Once the original kindling is well lit, add more kindling and 2 or 3 logs about three inches in diameter. Be careful not to smother the fire. Stack the new wood pieces carefully near enough to keep each other hot, but far enough away to allow adequate air flow between them. NEVER LEAVE THE HEATER UNATTENDED WHILE ANY OF ITS DOORS ARE NOT SECURELY CLOSED.



Once the logs begin to burn, securely close the fuel feed door and then the by-pass damper. The by-pass damper is closed when the control rod protruding through the heater's cabinet back is at its innermost position. NOTE: The by-pass damper must be operated manually.

CAUTION: OPERATING THE HEATER WITH THE FUEL FEED DOOR OR THE ASH REMOVAL DOOR OPEN CREATES AN ABNORMAL FIRING CONDITION WHICH CAN OVERHEAT THE HEATER, CHIMNEY AND ADJACENT COMBUSTIBLE MATERIALS. THIS CAN DRASTICALLY SHORTEN THE HEATER'S LIFE, THE CATALYTIC COMBUSTOR'S LIFE, AND VOID THE FACTORY WARRANTIES OF THE HEATER AND ITS COMPONENTS.

9. When all the wood in the firebox is burning well, finish loading the heater in the following sequence:

First - Open the by-pass damper.

Second - Wait about one minute after opening the by-pass damper, then open the fuel feed door.

NOTE: Because the catalytic combustor offers some resistance to the flow of smoke, opening the fuel feed door without first opening the by-pass damper will allow smoke and possibly flames to spill from the heater. ALWAYS OPEN THE BY-PASS DAMPER BEFORE OPENING THE FUEL FEED DOOR AND KEEP IT OPEN WHILE FEEDING WOOD TO THE FIRE. KEEP THE BY-PASS DAMPER CLOSED AT ALL OTHER TIMES FOR MORE EFFICIENT HEATER OPERATION.

Third - Load the firebox with the desired amount of wood.

NOTE: Probably the least understood requirement in maintaining a good fire is that of establishing a good base of coals. Many new heater users hesitate to load enough wood to sustain a fire. A good bed of hot coals will maintain a more even temperature as well as get a new load of wood started burning easily.

Fourth - Securely close the fuel feed door.

Fifth - Close the by-pass damper.

10. Wait about 20 minutes to ensure that the heater, catalytic combustor, and wood are all stabilized at proper operating temperatures, then adjust the inlet air control for the desired heat and burn rate. The proper setting can only be obtained by trial since conditions of fuel, space being heated, individual preference, etc., vary. For most conditions, good results can be obtained by setting the inlet air control lever at its center position. After some experience with the heater, you will learn the best setting for your needs. The more you close the air control, the lower and slower the fire will burn. The more open the inlet air control, the hotter and faster the fire will burn.

Let each load burn down to a good coal bed. Frequent reloading will cause major fluctuations in temperature and wood/air mix, thereby reducing efficiency.

How long a load of wood burns will vary considerably with the variables such as type of wood, how well the wood is seasoned, the inlet air control setting, the position of the heater in the house, and how well the house is insulated.

FIRE TENDING:

Fire tending is the occasional re-positioning of the burning wood to ensure air flow through it and adding new wood as needed. With experience, you should determine how often fire tending is required to maintain the desired heat output of the heater. To ensure safe and satisfactory performance of the heater, the following rules should be observed:

1. KEEP THE ASH AND FEED DOORS CLOSED EXCEPT WHEN TENDING THE FIRE OR REMOVING ASHES. Operating the heater with the doors open can cause the heater to dangerously overheat and increase the possibility of smoke, fire, ash, or sparks escaping the heater and damaging the dwelling or its contents.
2. The following sequence should always be followed when opening the heater's fuel feed door to prevent smoke and possibly fire from spilling out of the heater:
 - a. Fully open the inlet air control.
 - b. Fully open the by-pass damper.
 - c. Wait about one minute, then open the fuel feed door.
3. Never overfill the heater to the point that the by-pass damper is blocked. Overfilling the heater can cause it to overheat, create a fire hazard, and damage the heater.
4. DO NOT OVERFIRE THE HEATER. If the heater or chimney connector glows, you are overfiring the heater. Immediately close any heater door that might be open, completely close the heater's combustion air inlet, (See figure 19). These actions should decrease the fire intensity and allow the heater and chimney connector to cool down. Overfiring can cause a fire hazard and greatly shorten the life of the heater.
5. NEVER LEAVE THE HEATER UNATTENDED FOR LONG PERIODS OF TIME AFTER ADDING FRESH WOOD. Before the heater is left unattended, the fire should be well established and the inlet air control set so the opening is open only half or less.
6. LEAVE THE HEATER'S INLET AIR CONTROL FULLY OPEN FOR 15 MINUTES AFTER ADDING FRESH WOOD TO AN EXISTING FIRE. This allows the gases to be driven off and shortens the length of time the dense smoke is likely to deposit creosote in the chimney connector and chimney.

CATALYTIC COMBUSTOR OPERATING TEMPERATURES:

Achieving Catalytic Light-Off. At least once during each burning cycle, the temperature within the heater should be raised high enough to cause the catalyst to become active. The most convenient time to do this is during fuel loading. With a new combustor, gas inlet temperatures between 500° to 600°F (260° to 320°C) will initiate catalytic burning. But as a combustor ages, its catalytic activity decreases, so an older combustor needs more heat during start-up to sustain catalytic action. During the combustor's normal range of life, temperatures between 600° and 700°F (320° to 370°C) will be sufficient for light-off.

Maintaining Catalytic Burning Conditions. During the start-up of a cold heater, a medium to high firing rate must be maintained for about 20 minutes. This ensures that the heater, catalyst and fuel are all stabilized at proper operating temperatures.

Even though it's possible to have gas temperatures reach 600°F (320°C) within two to three minutes after a fire is started, if a fire is turned down immediately to low fire conditions it will result in either the fire or the combustor going out.

During the refueling of a hot heater that has an internal firebox temperature below 500°F (260°C), we recommend that the stove be fired for about 10 minutes to ensure that the catalyst reaches 600°F (320°C). At the end of a burn cycle, it's possible that a small amount of burning charcoal might not provide sufficient temperatures or fuel for the catalyst. Therefore, firing a new load of wood for 10 minutes ensures sufficient temperatures and proper amounts of volatiles for catalyst operation.

When refueling a hot stove that has an internal firebox temperature above 500°F (260°C), no refiring step is necessary. Just load the fuel and continue to operate. Temperatures within the firebox will be hot enough to support catalytic burning and wood pyrolysis.

The "Glow" Misconception: A catalyst does glow during certain stages of combustion. However, the determination that a catalyst is not working simply because it doesn't "glow" is an inaccurate conclusion. During the low burn cycle, when the catalyst is doing the bulk of its work, it usually does not glow.

ASHES-REMOVAL AND DISPOSAL:

Ashes should not be allowed to accumulate until they obstruct the airflow through the burning wood. If ashes are allowed to accumulate to within two inches of the bottom of the grates, poor burning of the fuel is likely, and the grates will be damaged from overheating.

When removing the ash pan from the heater, wear gloves to protect your hands from glowing embers and hot surfaces. ASHES SHOULD BE PLACED IN A METAL CONTAINER WITH A TIGHT FITTING LID. THE CLOSED CONTAINER OF ASHES SHOULD BE PLACED ON A NONCOMBUSTIBLE FLOOR OR ON THE GROUND, WELL AWAY FROM ALL COMBUSTIBLE MATERIALS, PENDING FINAL DISPOSAL. IF THE ASHES ARE DISPOSED OF BY BURIAL IN SOIL OR OTHERWISE LOCALLY DISPERSED, THEY SHOULD BE RETAINED IN THE CLOSED CONTAINER UNTIL ALL CINDERS HAVE THOROUGHLY COOLED.

Ashes should never be placed in wooden or plastic containers, or in paper or plastic bags, no matter how long the fire has been out. Coals have been known to stay hot for several days when embedded in ashes.

BLOWER OPERATION

The heater is equipped with a variable speed manual blower. Use the blower control knob located on the heater's lower righthand corner (see figure 19) to turn the blower on and set the blower speed as desired, or to turn the blower off. To begin we recommend setting the blower speed proportional to the air inlet setting, later the blower can be set as experience dictates. (Figure 20 provides a schematic wiring diagram of the blower.




FIGURE 20

SECTION 4 HOW TO TAKE CARE OF YOUR HEATER AND CHIMNEY SAFE MAINTENANCE

CREOSOTE FORMATION AND REMOVAL, CHIMNEY FIRE, CHIMNEY MAINTENANCE

When wood is burned slowly, it produces tar and other organic vapors which combine with expelled moisture to form creosote. The creosote vapors condense in the relatively cool chimney flue of a slow-burning fire. As a result, creosote residue accumulates on the flue lining. When ignited, this creosote makes an extremely hot fire.

The flue pipe and chimney should be checked at least twice monthly during the heating season to determine if creosote buildup has occurred. Cooler surfaces tend to build creosote deposits quicker, so it is important to check the chimney from the top. If creosote has accumulated, the flue pipe and chimney should be cleaned to reduce the risk of a chimney fire.

A chimney fire is usually indicated by a roaring noise within the chimney and/or a pinging noise within the chimney connector, and the emission of sparks and ash from the top of the chimney.

Should a chimney fire occur, immediately close any heater door that might be open, completely close the heater's combustion air inlet, (see figure 19). Get everyone out of the house and call the fire department. Protect the roof by wetting it with a garden hose or buckets of water.

A chimney fire may cause structural damage to the chimney. After the chimney fire is over, thoroughly inspect the chimney, chimney connector and surrounding materials for damage and make any necessary repairs before using the heater again. Most fire departments make free chimney inspections and can provide assistance in locating chimney cleaning or repair services.

Inspect the chimney and chimney connector pipes at least twice monthly for any signs of deterioration or creosote accumulation. To assure continued safety of your venting system, you should have the entire system cleaned and inspected by a competent chimney sweep at least once a year, preferably before the beginning of each new heating season.

ICE-FORMATION AND PREVENTION

Most of what you see coming from the chimney of a properly operating catalytic heater is water vapor. In extremely cold weather, and with some exterior chimneys, this vapor may freeze in the chimney to the point of actually blocking the chimney and extinguishing the fire. In such weather, occasionally burn the heater with the by-pass open and the inlet draft control set to its most open position to melt any possible ice buildup.

HEATER MAINTENANCE

The painted surfaces of the heater may be wiped free of dust with a soft cloth. The use of any other cleaning method may damage or remove the paint.

The brass finished trim components on the heater are coated with a clear baked-on enamel to prevent tarnishing. DO NOT polish the brass finished trim components. When cleaning is necessary, use mild soap suds and a soft cloth. After washing, dry the trim surfaces with a clean, dry, soft cloth.

This heater is equipped with a high temperature resistant glass panel. The glass may be cleaned when it is cool with a household glass cleaner. Take care to avoid chipping or scratching the glass. Chipped or scratched glass can break suddenly when heated. Do not use the heater with a broken glass panel.

The electrical power to the blower should be disconnected and the blower vacuumed or blown free of all lint, dust and ashes frequently. The motor is permanently lubricated and does not require oiling. The electrical cord should be inspected frequently and replaced if evidence of wear or damage is observed. Replace the cord only with the cord specified in the repair parts section of this manual.

Because continuous thermal self-cleaning action takes place within a catalytic combustor, it requires very little maintenance. Cleaning the catalyst with plain water can reduce buildup of the catalyst-retarding chemicals. Nothing but a soft fiber brush, low pressured air or plain water should be used to clean a catalyst. For information on how to remove the catalyst refer to the following section of this manual. The ceramic unit is fragile and it should be handled with care. A soak in warm or hot (not boiling) water for 20 minutes is ideal. Then allow the catalyst to cool at room temperature and rinse at medium pressure under a faucet. Allow the catalyst to dry before reinstalling in the heater. A cleaning once every year is sufficient for most. Clean it when you have your flue system cleaned or whenever and if ever it becomes plugged up.

Check the following items regularly during the heating season to ensure proper heater operation:

1. Condition of fuel feed door and ash removal door gaskets - replace gaskets if excessive wear is observed.
2. Condition of fuel feed door, ash removal door and cabinet door latching pawls and handles - ensure that operation of the latching pawls and handles will securely close the doors. Adjust as necessary.

At the end of each heating season, the heater should be thoroughly cleaned of all ashes. Ashes remaining in the heater in combination with moisture in the air can cause severe corrosion of the heater. All rust spots on the heater should be wire brushed and covered with a coat of high temperature paint. If the heater is to be stored until the next heating season, be sure the storage area is dry. The heater should never be used with damaged or missing parts.

Have a qualified heater installer inspect the complete system before cold weather each year. Make sure soot is removed. Replace all damaged or worn parts before using the heater.

WHEN AND HOW TO REPLACE THE CATALYTIC COMBUSTOR(S)

Tests conducted on actual wood heater installations indicate that the average expected operational life of a quality catalytic combustor is about 6000 operating hours. Remember, these are average test figures; actual combustor life of your heater's catalyst may be more or less, depending on operation procedures and normal care.

Whenever a catalytic combustor stops functioning, it should be replaced as soon as possible, or at least removed from the heater.

This heater employs two catalytic combustors. Indications that a combustor has stopped functioning and needs replacing are:

1. Sluggish heater operation.
2. Increased wood usage.
3. Increased build-up of creosote in the flue liner.

A simple test will determine if the catalytic combustor is functioning. To perform this test you should take note of the smoke exiting the chimney with a well established fire burning in the heater and the by-pass damper open. Then close the by-pass damper and observe the smoke exiting the chimney. If the catalytic combustor is functioning there should be a noticeable decrease in the amount of smoke exiting the chimney ten minutes after the by-pass damper is closed.

If you suspect that your heater needs new combustors, discuss the problem with your catalytic heater dealer, you may only need to clean the old combustors and change some operating habits.

When you do have to replace the combustors or just remove them for cleaning, here's how it's done:

1. Allow any fire in the heater to burn out and the heater to cool.
2. The combustors in this heater are both located inside the heater's firebox and can only be removed or replaced through the large round hole located in the top of the firebox. To remove or replace one or both of the combustors requires that the large round hole be uncovered. The hole is covered by the firebox cover plate (Key no. 8 on Figure 6). However, the same hole will be covered by the flue collar if you have converted the heater into a top vented model as described in the "REAR VENTED HEATER OR TOP VENTED HEATER?" section of this manual. Remove the hole's cover and gasket by removing the eight screws securing them to the firebox top. Care should be taken not to damage the gasket.
3. Reach into the hole and remove the combustor(s). The combustor(s) are encased by insulating material, but should come out without leaving any residue.
4. Inspect for residue where the combustors were sitting (commonly referred to as the combustor seat) inside the firebox. Wipe clean with a dry cloth. DO NOT USE DETERGENTS, STEEL OR METALLIC BRUSHES OR SOLVENTS.
5. Wrap the combustors with new insulating materials. Do not handle the new combustors any more than necessary for installation. Catalytic combustors are fragile.
6. Install the newly wrapped combustors. The new insulating material which encase the new combustors will form a tight seal between the combustors and the combustor seat when heated.

NOTE: When a catalytic combustor is removed from the heater, the insulating material forming the seal between the combustor and the combustor seat MUST be replaced. You may purchase the catalytic insulating material from your catalytic heater dealer.

7. Reinstall the gasket and cover over the hole in the firebox top. Care should be taken to ensure an airtight seal.
8. Reinstall any other heater parts which were removed to gain access to the combustors.

CATALYTIC COMBUSTOR PLUGGING

Plugging of the combustor usually happens when the heater operator attempts to burn materials that produce large flakes of char, such as Christmas wrapping paper and cardboard. This can plug enough cells in the combustor to cause a smoke spillage problem. To help avoid combustor plugging, burn natural wood only and keep the combustors clean.

SECTION 5

TROUBLE SHOOTING, FINAL CHECKLIST, REPAIRS, WARRANTY

THE VENTING SYSTEM-KEY TO GOOD HEATER PERFORMANCE

A majority of performance problems with wood burning heaters can be traced to some factor in the venting system that is adversely affecting the heater. Air will flow into the heater and smoke will flow up the chimney only if there is sufficient difference between the air pressure in the room where the heater is located and the air pressure inside the chimney. As hot gases and smoke flow up a chimney the pressure in the chimney is lowered creating a difference in pressure inside and outside the chimney. When this pressure difference, often referred to as "draft pressure" or simply as "draft", is sufficient, air will be forced into the combustion air openings of the heater. This air supplies the oxygen necessary for the wood to burn. If the draft is not sufficient, insufficient oxygen will reach the burning wood and it will burn poorly. This condition can also cause smoke and dangerous gases to spill or backpuff from the heater into the room. Backpuffing occurs when the air flow through the heater is insufficient to burn all the gases being released by the wood causing them to build up until they ignite as a minor explosion. This causes smoke to puff out of every opening in the heater and venting system.

Remember the heater cannot create draft. Only a proper leak free chimney can create the necessary draft.

WHAT TO DO IF YOUR HEATER SMOKES OR BURNS POORLY OR EXCESSIVE CREOSOTE ACCUMULATES IN THE CHIMNEY

Note: Read the preceding section titled "THE VENTING SYSTEM-KEY TO GOOD HEATER PERFORMANCE".

1. Check the catalytic combustor for damage or functional failure.
2. Examine your method of building and tending the fire in your heater. If you close the bypass damper too soon when building a fire, fail to open it before opening the feed door, add too much fresh wood at each refueling, or attempt to operate the heater at too low a combustion rate for the amount of wood present in the firebox, your failure to follow proper practices may be causing the problem.
3. Check the pipes connecting the heater to the chimney for loose or unsealed joints that may allow air to leak into the chimney system.
4. Check the chimney for cracks or holes that might allow air to leak into the chimney. If the chimney is equipped with an ash clean out, be sure the door is closed and fits tightly. The door may have to be temporarily sealed with tape or furnace cement to be as air tight as required. An excellent way to check an exterior chimney for leaks is to perform a smoke test by building a small wood fire in the heater, adding a small amount of wood to the fire to make it smoke heavily, momentarily blocking the top of the chimney, and watching for smoke to leak out of any opening or cracks.
5. Check the entire venting system for obstructions that could be causing resistance to the flow of smoke and gases up the chimney.
6. Check the height of the chimney. A chimney that is too short will not develop sufficient draft or will allow wind to interfere with the draft.
7. Check the size of the flue. If the flue is smaller than 6 inches round or 8 inches square it will be too restrictive to the flow of smoke and gases. A flue that is larger than 8 inches round or square may be large enough to allow excessive cooling of the gases in the chimney. If the chimney is too large it may be improved by restricting the top opening of the flue to a 6 inch round opening or in more extreme cases the chimney may have to be relined with a smaller lining.
8. Open a window slightly to see if the conditions improve. If opening a window improved the performance of the heater or stops the spillage of smoke into the room the problem is caused by a slight vacuum in the room. The vacuum can be the result of the room being so tightly constructed that the air removed from the room by the heater is not replaced by normal infiltration of air from outside the room.
The vacuum can also be caused by the loss of air from the room through kitchen or bathroom ventilating fans, other chimneys or vents etc. The only solution to this type problem is to reduce the air lost from the room or provide a source for air to enter the room.
9. If all the above steps are taken and the cause of the problem is not identified, a draft pressure reading should be taken with a draft meter or manometer. This requires someone with the proper equipment and the knowledge of how to use it. Your Ashley dealer should be able to perform this task for you or recommend someone who can.

WHAT TO DO IF YOUR HEATER BURNS TOO RAPIDLY OR OVERHEATS

Note: Read the preceding section titled "THE VENTING SYSTEM-KEY TO GOOD HEATER PERFORMANCE".

If your heater overheats or burns too rapidly only on moderately cool days this may be caused by you placing too much wood in the heater for the amount of heat required to heat your home. Although the combustion air controls on the heater are intended

to control the burning rate of the wood, a certain amount of air must enter the heater at all times to assure the fire does not go out and the wood burns as cleanly as possible. Thus you should adjust the amount of wood you put in the heater to the outdoor temperature. Placing excessive wood in the firebox will cause excessive creosote formation in the chimney, waste wood, can plug up the catalytic combustion causing the heater to smoke or back puff into the room, as well as make the room uncomfortably warm.

If your heater burns too rapidly or overheats even on cold days, it may be because air is leaking around a loose ash door or feed door gasket. Check thoroughly for leaks where air may enter the heater at any location other than the normal air passages of the heater.

DO NOT USE A MANUAL STOVE PIPE DAMPER IN THE CHIMNEY CONNECTOR PIPES. USE OF THIS TYPE DAMPER CAN CAUSE DANGEROUS GASES TO COLLECT IN THE HEATER OR SPILL OUT INTO THE ROOM.

FINAL CHECKLIST OF DO'S AND DONT'S

DO'S:

1. Do read and follow the installation, operation and maintenance manual carefully.
2. Do install a smoke detector in an area that will give warning in the unlikely event that a fire develops in the area of the heater or the heater malfunctions.
3. Do be sure that there is a fire extinguisher of the proper type and good working order accessible in the unlikely event that a fire develops near the heater or the heater malfunctions.
4. Do check with local building officials to be sure the installation of the heater complies with all building codes and requirements and obtain required building permits.
5. Do plan your installation with safety as your primary consideration.
6. Do keep all flammable liquids, gases and pressurized containers away from the heater.
7. Do complete the installation before attempting to use the heater.
8. Do use only the prescribed materials and parts for the installation of the heater.
9. Do install the heater in an area that will minimize the hazards of persons coming in contact with the hot surfaces of the heater.
10. Do instruct all responsible persons in the proper and safe operation of the heater.
11. Do instruct all persons, especially children and elderly persons, of the hazards involved with the heater and improper and unauthorized tampering with the heater.
12. Do check the heater for proper adjustment and operation before leaving it unattended for long periods of time.
13. Do start a fire only with paper and kindling. The use of liquid fire starters can cause an explosion within the heater.
14. Do use only a Listed Factory-Built Residential Type and Building Heating appliance chimney or a properly constructed and maintained masonry chimney to vent this heater.
15. Do use 6-inch diameter chimney connector pipes made from a minimum of 24 gauge cold rolled steel.
16. Do place all ashes in a metal container with a tight fitting lid and place them on a noncombustible surface well away from other combustible materials until they have completely cooled.
17. Do check the door latching mechanisms and gaskets regularly and replace parts or make adjustments as needed to maintain the intended tightness of the fire chamber.
18. Do use a noncombustible floor covering beneath the heater as required.
19. Do observe all instructions regarding clearance between the appliance, chimney connector and combustibles.
20. Do store your fuel supply at least 36 inches from the heater.
21. Do burn only seasoned wood in this heater.
22. Do be sure the heater is located in an area where combustible vapors are not present.
23. Do use a chimney for this heater that is not used by another appliance.
24. Do assemble the chimney connector so that moisture that accumulates within the chimney will flow back toward the heater.
25. Do remove the ashes from the heater regularly.
26. Do store wood in such a manner as to keep it dry.
27. Do protect your hands with noncombustible gloves when loading the heater, removing ashes, etc.
28. Do keep the heater doors closed except when refueling the heater or removing ashes.
29. Do build fires of moderate intensity in the heater for the first three fires to allow the materials to adjust and cure before being subjected to the intense heat of a large fire.
30. Do leave the heater's primary and secondary inlet air controls fully open for 15 minutes after adding fresh fuel to an existing fire.
31. Do keep the catalytic combustors clean.

DON'TS:


1. Don't dry clothing or other articles on or near the heater.
2. Don't store or place flammable liquids, gases or pressurized containers near the heater.
3. Don't use gasoline, kerosene, engine oil, charcoal lighter or other flammable liquids to start or intensify a fire. Using these and other similar materials can cause an explosion within the heater.
4. Don't use an unlisted, type B, or poorly constructed or maintained chimney to vent this heater.
5. Don't use galvanized pipe, steel pipe less than 24 gauge, or pipe of a diameter smaller than 6 inches as a chimney connector.
6. Don't store ashes in combustible containers, nor store them near combustible materials, nor dispose of them until they have completely cooled.
7. Don't neglect to inspect regularly and maintain door gaskets and latching mechanisms to assure the intended tightness of the fire chamber.
8. Don't install the heater or chimney connector at clearances to combustibles less than those recommended in this manual.
9. Don't install the heater where flammable or explosive liquids or vapors are likely to be present.
10. Don't install this heater in a chimney flue that is used by another appliance.
11. Don't neglect to clean and inspect your chimney regularly.
12. Don't operate the heater with its door open.
13. Don't neglect to keep the catalytic combustors clean.

Mountain View Hearth Products
manuals.stove-parts-unlimited.com

ORDER ALL REPAIR PARTS FROM YOUR ASHLEY DEALER
 BY SUPPLYING THE FOLLOWING INFORMATION:

1. PART NAME
2. PART NUMBER (Not Key No.)
3. MODEL NUMBER

FIGURE 21



KEY NO.	PART NAME	QTY.	AHS1 PART NO.	AHS1B PART NO.
1	Top, Frame Assy. Ptd.	1	035121	035132
2	Plate, Cover Ptd.	1	035176	035176
3	Gasket	2	035177	035177
4	Rail, Mounting Assy. Ptd.	4	035125	035136
5	Collar, Flue Reamed	1	035175	035175
6	Cover, Plate Rear Cab. Ptd.	1	035836	035838
7	Screw, 8 x 1/2	2	*	*
8	Handle, Spring	1	025516	025516
9	Corner, Cabinet Ptd.	2	035126	035137
10	Rear, Cabinet Ptd.	1	035828	035830
11	Top, Louvered (Lt. & Rt.) Pt.	2	035131	035142
12	Top, Center Louvered Ptd.	1	035130	035141
13	Top, Louvered Ctr. (w/hole)	1	035268	035266
14	Trim, Brass (30-3/4 Long)	2	032413	032413
15	Trim, Brass (14-5/8 Long)	2	032414	032414
16	Key, Corner	4	024034	024034
17	Screw, Set 8-32 x 1/8 Sit.	8	024035	024035
18	Side, Left Cabinet Ptd.	1	035128	035139
19	Gasket, Glass	1	035179	035179
20	Glass	1	033971	033971
21	Frame, Glass & Brass Assy.	1	035178	035178
22	Corner, Cab. & Brass Assy.	2	035190	035195
23	Side, Cabinet Front Ptd.	2	035122	035133
24	Top, Cabinet Front Ptd.	1	035124	035135
25	Bottom, Cabinet Front Ptd.	1	035123	035134
26	Trim, Brass (26-7/8 Long)	1	032418	032418
27	Louver, Grille Assy.	1	035967	035967
28	Knob	1	011656	011656
29	Control, Speed Adjusted	1	035262	035262
30	Housing, Wiring Assy. Ptd.	1	035073	035073
31	Leveler, Leg	4	016343	016343
32	Pedestal Assy. Ptd.	1	035408	035408
33	Pad	1	035968	035968
34	Blower Assy.	1	035165	035165
35	Insulation	1	035183	035183
36	Connector & Wire Assy.	1	035184	035184
37	Insulation	1	035181	035181
38	Shroud, Blower Ptd.	1	035075	035075
39	Cordset/Coverplate Assy.	1	025994	025994
40	Pan, Ash Assy.	1	034290	034290
41	Door (Feed) & Handle Assy. (See Fig. 22 For Components)	1	035401	035401
42	Pin	4	P626	P626
43	Door, Cabinet Assy. Ptd.	1	035127	035138
44	Knob & Latch Kit	1	035403	035403
45	Curtain, Smoke Ptd.	1	035144	035144
46	Rod, Stove Kit	1	035409	035409
47	Handle, 3/4 Dia. Ball	1	019848	019848
48	Handle, Airwash Slide Ptd.	1	035410	035410
49	Spacer	2	P5138	P5138
50	Slide, Air	1	032210	032210
51	Curtain, Smoke & Fasteners	1	035411	035411
52	Logo & Fasteners Kit	1	035412	035412
53	Pipe, Last Joint Ptd. Assy.	1	004302	004302
54	Housing, Air Slide	1	032209	032209
55	Retainer, Ash Ptd.	1	035413	035413
56	Door (Ash) & Handle Assy. (See Fig. 23 For Components)	1	035399	035399
57	Grate, Large	2	035308	035308
58	Grate, Small	1	035309	035309
59	Shield, Flame Impingement	1	035072	035072
60	Combustor & Wrap Kit	2	035415	035415
61	Wrap for Combustor	2	035416	035416
62	Probe Thermometer	1	036049	036049
65	Adapter Flue Outlet Ptd.	1	035829	035831
66	Label Lo/Hi	1	035552	035552
67	Trim Corner	4	035846	035846
	* Purchase Locally			

25 - S 30 3/4" L.

40 - S

15 - S


P.O.
22491
7-26-89

View Hearth Products
manuals.stove-parts-unlimited.com

ORDER ALL REPAIR PARTS FROM YOUR ASHLEY DEALER BY SUPPLYING THE FOLLOWING INFORMATION:

1. PART NAME 2. PART NUMBER (Not Key No.) 3. MODEL NUMBER

FIGURE 22




KEY NO.	PART NAME	QTY. Per Unit	PART. NUMBER
1	Handle Assy.	1	015905
2	Door Feed & Rope Assy.	1	035400
3	Rope Fiberglass	1	009535-03
4	Shield Door Radiation Ptd.	1	035402
5	Screw 1/4 x 1/2 Long Mach.	4	*
6	Latch & Latch Fasteners	1	035395
	* Purchase Locally		

NOTE: The complete feed door assembly may be ordered by using part number 035401 or individual components may be ordered as described above.

ORDER ALL REPAIR PARTS FROM YOUR ASHLEY DEALER BY SUPPLYING THE FOLLOWING INFORMATION:

1. PART NAME 2. PART NUMBER (Not Key No.) 3. MODEL NUMBER

FIGURE 23



KEY NO.	PART NAME	QTY. Per Unit	PART. NUMBER
1	Handle Assy.	1	015905
2	Door Ash & Rope Assy.	1	035756
3	Rope Fiberglass	1	012053-01
4	Latch & Latch Fasteners	1	035395

NOTE: The complete ash door assembly may be ordered by using part number 035399 or individual components may be ordered as described above.

LIMITED 10 YEAR WARRANTY ASHLEY HEATERS

MODELS AHS1, AHS1B, NCAHS1, NCAHS1B, CHS1 & CHS1B

Manufactured by the Ashley Heater Company, a division of Martin Industries, Inc., P.O. Box 128, Florence, Alabama 35631.

WHAT IS COVERED AND FOR HOW LONG

For five years after this heater is purchased for residential use, the Ashley Heater Co. will make available to the original purchaser, at our factory, a free replacement for any defective part of this heater except parts of the blower which are warranted for one year, the catalytic combustor (if the heater is equipped with a catalytic combustor) which is warranted separately by the combustor manufacturer, and the parts listed below as not covered.

During the 6th through 10th years after this heater is first purchased for use, the Ashley Heater Company will make available to the original purchaser, at our factory, a replacement for any defective part, except blower parts, the catalytic combustor and parts listed below as not covered, at the cost indicated by the following schedule:

IF DEFECT IS REPORTED DURING THIS PERIOD OF USE

6th year
7th year
8th year
9th year
10th year

THE COST TO THE PURCHASER WILL BE:

50% of last list parts price
60% of last list parts price
70% of last list parts price
80% of last list parts price
90% of last list parts price

WHAT IS NOT COVERED

- Glass parts.
- Door gaskets.
- Brick linings.
- Removal and re-installation costs.
- Labor costs for replacement or repairs.
- Transportation or shipping cost.
- The cost of a service call to diagnose trouble.
- Painted surfaces.
- Brass colored surfaces.
- Damage or defect caused by improper installation, accident, misuse, abuse, or alteration.

LIMITATIONS AND EXCLUSIONS

1. No one has authority to add to or vary this limited warranty, or to create for the Ashley Heater Company any other obligation or liability in connection with this heater.
2. ANY IMPLIED WARRANTY APPLICABLE TO THIS HEATER IS LIMITED IN DURATION TO THE SAME PERIOD OF TIME AS THIS WRITTEN WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
3. THE ASHLEY HEATER COMPANY SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, SPECIAL, OR CONTINGENT DAMAGES YOU MIGHT SUFFER AS A RESULT OF ITS BREACH OF THIS WRITTEN WARRANTY OR ANY IMPLIED WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
4. This warranty applies only to the original purchaser and may not be transferred.
5. This warranty applies only to a heater sold and used in the United States.
6. Parts replaced under the terms of this warranty are warranted for the remaining period of the original part warranty.

YOUR DUTIES

- This heater must be installed and operated in accordance with local codes and the instructions furnished with it.
- You should keep an invoice, cancelled check, or payment record to verify the purchase date.

(Continued)

IF YOU HAVE A PROBLEM WITH YOUR HEATER

1. Contact or take it to the nearest Ashley dealer. If you cannot locate your Ashley dealer, call or write the Ashley Heater Company Customer Service Department as indicated below.
2. If you do not receive satisfactory service from the dealer within a reasonable time, write the Ashley Heater Company Customer Service Department and include the date you purchased your heater, its serial number, and details of the problem you are having.

Customer Service Department, Ashley Heater Company, Post Office Box 128, Florence, Alabama 35631, Telephone: 205-767-0330.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



FROM
UNITED STATES STOVE COMPANY

P.O. BOX 151 • 227 INDUSTRIAL PARK ROAD
SOUTH PITTSBURG, TN 37380-0151

phone -

1.800.750.2723

RETURN POSTAGE GUARANTEED