



Thermometer Installation Instructions



Important: The Jack Daniel's Edition Oval XL 400 and Oval XL 400 grills include an outer stainless steel bezel for the thermometer. All other Primo grill models include the thermometer only.

Tools Needed

- 3/8" Masonry Drill Bit
- Electric Drill or Impact Driver
- Large Cloth or Bath Towel

Instructions

1. Remove the existing thermometer and place a large cloth over the cooking grates to catch any residual ceramic material while drilling.
2. Align the drill bit at the same angle as the existing hole. At a slow speed with moderate pressure begin to drill out the hole until you are past the ceramic glaze. Continue and use light pressure until the new hole is complete. *Light pressure should be used to reduce the chance of chipping off a piece of the ceramic material inside the dome.*
3. Remove the wing nut and washer from the back of the thermometer.
4. Insert the probe of the thermometer into the hole in the dome.
5. Place the washer, then the wing nut onto the probe. Tighten the wing nut until snug. **DO NOT** overtighten. Remove the cloth and dispose of any residue.

Calibration: This thermometer may be calibrated by adjusting the slot that is located at the end of the probe. Calibration is set at the factory. There are minor differences in boiling points depending on your elevation, but the variances are minor. There are many resources online including YouTube.com that provide the details for calibrating a thermometer.