

QUADRA-FIRE®

TOP VENT ADAPTER INSTALLATION INSTRUCTIONS CONTOUR, CASTILE, SANTA FE, CB1200 & MT VERNON PELLET STOVES

3-3 Top Vent Adapter

Contour: Part 811-0860
Castile & Santa Fe: Part TPVNT-2
CB1200: Part TPVNT-1
Mt. Vernon: Part 7005-027

3-6 Offset Adapter

All Stoves: Part 812-3570

Kit Contents: Top Vent Adapter, drill bit #26, (6) screws.

Tools Required: Power drill, Phillips head screwdriver; high temperature silicone

1. Put a layer of silicone on the 3 inch (7.6cm) rear exhaust outlet.
2. Slide the Top Vent Adapter onto the rear exhaust outlet.
3. Adjust the assembly to a vertical position.
1200: Slide the outer shield up or down to align evenly with the top of stove. Tighten the adjusting screws when the shield is in the proper position.
4. Drill 4 holes with #26 drill bit (provided) into the back of the stove using the outer shield on the Top Vent Adapter as a pattern (make sure the assembly is vertical).
5. Install the 4 mounting screws.
6. Drill 2 holes with #26 drill bit through the Rear Exhaust Outlet using the 2 holes already in the short horizontal pipe in the Top Vent Adapter as a guide. Install the 2 screws.
7. Install the stove pipe into the Top Vent Adapter (be sure to silicone all joints).
8. To clean the Top Vent Adapter, remove the clean-out cover.

1200: To clean adapter, open the hinged clean-out cover.

1200 Pellet Stove

