



Keeping the shaker weldment pointed towards the bottom of the stove. Place a thin shim (about 0.01") on the shaker block and place on the shaker handle mount, align edges of the shaker block and shaker handle mount and plug weld the block to the shaft.

Sand the handle mount where you welded.

Make sure the shaker spins freely.

