

Technical Service Document for the installation of Extended Smoke Shields

These smoke shields have been tested for use with specific Hearth & Home Technologies Inc. fireplaces. Check with your local building code agency before you begin installation to ensure compliance with local codes, including the need for permits and follow-up inspections. If you encounter any problems regarding code approvals, or if you need clarification of any of the instructions contained here, contact your Hearth & Home Technologies Inc. dealer. For the dealer nearest you, please visit www.hearthnhome.com.

Note: An arrow (➡) found in the text signifies change in content.

CAUTION! Risk of Cuts, Abrasions or Flying Debris. Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

- Remove the screws holding the smoke shield on the fireplace. (If doors are installed they must be removed and some fireplaces require the screens to be removed also.)
- If the U.L. label is on the existing smoke shield it must be removed using a 1/8 in. drill bit to drill out the rivets.
- Screw the U.L. label to the new smoke shield in holes provided. If holes are not there then lay the label on the new smoke shield in about the same location as it was on the old one and drill 1/8 in. holes and screw it on.
- Install the new smoke shield. Seal ends of the smoke shield with high temp sealant around the sides/top of the side refractory.
- Replace the screens and doors.