

Models:
SRV433DRGASKET



These rope kits have been tested for use with specific Hearth & Home Technologies products. Check with your local building code agency before you begin installation to ensure compliance with local codes, including the need for permits and follow-up inspections. If you encounter any problems regarding code approvals, or if you need clarification of any of the instructions contained here, contact your Hearth & Home Technologies dealer. For the dealer nearest you, please visit www.hearthnhome.com.

WARNING



HOT SURFACES!

Screen/mesh, glass doors and other surfaces are hot during operation AND cool down.

Hot screen/mesh and glass doors will cause burns.

- Do not touch screen/mesh or glass doors until cooled
- NEVER allow children to touch screen/mesh or glass doors
- Keep children away
- CAREFULLY SUPERVISE children in same room as fireplace.
- Alert children and adults to hazards of high temperatures.

High temperatures may ignite clothing or other flammable materials.

- Keep clothing, furniture, draperies and other flammable materials away.

CAUTION! Risk of Cuts/Abrasions. Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

Replace Braided Gaskets

1. Remove the stove doors, if possible, and lay them on a piece of cardboard on a table. Pull the old gasket out of the gasket groove in the doors. Scrape any bits of old gasket and adhesive out of the grooves with the blade of a flat screwdriver. Scour the grooves clean with coarse steel wool.
2. Lay gasket in grooves to trial fit.
Note: Gasket may have to be stretched or bunched **slightly** to fit the doors.
3. Remove gasket.
4. Apply a bead of stove gasket adhesive 1/2 in. wide along the entire length of the gasket grooves.
5. Press the new gasket into the grooves so it makes good contact with the adhesive. Start midway along one of the long, straight parts of the groove. Be sure the gasket is firmly cemented at the corners. When you get back to the starting point, butt the taped ends each other so they form a good seal.
6. Remount the doors. Close the doors and test the seal with a piece of paper. You should feel resistance when you try to pull the paper out. Allow the gasket adhesive to dry for 24 hours before using the fireplace.