



Remove the screws from the louvers

Apply the Rope Gasket on the bottom ledge
against the front lip of the stove.