

## Door and Glass Gasket Replacement Instructions

for all Jøtul Gasket Kits

**Contents:**

- 3/8" Round Gasket
- 1/4" Round Gasket
- 1/4" Round Gasket (Self-adhesive)
- 3/16" Round Gasket (Self-adhesive)
- 1/8" x 5/16" Flat Gasket (Self-adhesive)
- Gasket Cement

**Tools Required:**

- Wire Brush
- Scraper
- Work Gloves
- Safety Goggles
- Scissors or Utility Knife

Please read these instructions before beginning the installation procedures.

1. Remove door(s) from the stove.
2. Place doors on a work surface. Place cardboard or a drop cloth on the work surface to avoid damaging the door's finish.
3. Remove Glass Clips and Glass, if required. Note the orientation of the glass. Some stove models have a coated glass that must be reinstalled with the same face on the outside. Look for the imprint, "THIS SIDE OUT".
4. Scrape and brush the old gasket and cement from the door(s). For best results, remove *all* of the old cement.
5. Select the gasket(s) required for your stove model from the chart on the reverse side of this sheet. Lengths noted are approximate. Trim gasket as appropriate for the application.
6. Cut the tip 3/16" from the top of the cement bottle. CAUTION: Skin and eye irritant. Use gloves and eye protection when using gasket cement. (Note: Cement is not necessary for self-adhesive gaskets.)
7. Run a 3/16" bead of cement in the gasket channel. Keep the bead modest - no more than 3/16" for the largest diameter gasket.
8. Starting in the middle of one side, place gasket in the channel. DO NOT STRETCH THE GASKET MATERIAL WHEN HANDLING. Trim excess to form a clean butt joint at the ends. Depending upon the application, the ends will either butt together or be secured under a glass clip. Once the gasket is in place, use your fingertips to push the material down to ensure that it is uniformly seated within the channel.
9. Allow the cement to air cure for at least 30 minutes.
10. Replace the glass clip gasket, if required, with 1/8" x 5/16" flat, self-adhesive gasket.
11. Reinstall the glass, glass clips, and doors.



Application	Part Number	Size	Approximate Length
<b>F 600 Firelight</b>			
Ash Door Gasket	200024	1/4 in.	3 ft. 9 in.
Door Gasket, Center	200024	1/4 in.	1 ft. 6 in.
Door Gasket (both)	100038	3/8 in.	7 ft.
Side Door Gasket	100038	3/8 in.	5 ft.
Glass Gasket (each)	129644	1/4 in. self-adhesive	3 ft. 6 in.
<b>F 500 Oslo</b>			
Ash Door Gasket	200024	1/4 in.	4 ft.
Door Gasket	100038	3/8 in.	6 ft.
Side Door Gasket	100038	3/8 in.	4 ft. 6 in.
Glass Gasket	100038	3/8 in.	5 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft. 4 in.
<b>F 400 Castine</b>			
Ash Door Gasket	100038	3/8 in.	3 ft. 6 in.
Single Door Gasket	100038	3/8 in.	6 ft.
Left Door	100038	3/8 in.	3 ft.
Right Door	100038	3/8 in.	4 ft.
Single Door Glass Gasket	129644	1/4 in. self-adhesive	5 ft.
Glass, Left Door	200028	3/16 in.	3 ft.
Glass, Right Door	200028	3/16 in.	3 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	8 in.
<b>F 118 CB Black Bear</b>			
Door Gasket	100038	3/8 in.	3 ft.
Glass Gasket	200028	3/16 in.	2 ft.
Glass Clip Gasket	127215	1/8 in. x 1/4 in. flat	1 ft.
<b>F 3 CB</b>			
Door Gasket	100038	3/8 in.	5 ft.
Ash Door Gasket	200024	1/4 in.	2 ft. 6 in.
Glass Gasket	200024	1/4 in.	3 ft. 6 in.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft.
<b>F 100 Nordic</b>			
Door Gasket	100038	3/8 in.	5 ft. 6 in.
Glass Gasket	200024	1/4 in.	5 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	8 in.
<b>F 602 CB</b>			
Door Gasket	200024	1/4 in.	3 ft.
Glass Gasket	200028	3/16 in.	2 ft.
Glass Gasket	127215	1/8 in. x 5/16 in. flat	2 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft.
<b>C 550 CB Rockland</b>			
Door Gasket	100038	3/8 in.	7 ft. 9 in.
Glass Gasket	129644	1/4 in. self-adhesive	5 ft. 6 in.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft. 4 in.
<b>C 450 Kennebec &amp; Tamarack</b>			
Front Doors	100038	3/8 in.	9 ft. 6 in.
Double Door Glass Gasket	129644	1/4 in. self-adhesive	7 ft.
Single Door Glass Gasket	129644	1/4 in. self-adhesive	7 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft. 4 in.
<b>C 350 Winterport</b>			
Front Door	100038	3/8 in.	6 ft.
Glass Gasket	129644	1/4 in. self-adhesive	4 ft. 6 in.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	1 ft. 4 in.
<b>C 370 USA</b>			
Doors Gasket	100038	3/8 in.	7 ft.
Door Glass Gasket	200024	1/4 in.	6.5 ft.
Glass Clip Gasket	127215	1/8 in. x 5/16 in. flat	6 in.