


repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840626




repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840626

Key No.	Part No.	Description
1	83242	Set Screw 1/4"-20 x 1/4" long (slotted)
2	89173	Handle, Door Latch
3	89041	Spring
4	67724	Door Latch Weldment
5	67734	Cabinet Door
6	89065	Door Hinge (4 Req'd.)
7	67733	Cabinet Door Frame
8	67743	Thermostat
9	86191	Thermostat Linkage Adjuster
10	85357	Thermostat Dial Indicator
11	67564	Lower Front Panel
12	89142	Thermostat Knob
13	89079	Pull Handle (2 Req'd.)
14	67561	Front Panel
15	67732	Cabinet Left Side
16	21593	Hinge Support
17	83833	Hinge Clip
18	67731	Cabinet Top
19	67565	Upper Front Panel
20	11450	Handle Bracket (2 Req'd-Not Shown)
21	21063	Back Brace (2 Req'd.)
22	86192	Thermostat Linkage
23	67514	Cabinet Back

repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840626



repair parts

SEARS AUTOMATIC COAL OR WOODBURNING CIRCULATOR MODEL NO. 143.840626

Key No.	Part No.	Description
1	67781	Ash Door
2	22108	Latch, Ash Door
3	21803	Rope Gasket
4	67444	Pan, Ash
5	40045	Shaker (Cast Iron)
6	22110	Floor Shield
7	17200	Hinge Pin (Draft Damper)
8	40075	Draft Damper Frame
9	67664	Base
10	67132	Draft Control Damper
11	83818	Clip (2 Req'd.)
12	40101	Coal Grate (Cast Iron)
13	17060	Thermostat Baffle
14	40130	Grate Support (5 Req'd.)
15	89066	Fire Brick (10 Req'd.)
16	67783	Heat Jacket
17	40100	Liner (Cast Iron) (3 Req'd.)
18	66960	Flue Collar
19	88032	Flue Collar Gasket
20	40132	Top Brick Retainer (Cast Iron) (2 Req'd.)
21	17210	Hinge Pin (Smoke Curtain)
22	21548	Curtain, Smoke
23	83117	Hinge Pin (4 Req'd.)
24	40102	Coal Grate Frame
25	67775	Feed Door
26	21810	Handle (2 Req'd.)
27	67567	Handle, Wood (2 Req'd.)
28	21047	Latch, Feed Door
29	21804	Gasket, Feed Door
*	85247C	Owner's Manual (F642-18982)