


repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840630




repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840630

Key No.	Part No.	Description
1	89173	Handle, Door Latch
2	83242	Set Screw 1/4"-20 x 1/4" long (slotted)
3	89041	Spring
4	67724	Door Latch Weldment
5	86191	Thermostat Linkage Adjuster
6	67863	Front Panel
7	85357	Thermostat Dial Indicator
8	89142	Thermostat Knob
9	89079	Pull Handle (2 Req'd.)
10	67732	Cabinet Left Side
11	21593	Hinge Support
12	83833	Hinge Clip
13	67731	Cabinet Top
14	21063	Back Brace (2 Req'd.)
15	67514	Cabinet Back
16	83819	Spring Clip (4 Req'd.)
17	86192	Thermostat Linkage
18	67743	Thermostat
19	89065	Door Hinge (4 Req'd.)
20	67733	Cabinet Door Frame
21	67734	Cabinet Door

repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840630



repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840630

Key No.	Part No.	Description
1	40045	Shaker
2	67806	Second Heat Shield Assm.
3	21887	Heat Shield
4	17200	Draft Damper Hinge Pin
5	40075	Draft Damper Frame
6	67859	Base
7	67132	Draft Control Damper
8	83818	Clip (2 Req'd.)
9	40101	Coal Grate
10	17060	Thermostat Baffle
11	40130	Support, Grate (5 Req'd.)
12	89066	Fire Brick (10 Req'd.)
13	67858	Fire Box
14	40100	Liner (3 Req'd.)
15	66960	Flue Collar
16	88032	Flue Collar Gasket
17	40132	Fire Brick Retainer (2 Req'd.)
18	17210	Smoke Curtain Hinge Pin
19	83117	Hinge Pin (4 Req'd.)
20	21548	Smoke Curtain
21	40102	Coal Grate Frame
22	22103	Feed Door
23	83109	Nut 1/4 - 20
24	40056	Draft Wheel
25	83181	Machine Screw, 1/4-20 x 3/4 SL FH
26	21810	Handle, Door (2 Req'd.)
27	67567	Handle, Wood (2 Req'd.)
28	21804	Feed Door Rope Gasket
29	40187	Ash Door
30	67855	Two-Step Latch
31	83045	Washer, Flat
32	83002	Lock Washer, 1/4"
33	83072	Nut, 1/4 - 20
34	21803	Ash Door Gasket
35	21047	Latch
36	67444	Ash Pan
*	85391	Owner's Manual (F642-23582)

* Not Shown