


repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840631




repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840631

Key No.	Part No.	Description
1	89062	Knob, Door
2	83033	Screw, Machine (8-32 x 1/4 PH T R HDZ)
3	83005	Screw, Machine (10-24 x 1/2 PH T R HD BLK)
4	83093	Latch, Spring
5	83244	Nut, Keps (10-24 PLN)
6	86191	Thermostat Linkage Adjuster
7	67973	Cabinet Front
8	85431	Control Panel Plate
9	89142	Thermostat Knob
10	89079	Pull Handle (2 Req'd.)
11	67963	Cabinet Left Side
12	21593	Hinge Support
13	83833	Hinge Clip
14	67965	Cabinet Top
15	21063	Back Brace (2 Req'd.)
16	67514	Cabinet Back
17	83819	Spring Clip (4 Req'd.)
18	86192	Thermostat Linkage
19	67743	Thermostat
20	89065	Door Hinge (4 Req'd.)
21	67868	Cabinet Door Frame
22	67869	Cabinet Door

repair parts

SEARS AUTOMATIC COAL OR WOODBURNING
CIRCULATOR MODEL NO. 143.840631



repair parts

SEARS AUTOMATIC COAL OR WOODBURNING CIRCULATOR MODEL NO. 143.840631

Key No.	Part No.	Description
1	40045	Shaker
2	67806	Second Heat Shield Assm.
3	22110	Heat Shield
4	17200	Draft Damper Hinge Pin
5	40075	Draft Damper Frame
6	67859	Base
7	67132	Draft Control Damper
8	83818	Clip (2 Req'd.)
9	40101	Coal Grate
10	40130	Support, Grate (5 Req'd.)
11	89066	Fire Brick (10 Req'd.)
12	67858	Fire Box
13	40100	Liner (3 Req'd.)
14	66960	Flue Collar
15	88032	Flue Collar Gasket
16	83250	Nut, Keps (1/4-20) (2 Req'd.)
17	22171	Smoke Curtain Bracket (2 Req'd.)
18	40132	Fire Brick Retainer (2 Req'd.)
19	83035	Screw, Machine (1/4-20x1/2 PH SL THZ) (2 Req'd.)
20	22090	Smoke Curtain
21	40102	Coal Grate Frame
22	83117	Hinge Pin (4 Req'd.)
23	40199	Feed Door
24	83109	Nut 1/4 - 20
25	40056	Draft Wheel
26	83105	Machine Screw, 1/4-20 x 1-1/2 SL FH
27	21810	Handle, Door (2 Req'd.)
28	67567	Handle, Wood (2 Req'd.)
29	21804	Feed Door Rope Gasket
30	40187	Ash Door
31	67855	Two-Step Latch
32	83045	Washer, Flat (1/4" Z)
33	83261	Locknut (1/4-20 Jam Top Z)
34	21803	Ash Door Gasket
35	22108	Latch
36	67444	Ash Pan
*	85391A	Owner's Manual (F642-18483)

* Not Shown