


repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840651



repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840651

Key No.	Part No.	Description
1	67169	Heat Jacket
2	65930	Cabinet Top
3	66440	Cabinet Back
4	66960	Flue Collar
5	89065	Door Hinge (2 req.)
6	67194	Cabinet Right End
7	67243	Cabinet Door
8	67367	Feed Door
9	89001	Coil Wire Handle
10	83819	Pin Clip (4 req.)
11	89062	Door Knob
12	83093	Stove Spring
13	17350	Brick Top Clamp
14	00800	Smoke Curtain
15	40055	Grate (Cast) (2 req.)
16	17120	Metal Liner Front
17	21430	Door Pin (4 req.)
18	67368	Ash Pit Door
19	83081	* Nut Hex. No. 6-32
20	83080	* Screw Round Head No. 6-32-1 1/2
21	89064	Chain
22	88042	Ceramic Glass Rope (73" for both doors)
23	17060	Thermostat Shield
24	67134	Thermostat Coil & Shaft
25	18640	Lock Plate
26	89041	Spring
27	84016	Cotter Key
28	17230	Thermostat Bracket
29	67187	Thermostat Assembly (Incl. Keys 24 thru 28)
30	85079	Thermostat Dial Indicator
31	89063	Thermostat Knob
32	65980	Ash Pan
33	21039	Draft Manifold
34	67132	Draft Damper
35	17200	Draft Damper Pin
36	65960	Base
37	65950	Front Frame
38	89066	Fire Brick (10 req.)
39	17130	Metal Liner Back
+	66000	Cabinet Left Side
+	66080	Grate Support
+	17260	Back Brace
+	17210	Smoke Curtain Hinge Pin
40	88032	Flue Collar Gasket
+	85152	Owners Manual (F642-8776)
+	67266	Base Bottom

+ Not Illustrated

* Standard Hardware Item—May be purchased locally