


repair parts

AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840653



repair parts


**SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840653**

Key No.	Part No.	Description
1	66000	Cabinet Left Side
2	65930	Cabinet Top
3	86192	Thermostat Linkage
4	66440	Cabinet Back
5	21063	Back Brace
6	65950	Cabinet Front
7	89142	Thermostat Knob
8	85204	Thermostat Dial Indicator
9	67187	Thermostat
10	86191	Thermostat Linkage Adjuster
11	67194	Cabinet Door Frame
12	89065	Door Hinge (2 required)
13	67243	Cabinet Door
14	83093	Stove Spring Latch
15	89062	Door Knob
†	85210	Owners Manual (F642-3378)

† Not Illustrated

repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840653



repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840653

Key No.	Part No.	Description
17	67169	Heat Jacket
18	17130	Back Liner
19	66960	Flue Collar
20	88032	Flue Collar Gasket
21	17150	Back Liner Support
22	66080	Grate & Liner Support
23	89066	Firebrick (10 required)
24	40055	Fire Grate (2 required)
25	17120	Front Liner
26	21548	Smoke Curtain
27	17210	Hinge Pin (Smoke Curtain)
28	17060	Thermostat Baffle
29	67367	Feed Door (Includes Key No. 30)
30	88042	Rope Gasket (73")
31	89001	Handle (Coil Wire)
32	65960	Base
33	67266	Floor Shield Kit
34	67132	Draft Damper
35	40075	Draft Damper Frame
36	17200	Draft Damper Pin
37	67444	Ash Pan
38	83818	Clip, Pin (2 required)
39	17350	Firebrick Retainer (2 required)
40	21430	Hinge Pin (4 required)
41	83819	Hinge Pin Clip (4 required)
42	67368	Ash Door (includes Key No. 30)
43	LK-26	Door Latch Kit (2 req'd) (includes Kay No. 31)
†	42-84066	Blower Kit (Optional Accessory)
†	42-99185	Connector Adaptor

† Not Illustrated