



repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840654




repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840654

Key No.	Part No.	Description
1	66000	Cabinet Left Side
2	65930	Cabinet Top
3	86192	Thermostat Linkage
4	66440	Cabinet Back
5	21063	Back Brace
6	65950	Cabinet Front
7	89142	Thermostat Knob
8	85204	Thermostat Dial Indicator
9	67187	Thermostat
10	86191	Thermostat Linkage Adjuster
11	67194	Cabinet Door Frame
12	89065	Door Hinge (2 Req'd.)
13	67243	Cabinet Door
14	83093	Stove Spring Latch
15	89062	Door Knob

repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
MODEL NUMBER 143.840654



repair parts

SEARS AUTOMATIC WOODBURNING CIRCULATOR
 MODEL NUMBER 143.840654

Key No.	Part No.	Description
16	88032	Flue Collar Gasket
17	17120	Front Liner
18	21548	Smoke Curtain
19	17210	Hinge Pin (Smoke Curtain)
20	17350	Firebrick Retainer (2 Req'd.)
21	17060	Thermostat Baffle
22	21430	Hinge Pin (4 Req'd.)
23	67367	Feed Door (Includes Handles & Gasket)
24	88042	Rope Gasket (73" – both doors)
25	67567	Wood Handle (2 Req'd.)
26	LK-26	Door Latch Kit (2 Req'd., includes Key No. 25)
27	67368	Ash Door (Includes Handles & Gasket)
28	83819	Hinge Pin Clip (4 Req'd.)
29	65960	Base
30	67266	Floor Shield Kit
31	67444	Ash Pan
32	17270	Front Brace
33	17200	Draft Damper Pin
34	40075	Draft Damper Frame
35	67132	Draft Damper
36	83818	Clip, Pin (2 Req'd.)
37	40055	Fire Grate (2 Req'd.)
38	89066	Firebrick (10 Req'd.)
39	66080	Grate & Liner Support
40	17150	Back Liner Support
41	17130	Back Liner
42	66960	Flue Collar
43	67169	Heat Jacket
†	42-84066	Blower Kit (Optional Accessory)
†	42-99185	Connector Adapter (Optional Accessory)
†	85210	Owners Manual (F642-16879)

† Not Illustrated