


# repair parts

RMOSTAT CONTROLLED  
COAL OR WOOD BURNING CIRCULATOR MODEL NO. 143.840681




# repair parts

**THERMOSTAT CONTROLLED COAL OR WOOD BURNING  
CIRCULATOR MODEL NO. 143.840681**

Key No.	Part No.	Description
1	66000	Cabinet Left Side
2	65930	Cabinet Top
3	86192	Thermostat Linkage
4	66440	Cabinet Back
5	21063	Back Brace
6	65950	Cabinet Front
7	89142	Thermostat Knob
8	85204	Thermostat Dial Indicator
9	67187	Thermostat
10	86191	Thermostat Linkage Adjuster
11	67194	Cabinet Door Frame
12	89065	Door Hinge (2 required)
13	67243	Cabinet Door
14	83093	Stove Spring Latch
15	89062	Door Knob

# Repair parts

ERMOSTAT CONTROLLED  
ALUMINUM WOOD BURNING CIRCULATOR MODEL NO. 143.840681



# repair parts

THERMOSTAT CONTROLLED

COAL OR WOOD BURNING CIRCULATOR MODEL NO. 143,840681

Key No.	Part No.	Description
17	67479	Heat Jacket
18	66960	Flue Collar
19	88032	Flue Collar Gasket
20	40132	Top Brick Retainer (Cast Iron) (2 required)
21	89066	Fire Brick (10 required)
22	21548	Smoke Curtain
23	40100	Liner (Cast Iron) (3 required)
24	17210	Hinge Pin (Smoke Curtain)
25	17060	Thermostat Baffle
26	88042	Rope Gasket (73")
27	67447	Feed Door Assembly (Cast Iron) (includes Key Nos. 26, 28, 29, 46)
28	40092	Feed Door Handle (Cast Iron)
29	89001	Handle Wire Coil
30	40131	Grate Support—Sides (Cast Iron) (2 required)
31	83818	Clip (2 required)
32	65960	Base
33	67132	Draft Control Damper
34	67266	Floor Shield
35	40075	Draft Damper Frame
36	17200	Hinge Pin (Draft Damper)
37	21552	Throttle Plate
38	40101	Coal Grate (Cast Iron)
39	67444	Ash Pan
40	21430	Hinge Pin (4 required)
41	40045	Shaker (Cast Iron)
42	67368	Ash Door Assembly (includes Key Nos. 26, 44)
43	LK-26	Latch
44	83819	Clip (4 required)
45	40102	Coal Grate Frame (Cast Iron)
46	21467	Latch Spacer (2 required)
47	17270	Front Catch Brace
*	40130	Grate Support — Rear (Cast Iron)
*	85212	Owners Manual (F642-3478)
*	42-84066	Optional Blower Kit
*	42-99185	Connector Adaptor

\* Not Illustrated