

REPAIR PARTS

CC60

Order all repair parts from your Ashley dealer by supplying the following information:

- 1. Part Name
- 2. Part Number (not key number)
- 3. Model Number





FIGURE 17 -- (HEATER REPAIR PARTS. SEE LEDGER ON NEXT PAGE FOR PART NAMES AND PART NUMBERS).





SEE FIGURE 17 FOR ILLUSTRATION OF PARTS.

KEY NO.	PART NAME	QTY. Per Heater	CC60 PART NO.
1	Inner Unit Assy. Ptd.	1	039348
2	Probe Thermostat	1	037212
3	Chain	2.5 Ft	-P5072
4	Nut Acorn	2	009028
5	Pin Inlet Cover	1	009027
6	Plate Draft Assy. Ptd.	1	039351
7	Manifold Ptd. Assy.	1	006401
8	Gasket-Manifold	2	006145
9	Leveler	4	009041
10	Tube Horizontal Ptd.	1	039577
11	Handle Knob Kit	2	024822
12	Tube Vert. Inlet Air Ptd.	1	039578
13	Liner Left Side Rear Kit	1	039579
14	Liner Left Side Front Kit	1	039580
15	Liner Left Front Kit	1	039581
16	Liner Right Front Kit	1	039582
17	Thermostat Assy.	1	009006
18	Pan Ash Assy.	1	006562
19	Angle Grate Support Kit	2	039583
20	Grate	2	006054
21	Rear Retainer Kit	1	039584
22	Liner Rear	1	009669
23	Curtain Smoke & Rod Kit	1	045383
24	Rope Gasket	1	009535-06
25	Wrap Combustor	1	039352
26	Combustor Catalytic	2	035199
27	Shield Flame Impingement	1	039243
28	Combustor Housing Drilled	1	045958
28A	Frame & Rope Assy.	1	045384
28B	Damper Bypass Drilled	1	045378
28C	Prop Plate	1	043179
28D	Rope Fiberglass	1	045379
28E	Gasket w/Adhesive	1	045376
28F	Actuator Bypass Damper	1	045342
29	Gasket	2	035177
30	Handle Spring	1	025516
31	Collar Flue Ream & Drill	1	035175
32	Liner Rt. Side Front Kit	1	039587
33	Rope Fiberglass	1	009448-01
34	Frame Feed Door	1	016097
35	Frame Ash Door	1	016093
36	Latch Ash Door Kit	1	024821
37	Latch Feed Door	1	014713
38	Rope Gasket	1	009535-01
39	Door Feed & Rope Assy.	1	016101
40	Shield Radiation Kit	1	024819
41	Pin Door	4	P626
42	Handle Kit	2	024823
43	Door Ash & Rope Assy.	1	016082
44	Rope Gasket	1	009535-02
45	Liner Rt. Side Rear Kit	1	039588
46	"S" Hook	2	011641
47	Top Cabinet Assy. Ptd.	1	046731
48	Side Cabinet Left Assy. Ptd.	1	046728
49	Shield Radiation Kit	1	024964
50	Frame Front Panel Assy. Ptd.	1	046380
51	Knob	1	004798
52	Panel Top Front	1	046360
53	Plate Ashley Logo	1	018449
54	Strip Trim	2	046370
55	Screen Center Front Ptd.	1	046379
56	Panel Bottom Front	1	046358
57	Tie Bar Assy. Ptd.	1	046376
58	Tie Bar Ptd.	1	046375
59	Rod & Nut Kit	1	040005
60	Back Cabinet Assy. Ptd.	1	039723
61	Door End Cabinet Assy. Ptd.	1	046724
62	Hinge Painted	2	039728
63	Handle & Latch Kit	1	040006
64	Cabinet Door Support	1	045574
65	Panel Thermostat Cover Pt.	1	009686

CC70

FIGURE 12
ILLUSTRATION OF REPAIR PARTS. SEE LEDGER ON NEXT PAGE FOR PART NAMES AND PART NUMBERS.



SEE FIGURE 12 FOR ILLUSTRATION OF PARTS

CUSTOMER NOTE: IN ADDITION TO THE REPAIR PART, KITS INCLUDE ANY REPLACEMENT FASTENERS WHICH WILL MOST LIKELY BE NEEDED TO INSTALL THE REPAIR PART.

KEY NO.	PART NAME	QTY. Per Heater	CC70 PART NO.
1	Inner Unit Assy. Ptd.	1	039471
2	Thermostat Assy.	1	009006
3	Chain	2.5 Ft.	P5072
4	"S" Hook	2	011641
5	Nut Acorn	2	009028
6	Pin Inlet Cover	1	009027
7	Plate Draft Assy. Ptd.	1	010327
8	Manifold Assy. Ptd.	1	006401
9	Gasket Manifold	1	006145
10	Leveler	4	009041
11	Extension Grate	1	006251
12	Frame Grate	1	007591
13	Grate Right	1	007716
14	Grate Left	1	007717
15	Cog Grate	2	007714
16	Shaker Handle	1	005256
17	Retainer Cog	1	007715
18	Angle Grate Support Assy.	2	000851
19	Pan Ash Welded	1	006562
20	Brick	5	004911
21	Side Brick Retainer	1	006076
22	Liner Rear	1	009669
23	Retainer Rear	1	006075
24	Curtain Smoke Kit	1	029207
25	Liner Kit	1	039587
26	Liner Kit	1	039588
27	Gasket	1	035177
28	Collar Flue	1	010822
29	Plate Relief Assy.	1	006289
30	Door Pin	4	P626
31	Door Feed & Rope Assy.	1	016105
32	Rope Gasket For Feed Door	1	009535-01
33	Latch	1	014713
34	Frame Feed Door	1	016097
35	Rope Gasket	1	009448-01
36	Rope Gasket	1	009535-06
37	Frame Ash Door	1	016093
38	Latch Kit For Ash Door	1	024821
39	Rope Gasket For Ash Door	1	009535-02
40	Ash Door & Rope Assy.	1	016082
41	Handle Kit	2	024823
42	Handle Knob Kit	2	024822
43	Support Front Liner	1	039824
44	Shield Handle Radiation	1	008804
45	Liner Left Front Kit	1	039581
46	Liner Right Front Kit	1	039582
47	Top Cabinet Assy. Ptd.	1	046731
48	Side Cabinet Left Assy. Ptd.	1	046728
49	Shield Radiation Kit	1	024964
50	Frame Front Panel Assy. Ptd.	1	046380
51	Knob	1	004798
52	Panel Top Front	1	046360
53	Plate Ashley Logo	1	018449
54	Strip Trim	2	046370
55	Screen Center Front Ptd.	1	046379
56	Panel Bottom Front	1	046358
57	Tie Bar Assy. Ptd.	1	046376
58	Tie Bar Ptd.	1	046375
59	Rod & Key Kit	1	040005
60	Back Cabinet Assy. Ptd.	1	039723
61	Door End Cabinet Assy. Ptd.	1	046724
62	Hinge Painted	2	039728
63	Handle & Latch Kit	1	040006
64	Cabinet Door Support	1	045574
65	Panel Thermostat Cover Ptd.	1	009686

SAVE THIS MANUAL FOR FUTURE REFERENCE.