

## VERMONT CASTINGS PRIMARY AIR SHUTTER SPECS

### Intrepid II

*Primary*



*Secondary*



### Aspen 1920



**Encore 2550**

*Secondary*



*Primary* - With the thermostat control lever located on the right side fully closed (all the way to the back), the valve should be just closed.



Make sure Flap closes all the way when the them handle is in the closed position. No gap at all is the EPA standard.

## Defiant 1945 & 1910

*Secondary*



*Primary* - With the thermostat control lever located on the right side fully closed (all the way to the back), the valve should be just closed.



Make sure Flap closes all the way when the them handle is in the closed position. No gap at all is the EPA standard.

## **Vigilant 2310**

Primary air lever fully closed. Flap 1/8" open.



Mountain View Hearth  
manuals.stove-parts-unlimited.com

**Madison 1655**

Primary air lever fully closed. Flap 5/32" open.



5/32" off the stove body

## Resolute Parlor Stove

With the thermostat control lever closed as per the photo below, flap should be just closed 100%.



**Intrepid Parlor Stove (Intrepid I/Intrepid 1302)**

With the thermostat control lever closed (pulled all the way forward) as per the photo below, flap should be just closed 100%.

